


FRONT VIEW




- (1) i `` a=aééééé
- (2) mçïÉê=Äíííå
- (3) ciåÅíáçå=hÉóë
- (4) jÉåi= hÉóë

- (5) pÅéçäééééä
- (6) ^ééçï=âÉóë
- (7) hÉóé~Ç=åÇñåí=âÉóë
- (8) oc=fåéíí= íééääå~ä

- (9) rp_=^éçéí
- (10) kiäÉéåÅ=qééääå~ä

REAR PANEL















- (11) rp_=^éçéí
- (12) op=OPOéçéí


- (13) sd^=éçéí
- (14) pÉÅéééééééééí

- (15) c~éí
- (16) mçïÉê=éçÅééí

MENU KEYS


	Sets the center frequency, start frequency, stop frequency and step frequency.		Sets the resolution bandwidth.
	Sets the span, with options for full span, zero span and last span.		Sets traces and trace related functions.
	Sets the amplitude reference level, scale and amplitude units.		The Display key configures the split-screen windowing mode and the basic display properties.
	Automatically searches the peak signal with maximum amplitude and displays it with appropriate horizontal and vertical scales.		The memory key is used to save or recall setup, trace and limit line data.
	The Marker key is used to configure the markers, as well as other related functionality.		The Preset key will restore the spectrum analyzer to the factory settings.
	Finds each maximum and minimum peak. Used with the Marker functions.		The hardcopy key is a quick save key that will save a screen-shot of the display.
	Configures ACPR and OCBW measurements.		Configures the hardcopy options.
	Sets and tests Pass/Fail limit lines.		The System key is used to configure the RS232 interface, language, update the firmware as well as other system options.

NUMERIC TERMINAL




The numeric keypad is used to enter values and parameters.

It is often used in conjunction with the arrow keys and scroll wheel.


To confirm a value press the Enter key  bâiÉé.

SCROLL WHEEL



Edit values, select listed items.

ARROW KEYS




Increment/decrement values (in steps), select listed items.

INPUT / OUTPUT CONNECTORS

RF INPUT TERMINAL

RF input port.



- Maximum input: +30dBm (+20 dBm measurable)
- Input impedance: 50 Ω
- Maximum DC voltage: ±25 V.
- N-type: female.


USB-A PORT



USB A port for saving/recalling settings/files to external memory. Only supports FAT/FAT32 formatting.

RS-232 PORT

RS232



RS 232 9 PIN DSUB
For remote control.

USB-B PORT




USB-B Device port.
For remote control.

VGA PORT



VGA video-out port.
Supports SVGA (640x480)

DESCRIPTION DISPLAY



① Reference Level

② Trace and waveforms

③ Frequency Bandwidth settings

④ Entry/Message area

⑤ Marker information

⑥ Function menu

⑦ Soft menu keys

⑧ Trace icons

MENU AND FUNCTION KEYS

