

ENGLISH

ET600

INSTRUCTION MANUAL

Digital Insulation Resistance Tester

- 125V, 250V, 500V, AND 1000V TEST VOLTAGES
- INSULATION RESISTANCE RANGE UP TO 4000 MΩ
- MEASURES 1000V AC/DC
- RESISTANCE
- CONTINUITY



1000V \approx
80k Ω



Intertek
5000573

**CAT IV
600V
CAT III
1000V**



GENERAL SPECIFICATIONS

The Klein Tools ET600 is a digital tester with four voltage ranges for insulation resistance measurements, and is also a True Root-Mean-Squared (TRMS) tester that measures AC/DC voltage, electrical resistance, and continuity.

- **Operating Altitude:** 6562 ft. (2000m)
- **Relative Humidity:** <80% non-condensing
- **Operating Temp:** 14°F to 122°F (-10°C to 50°C)
- **Storage Temp:** -4°F to 140°F (-30°C to 60°C)
- **Accuracy:** Values stated at 65°F to 83°F (18°C to 28°C)
- **Temp Coefficient:** 0.1 x (Quoted Accuracy) per °C above 28°C or below 18°C, corrections are required when ambient working temp is outside of Accuracy Temp range
- **Battery Life** with fresh alkaline batteries (EN61557):
Insulation test: Tester performs at least 137 insulation tests of 1000V DC into 1MΩ with a duty cycle of 5 seconds on and 25 seconds off.
Resistance measurement: Tester performs at least 265 resistance measurements of 1Ω with a duty cycle of 5 seconds on an 25 seconds off.
- **Dimensions:** 7.8" x 3.6" x 2.4" (200 x 92 x 62 mm)
- **Weight:** 24.6 oz. (700 g)
- **Calibration:** Accurate for one year
- **Standards:** Conforms to: UL STD 61010-1, 61010-2-030, 61010-2-033, 61557-1-2-4.
 Certified to: CSA STD C22.2 # 61010-1, 61010-2-030, 61010-2-033, 61557-1-2-4.
 IEC EN 61010-1, 61010-2-030, 61010-2-033, 61326-1, 61557-1-2-4.



Intertek
5000573

- **Pollution degree:** 2
- **Accuracy:** ±(% of reading + # of least significant digits)
- **Drop Protection:** 3.3 ft. (1 m)
- **Ingress Protection:** IP40*
*except test lead jacks, see **WARNINGS** section
- **Safety Rating:** CAT IV 600V, CAT III 1000V, Class 2, Double insulation

CAT III: Measurement category III is applicable to test and measuring circuits connected to the distribution part of the building's low-voltage MAINS installation.

CAT IV: Measurement category IV is applicable to test and measuring circuits connected at the source of the building's low-voltage MAINS installation.

- **Electromagnetic Environment:** IEC EN 61326-1. This equipment meets requirements for use in basic and controlled electromagnetic environments like residential properties, business premises, and light-industrial locations.

Specifications subject to change.

ELECTRICAL SPECIFICATIONS

INSULATION RESISTANCE

Terminal Voltage	Range (MΩ)	Resolution (MΩ)	Accuracy	Test Current
125V (0% to +20%)	0.125 to 3.999	0.001	±(2% + 10 digits)	1mA load @ 125kΩ
	4.00 to 39.99	0.01	±(2% + 10 digits)	
	40.0 to 399.9	0.1	±(4% + 5 digits)	
	400 to 4000	1	±(5% + 5 digits)	
250V (0% to +20%)	0.250 to 3.999	0.001	±(2% + 15 digits)	1mA load @ 250kΩ
	4.00 to 39.99	0.01	±(2% + 10 digits)	
	40.0 to 399.9	0.1	±(3% + 5 digits)	
	400 to 4000	1	±(4% + 5 digits)	
500V (0% to +20%)	0.500 to 3.999	0.001	±(2% + 10 digits)	1mA load @ 500kΩ
	4.00 to 39.99	0.01	±(2% + 10 digits)	
	40.0 to 399.9	0.1	±(2% + 5 digits)	
	400 to 4000	1	±(4% + 5 digits)	
1000V (0% to +20%)	1.000 to 3.999	0.001	±(3% + 10 digits)	1mA load @ 1MΩ
	4.00 to 39.99	0.01	±(2% + 10 digits)	
	40.0 to 399.9	0.1	±(2% + 5 digits)	
	400 to 4000	1	±(4% + 5 digits)	

VOLTAGE

Function	Voltage	Resolution	Accuracy (50–60 Hz)
AC Voltage (V AC) (1000V Max.)	<400V	≤0.01V	±(1.0% + 5 digits)
	>400V	≤1V	±(1.2% + 5 digits)
DC Voltage (V DC) (1000V Max.)	<400V	≤0.01V	±(0.9% + 3 digits)
	>400V	≤1V	±(1.0% + 3 digits)

Input Impedance: 10MΩ **Frequency Range:** 50 to 60Hz
Maximum Input: 1000V DC or 1000V AC RMS

RESISTANCE

Function	Resolution	Accuracy
40.0Ω	0.1Ω	±(0.5% + 2 digits)
400.0Ω	0.1Ω	±(1.2% + 5 digits)
4.000kΩ	1Ω	±(2.5% + 8 digits)
40.00kΩ	10Ω	±(2.8% + 8 digits)
80.0kΩ	100Ω	±(3.0% + 8 digits)

Maximum Input: 300V DC or 300V AC RMS

CONTINUITY BEEPER: Audible signal when resistance <30Ω, short circuit >200mA, open circuit voltage 5.5V DC

AUTO POWER-OFF: after 15 minutes of inactivity

ZERO ADJUSTMENT: Automatic

SAMPLING FREQUENCY: 3 times per second

OVERLOAD: "OL" indicated on display, 1000V RMS in voltage settings, 300V RMS in all other settings

POLARITY: "-" on display indicates negative polarity

DISPLAY: 4000 Count LCD with Dual readout

OPERATIONAL UNCERTAINTY

INTRINSIC UNCERTAINTY (EN61557)

Code	Measurement Intrinsic	Operating Uncertainty	Maximum Uncertainty*
A	Insulation Resistance	See ELECTRICAL SPECIFICATIONS	<30%
A	Earth-Bond Resistance	See ELECTRICAL SPECIFICATIONS	<30%

*Indicates maximum amount allowable by standard

INFLUENCE VARIABLES AND UNCERTAINTIES (EN61557)

Code	Variable	Range	% Within Range
E1	Position	+/- 90°	<5%
E2	Supply voltage	7.21 to 9.13V	<5%
E3	Temperature	0 to 35°C	<5%

⚠ WARNINGS

To ensure safe operation and service of the meter, follow these instructions. Failure to observe these warnings can result in severe injury or death.

- Before each use, verify meter operation by measuring a known voltage.
- **DO NOT** use the meter on a circuit with voltages that exceed the category based rating of this meter.
- **DO NOT** use the meter during electrical storms or in wet weather.
- **DO NOT** use the meter or test leads if they appear to be damaged.
- Use **ONLY** with CAT IV rated test leads.
- Ensure meter leads are fully seated, and keep fingers away from the metal probe contacts when making measurements.
- **DO NOT** open the meter to replace batteries while the probes are connected.
- Use caution when working with voltages above 25V AC RMS or 60V DC. Such voltages pose a shock hazard.
- To avoid false readings that can lead to electrical shock, replace batteries when a low battery indicator appears.
- **DO NOT** attempt to measure resistance or continuity on a live circuit.
- Make sure the circuit under test does not include components that can be damaged by 1000VDC; such devices include power factor correction capacitors, low voltage mineral insulated cables, electronic light dimmers, and ballast/starters for fluorescent lamps.
- **DO NOT** perform insulation resistance testing or earth-bond resistance testing if voltage is present on parts of an installation or equipment under test. Circuits under test (except for voltage measurements) must be de-energized and isolated before connections are made.
- Circuit connections must not be touched during a test. Accidental contact with conductors could result in electrical shock.
- After insulation resistance testing, make sure the circuit is fully discharged before removing test leads. LCD should read close to zero volts.
- Always adhere to local and national safety codes. Use personal protective equipment to prevent shock and arc blast injury where hazardous live conductors are exposed.
- Meter is IP40 dust & water resistant, except for the test lead jacks. Following any contact with water, thoroughly dry meter and test lead jacks prior to subsequent use.


SYMBOLS ON METER

- V~** AC Voltage
- V---** DC Voltage
- Ω** Resistance (Ohms)
- ⎓** Audible Continuity
- ⎓** Fuse (with rating below symbol)
- Double Insulated Class II
- ⚠** Warning or Caution
To ensure safe operation and service of this meter, follow all warnings and instructions detailed in this manual.
- ⚡** Risk of Electrical Shock
Improper use of this meter can lead to risk of electrical shock. Follow all warnings and instructions detailed in this manual.


SYMBOLS ON LCD

- H** Data Hold
- AC** AC (Alternating Current)
- B** Low Battery
- MAX** Maximum Value
- M** Mega (value x 10⁶)
- V** Volts
- ⚡** Test Voltage
- ▬** Bar Graph
- >** Greater Than
- ⎓** Audible Continuity
- DC** DC (Direct Current)
- ⏻** Auto Power Off
- MIN** Minimum Value
- k** kilo (value x 10³)
- Ω** Ohms
- LOCK** Test Lock
- Negative
- ZERO** Zero Adjustment

NOTE: The bar graph provides a visual indication of the measurement value, showing voltage for VAC / VDC, and showing resistance for insulation resistance testing.



FEATURE DETAILS



NOTE: There are no user-serviceable parts inside meter.

- | | |
|-----------------------------|---------------------|
| 1. 4000 count LCD Display | 6. "ZERO" Button |
| 2. Function Selector Switch | 7. "MAX/MIN" Button |
| 3. "COM" Jack | 8. "HOLD" Button |
| 4. "V Ω →" Jack | 9. "LOCK" Button |
| 5. Backlight Button | 10. "TEST" Button |

FUNCTION BUTTONS

ON/OFF

To Power ON the meter rotate the Function Selector switch ② from the OFF setting to any measurement setting. To Power OFF the meter, rotate the Function Selector switch to the OFF setting. **NOTE:** The meter will automatically power OFF after 15 minutes of inactivity. To disable auto-power off, press and hold the "HOLD" button ⑧ while powering on.

"BACKLIGHT BUTTON" ⑤

Press and hold the Backlight button for more than one second to turn the backlight on or off. The backlight will automatically turn off after approximately 3 minutes.

ZERO BUTTON ⑥

Press the zero button for automatic zero adjustment for voltage and resistance.

"MAX/MIN" BUTTON ⑦

When the "MAX/MIN" button is pressed, the meter keeps track of the minimum and maximum value of the measurement for VAC, VDC, continuity, and ohms. The first press of the MAX/MIN button displays the MAX value, the second press displays the MIN value. To return to normal measuring mode, press and hold the "MAX/MIN" button for more than one second.

"HOLD" (DATA HOLD) BUTTON ⑧

Press the "HOLD" button to hold the measurement on the display. Press again to release the display to return to live measuring (not for insulation resistance testing).

LOCK BUTTON ⑨

For hands-free insulation resistance testing, use the Lock button feature. With the test leads connected to the equipment under test, press the Lock button for two seconds, and then press the TEST button to begin the test. The lock icon will appear on the display and the meter will beep to indicate it is in lock mode. Press the Test button to end the test.

TEST BUTTON ⑩

With the test leads connected to the equipment under test, press and hold the TEST button to begin an insulation resistance test. The lower-right display will show test voltage, and the main display will show the resistance.

NOTE: Make sure the circuit under test does not include components that can be damaged by 1000VDC; such devices include power factor correction capacitors, low voltage mineral insulated cables, electronic light dimmers, and ballast/starters for fluorescent lamps.

OPERATING INSTRUCTIONS


CONNECTING TEST LEADS

Do not test if leads are improperly seated. Results could cause intermittent display readings. To ensure proper connection, firmly press leads into the input jack completely.




TESTING IN CAT III / CAT IV MEASUREMENT LOCATIONS

Ensure the test lead shield is pressed firmly in place. Failure to use the CAT III / CAT IV shield increases arc-flash risk.



TESTING IN CAT II MEASUREMENT LOCATIONS


CAT III / CAT IV shields may be removed for CAT II locations. This will allow testing on recessed conductors such as standard wall outlets. Take care not to lose the shields.



OPERATING INSTRUCTIONS

INSULATION RESISTANCE MEASUREMENTS

1. Insert RED test lead into V Ω jack ④, and BLACK test lead into COM jack ③, and rotate the function selector to the desired test voltage. Choose from 125V, 250V, 500V, or 1000V based on the compatibility with the device tested. **NOTE:** Disconnect the circuit under test and isolate it from any stray resistance. Insulation test should only be performed on de-energized circuits.



2. Connect the Red and Black leads to the circuit under test. If there is a voltage in the circuit, a constant beep will sound and the Test Voltage symbol ⚡ will be displayed. *Disconnect the circuit to proceed.*
3. Press and hold the TEST button to begin test. The lower right display shows test voltage, and the main display shows the resistance.
4. The measured insulation resistance is displayed on the main display in M Ω . Allow the reading to stabilize before recording the measurement. Turning the function switch, at any time during the insulation test will end the testing process.
5. The circuit will discharge through the meter. Keep the test leads connected until the circuit is completely discharged and the lower right display shows near zero volts.

NOTE: Measurements can be adversely affected by impedances of additional operating circuits connected in parallel or by transient currents.

NOTE: Overload "OL" for insulation resistance measurements is a value >4000 M Ω .

LOCK FUNCTION


For hands free testing, use the Lock feature for PI (Polarization Index) and DAR (Dielectric Absorption Ratio) testing.

With the test leads connected to the equipment under test, press the "LOCK" button ⑨, then press the "TEST" button ⑩ to begin the test. The lock icon will appear on the display. The meter will beep to indicate it is in lock mode. To end the test at any time during the process, press the "TEST" button ⑩, or turn the function switch ② to any other setting.

OPERATING INSTRUCTIONS

AC/DC VOLTAGE MEASUREMENTS

1. Insert RED test lead into V Ω jack ④, and BLACK test lead into COM jack ③, and rotate the function selector to the AC Voltage V_{\sim} or DC Voltage $V_{\text{---}}$ setting.




2. Apply test leads to the circuit to be tested to measure voltage.

NOTE: When measuring DC voltage, the main display shows the voltage measurement, the secondary display shows battery voltage.

NOTE: When measuring DC voltage, if "-" appears on the LCD, the test leads are being applied to the circuit in reverse polarity. Swap the position of the leads to correct this.

CONTINUITY

1. Insert RED test lead into V Ω jack ④, and BLACK test lead into COM jack ③, and rotate function selector switch ② to the Continuity \Rightarrow setting.




2. Remove power from circuit.
3. Test for continuity by connecting conductor or circuit with test leads. If resistance is measured less than 40 Ω , an audible signal will sound and display will show a resistance value indicating continuity. If circuit is open, display will show "OL".

⚠ DO NOT attempt to measure continuity on a live circuit.

OPERATING INSTRUCTIONS

RESISTANCE MEASUREMENTS

1. Insert RED test lead into V Ω jack ④, and BLACK test lead into COM jack ③, and rotate function selector switch ② to the Resistance Ω setting.



2. Remove power from circuit.
3. Measure resistance by connecting test leads to circuit. The meter will auto-range to display the measurement in the most appropriate range.

NOTE: When in a Resistance setting and the test leads are open (not connected across a resistor), or when a failed resistor is under test, the display will indicate O.L. This is normal.

⚠ DO NOT attempt to measure resistance on a live circuit.

MAINTENANCE

BATTERY REPLACEMENT

When B indicator is displayed on LCD, batteries must be replaced.


1. Remove screw from battery/fuse door.
2. Replace 6 x 1.5V AA batteries (note proper polarity).
3. Replace battery/fuse door and fasten securely with screw.

FUSE REPLACEMENT

1. Remove screw from battery/fuse door.
2. Replace blown fuse with 6.3 x 31.7 mm, 500mA/1000V fast-blow 10kA fuse (Klein Cat. No. 69035).
3. Replace battery/fuse door and fasten securely with screw.

⚠ To avoid risk of electric shock, disconnect leads from any voltage source before removing battery/fuse door.

⚠ To avoid risk of electric shock, do not operate meter while battery/fuse door is removed.



CLEANING

Be sure meter is turned off and wipe with a clean, dry lint-free cloth. ***Do not use abrasive cleaners or solvents.***

STORAGE

Remove the batteries when meter is not in use for a prolonged period of time. Do not expose to high temperatures or humidity. After a period of storage in extreme conditions exceeding the limits mentioned in the General Specifications section, allow the meter to return to normal operating conditions before using.

WARRANTY

www.kleintools.com/warranty

DISPOSAL / RECYCLE

Do not place equipment and its accessories in the trash. Items must be properly disposed of in accordance with local regulations. Please see www.epa.gov or www.ecycle.org for additional information.