

# **OWNER'S MANUAL**

ECCENTRIC CONE FLARING TOOLS FT800FN.FT806A.FT806M Series

### **FEATURES**

- Forms a burr-free 45° flare.
- Suitable for soft materials such as copper and aluminum.
- FT800FN designed specifically for R-410A systems
- Heat treated, black oxide finished steel flaring bars




## **OPERATION INSTRUCTIONS**

#### ECCENTRIC TYPE FLARING TOOL

Anale: 45°


Uses: Suitable for soft copper tube, aluminum tube and other soft tubes, etc.

- 1) Turn both yoke and clamp handles counter-clockwise until yoke slides freely. Move yoke to far end of flaring bar up against the stop screws (Fig. 1).
- 2) Spread flaring bar and insert tube into hole that corresponds to tube diameter. Close bar and position tube approximately 1mm above horizontal plane of flaring bar (Fig 2 & Fig.3).
- 3) Slide yoke above tube, align red arrow on yoke with positioning mark on flaring bar. Turn clamp handle clockwise to tighten and secure (Fig. 4).
- 4) Use supplied ratchet or manually turn yoke handle clockwise until clutch releases. Continue to turn another 2-3 revolutions (Fig. 5).
- 5) Turn yoke handle counter-clockwise until free from flared tubing. Loosen clamp handle and slide yoke to end of flaring bar. Spread flaring bar and remove tube (fig. 6).
- \*Always wear eye protection and hand gloves when working with hand tools.



## **MAINTENANCE INSTRUCTIONS**

- 1. Keep 45° place of the circular cone clean away from copper dust after using (Fig. 7).
- 2. Apply lubricating grease to all threaded parts on the yoke.
- 3. Apply lubricated grease to the bearing located under the flaring cone mechanism.



# SPARE PARTS

FTX800B410 R-410A bar: 3/16, 1/4, 5/16, 3/8, 1/2, 5/8 and 3/4 inch

FTX800BA Standard imperial bar: 3/16, 1/4, 5/16, 3/8, 1/2, 5/8 and 3/4 inch FTX800BM Standard metric bar: 6, 8, 10, 12, 15, 16 and 18 millimeter

FTX800R 3/8" sq. drive ratchet Yoke assembly.



Test Equipment Depot - 800.517.8431 - 99 Washington Street Melrose, MA 02176

TestEquipmentDepot.com