

Programmable DC Electronic Load

PEL-2000B Series

USER MANUAL



ISO-9001 CERTIFIED MANUFACTURER

This manual contains proprietary information, which is protected by copyright. All rights are reserved. No part of this manual may be photocopied, reproduced or translated to another language without prior written consent of the Good Will company.

The information in this manual was correct at the time of printing. However, Good Will continues to improve products and reserves the right to change specification, equipment, and maintenance procedures at any time without notice.

Good Will Instrument Co., Ltd.
No. 7-1, Jhongsing Rd., Tucheng Dist., New Taipei City 236, Taiwan.

Table of Contents

SAFETY INSTRUCTIONS	6
GETTING STARTED.....	10
Main Features.....	12
Series Overview	14
Package Contents and Accessories	16
Measurement Overview	17
Front Panel Overview.....	18
Display Overview – Mainframe	23
Rear Panel Overview	27
Front Panel Overview – Load Module	30
LED Display Overview – Load Module	33
Installation	36
Load Connections.....	44
Frame Link Connection	54
Channel Control Connection	56
Go/NoGo Connection.....	59
OPERATING DESCRIPTION.....	60
Operating Mode Description	61
Group Unit Mode	71
Run Program	73
Sequence.....	76
OCP Test Automation	80
Parallel Dynamic Loading	81
Configurations Description.....	82
Interface and System	91
TUTORIALS	98
Local loads	99
Single Channel Load	101

Parallel Load Modules	103
Programming.....	105
Sequences	107
Frame Link.....	108
Channel Control.....	110
General Configuration Options	112
OPERATION	114
Local Mode Operation	117
Mainframe Basic Operation	123
Creating a Program Sequence	146
Edit Sequence	158
OCP Test Automation	167
Channel Configuration	173
Mainframe Configuration	199
Interface Configuration (settings)	222
RS232 or RS485, LAN and USB CDC Function Check	229
GPIB Function Check	232
Saving/Recalling Channels.....	234
INTERFACE.....	269
Interface Configuration	270
FAQ.....	288
APPENDIX.....	289
Fuse Replacement.....	289
Firmware Update	290
Calibration	293
Range Chart.....	294
Default Settings	299
Specifications	302
Dimensions	313
Certificate Of Compliance	316

INDEX 317

S SAFETY INSTRUCTIONS

This chapter contains important safety instructions that you must follow when operating the PEL-2000B series, and when keeping it in storage. Read the following before operating the PEL-2000B series to ensure your safety and to keep the PEL-2000B series in the best possible condition.

Safety Symbols

These safety symbols may appear in this manual or on the PEL-2000B series.



WARNING

Warning: Identifies conditions or practices that could result in injury or loss of life.



CAUTION

Caution: Identifies conditions or practices that could result in damage to the PEL-2000B series or to other properties.



DANGER High Voltage



Attention Refer to the Manual



Protective Conductor Terminal



Earth (ground) Terminal



Do not dispose electronic equipment as unsorted municipal waste. Please use a separate collection facility or contact the supplier from which this instrument was purchased.

Safety Guidelines

General Guideline



CAUTION

- Do not place any heavy object on the PEL-2000B series.
- Avoid severe impact or rough handling that leads to damaging the PEL-2000B series.
- Do not discharge static electricity to the PEL-2000B series.
- Do not block or obstruct the cooling fan vent openings.
- Do not perform measurement at circuits directly connected to Mains (Note below).
- Do not disassemble the PEL-2000B series unless you are qualified as service personnel.
- The equipment is not for measurements performed for CAT II, III and IV.

(Measurement categories) EN 61010-1 specifies the measurement categories and their requirements as follows. The PEL-2000B series falls under category I.


- Measurement category IV is for measurement performed at the source of low-voltage installation.
- Measurement category III is for measurement performed in the building installation.
- Measurement category II is for measurement performed on the circuits directly connected to the low voltage installation.
- Measurement category I is for measurements performed on circuits not directly connected to Mains.

Power Supply



WARNING

- AC Input voltage range: 100-120Vac/ 200-240Vac (90-132Vac/ 180-250Vac)
Frequency: 47~63Hz
Power rating: PEL-2004B: 250VA Max
PEL-2002B: 150VA Max
 - Connect the protective grounding conductor of the AC power cord to an earth ground, to avoid electrical shock.
-

Fuse	<ul style="list-style-type: none">• Fuse type: T3.15A/250V
 WARNING	<ul style="list-style-type: none">• Make sure the correct type of fuse is installed before power up.• To avoid fire, only replace the fuse with the specified type and rating.• Disconnect the power cord before fuse replacement.• Make sure the cause of a fuse blowout is fixed before replacing the fuse.
Cleaning the PEL-2000B	<ul style="list-style-type: none">• Disconnect the power cord before cleaning.• Use a soft cloth dampened in a solution of mild detergent and water. Do not spray any liquid.• Do not use chemicals or cleaners containing harsh material such as benzene, toluene, xylene, and acetone.
Operation Environment	<ul style="list-style-type: none">• Location: Indoor, no direct sunlight, dust free, almost non-conductive pollution (Note below)• Temperature: 0°C to 40°C• Altitude: Up to 2000m• Transient Overvoltage on the main supply is 2500V. <p>(Pollution Degree) EN 61010-1 specifies the pollution degrees and their requirements as follows. The PEL-2000B series falls under degree 2.</p> <p>Pollution refers to “addition of foreign matter, solid, liquid, or gaseous (ionized gases), that may produce a reduction of dielectric strength or surface resistivity”.</p> <ul style="list-style-type: none">• Pollution degree 1: No pollution or only dry, non-conductive pollution occurs. The pollution has no influence.• Pollution degree 2: Normally only non-conductive pollution occurs. Occasionally, however, a temporary conductivity caused by condensation must be expected.• Pollution degree 3: Conductive pollution occurs, or dry, non-conductive pollution occurs which becomes conductive due to

condensation which is expected. In such conditions, equipment is normally protected against exposure to direct sunlight, precipitation, and full wind pressure, but neither temperature nor humidity is controlled.

Storage environment

- Location: Indoor
- Relative Humidity: < 80%
- Temperature: -10°C to 70°C

Disposal

Do not dispose this instrument as unsorted municipal waste. Please use a separate collection facility or contact the supplier from which this instrument was purchased. Please make sure discarded electrical waste is properly recycled to reduce environmental impact.

GETTING STARTED

This chapter describes the features and functions of the PEL-2000B series, including the front and rear panel appearance, panel installation and connection types. Use the Tutorial section for quick access to step by step instructions on the main functions.



Main Features	12
Series Overview	14
Package Contents and Accessories	16
Measurement Overview	17
Front Panel Overview	18
Display Overview – Mainframe	23
Rear Panel Overview	27
Front Panel Overview – Load Module.....	30
LED Display Overview – Load Module.....	33
Installation	36
Load Module Installation.....	36
GPIB Installation	39
Rack Mount Installation.....	40
Channel Number.....	41
Power Up & Self Test	42
Load Connections	44

Precautions and Procedures	44
Remote (Sense) Connection	49
Single Load Connections	50
Parallel Load Connections	52
Frame Link Connection	54
Channel Control Connection	56
Go/NoGo Connection	59

Main Features

Description The PEL-2002B and PEL-2004B are multichannel programmable DC electronic load mainframes. The PEL-2002B mainframe is able to hold 2 load modules, whilst the PEL-2004B is able to hold 4. The flexible module configuration allows the mainframes to either sink multiple loads independently or large loads when used in parallel.

The PEL-2000B series support four operation modes: constant current (CC), constant voltage (CV and CV+CC), constant resistance (CR) and constant power (CP). Constant current and constant resistance mode can operate in either static or dynamic mode.

- Feature Overview**
- Flexible operation with removable load modules.
 - Multiple independent isolated channels.
 - High performance, up to 5 digit resolution.
 - High slew rate enabling a high response speed
 - High capacity when frame linked.
 - Different load module types can be used in the same mainframe.
 - Dedicated parallel mode.
 - Supports rack mount installation.
 - Supports frame link connections, with up to 4 slave units.
 - Color LCD display.
 - 120 different sets of programmable sequences.
 - Accurate load simulation using Sequences.
-

- 4 panel setups.
 - USB flash drive support.
-


Interface

- USB
 - RS-232C/RS485
 - LAN
 - GPIB (optional)
-


Series Overview

The PEL-2000B series comprises of two different Mainframes: the PEL-2002B and the PEL-2004B. The Mainframes differ by the number of load module slots that can be accommodated. The PEL-2002B has two load module slots whilst the PEL-2004B has 4. There are 4 different load module models, the PEL-2020B, PEL-2030B, PEL-2040B and PEL-2041B.

PEL-2004B Mainframe



PEL-2002B Mainframe



The 4 different load module models each differ in the amount of current, voltage and power and the number of channels that the load module can accommodate. The procedures in this manual will be load module model independent unless specifically stated. Below is a table showing the basic differences between each load module model. For detailed specifications, please see page 302.

Load Module	Channels	Power (W) CH L/R (low/high range)	Current (A) Range Low/High	Voltage (V)
PEL-2020B (100Wx2)	2	100/100	2/20	0-80
PEL-2030B (30/(25/250W))	2	30/(25/250)	5/4/40	0-80
PEL-2040B	1	(35/350)	7/70	0-80
PEL-2041B	1	(35/350)	1/10	0-500

Package Contents and Accessories

The PEL-2000B electronic load has a number of standard and optional accessories that can be ordered. For more information please consult your authorized distributor for details.

Standard Accessories	Description
Power Cable	Mains power cable (region dependent) (18AWGx3C, 125V/10A, 1.8m)
CD ROM	Contains PEL-2000B series Electronic DC Load User Manual, Programming Manual and USB Driver
GTL-120	Load cables 2X red, 2X black (per load module)
GTL-121	Remote sense cables, 1X red, 1X black (per load channel)
PEL-003	3 sets for PEL-2004B; 1 set for PEL-2002B

Options	Description
PEL-2020B	Load Module
PEL-2030B	
PEL-2040B	
PEL-2041B	
PEL-001	GPIB interface


Optional Accessories	Description
PEL-003	Panel Cover
GTL-246	USB
GTL-248	GPIB cable
GTL-249	Frame link cable
GTL-259	RS232 cable with DB9 & RJ-45
GTL-260	RS485 cable with DB9 & RJ-45

Measurement Overview


The PEL-2000B series has a number of different operating modes that are completely configurable. All the modes have customizable Go/NoGo limits, range limits, timers, slew rates, alarms and protection limits. For parallel loads, there is a dedicated Parallel configuration mode. To make tests, Programs and Sequences can be created.


Function	Description
Constant Current Mode (CC)	In constant current mode, the load module will sink a constant amount of current, regardless of the voltage.
Constant Voltage Mode (CV)	Under constant voltage mode, the voltage remains unchanged, regardless of the current.
Constant Resistance Mode (CR)	In constant resistance mode, the resistance load will remain unchanged as the voltage and current remain proportional.
Constant Power Mode (CP)	In constant power mode, the load module will ensure the power consumed is constant.
Programmable Sequences (Prog.)	The load module supports programming sequences. With up to 120 different memory settings in 12 programs with 10 sequences.
Sequences (Seq.)	Used to create load profiles to accurately simulate a load. Sequences can be created for each channel.
Group Unit Mode	Group Unit Mode enables the PEL-2000B series mainframes to easily use load modules (of the same type/rating) in parallel. Parallel mode is used in conjunction with CC or CR modes. CP and CV mode cannot be used with this mode.

Front Panel Overview





LCD display 320 by 240, TFT LCD display.


Function keys  Assigned to the menu functions on the bottom of the display.


System Keys  CHAN/LOCAL is used to select the load channel. Combined with the shift key, Local is used to activate local control (during remote control via the interface or frame link connections).


LOCAL
 Brings up the Channel Menu.


Used to activate local control mode during remote control via the interface

 + 

 Used to access the Program, Sequence or OCP automation menu.

 Used to access the File menu.


UTILITY
 Brings up the Help menu and utility menu.



UTILITY
 Provides help for the last function /key pressed.


 +  Activates the Utility Menu.

Number pad

Enter numerical values, or to save/recall presets (P0-P9).



P0
 Number values.

 +  Preset numbers P0-P9.

CAL.
 Decimal point and Calibration key

CAL.

Decimal point.



Activate calibration mode.



Note

Please note, calibration mode is not supported. Please see your distributor for calibration needs.


LOCK



Clears current values. Alternative function locks the keys and the Selector knob.

LOCK

Clears the current value.




Locks all the keys and Selector knob.

USB Input




USB flash memory slot.


Selector Knob



Used to select operations and to increase/decrease values.



When turned left or right moves the cursor in menus or changes the selected item or value.



When pushed down, acts as the Enter key.

Operation Keys



Saves and recalls preset settings and values.


When pressed in combination with the number pad, Presets P0-P9 can be recalled or saved.



Inactive




Active. Used in combination with the number pad and/or shift key.



Press to recall a channel preset

Hold to save a channel preset



Press to recall all channel presets.

Hold to save all channel presets.




The shift key is used to access alternate functions assigned to select keys.

The shift key is also used to toggle between coarse and fine control mode when used in conjunction with the selector knob to adjust parameters.





Inactive mode.


 Active. When active the shift key can be used to access the Local and Utility menus.


 +  Coarse control mode.

 +  Fine control mode


 Confirms selections.

 Turns the current load/channel on or off

 Load is currently off. (unlit)

 Load is currently on. (orange light)


Power

 Turns the unit on or into standby mode.


 Standby mode.

 On.

Display Overview – Mainframe



Mainframe Status Panel The Mainframe Status Panel displays the status of the Mainframe interface, programs and alarm status.



Frame Link Status

FRM	Indicates Frame Link is turned on and that the mainframe is set as either a master (FRM) or slave (FRS) unit.
↕	
FRS	

Load Type


The Load Type Icon indicates if a Sequence (SEQ) or Program (PROG) is turned on. If not then LOAD is displayed as default. When any Load type is running, their icon will turn orange.

Interface Status

The interface status icon displays which interface type is set.

Current Operation Channel Status Panel

The Current Operation Channel Status panel generally displays the status of the current channel.



Channel	CH1~ CH8	Displays the current channel.
	*CHx	* = independent mode
	CHxS	S = Group channels Sync mode
	CHxP	P = Group channels Parallel mode

Mode Displays the current mode.

CCL	CC Static Low Range
CCH	CC Static High Range
CCDL	CC Dynamic Low Range
CCDH	CC Dynamic High Range
CRL	CR Static Low Range
CRH	CR Static High Range
CRDL	CR Dynamic Low Range
CRDH	CR Dynamic High Range
CVL	CV Static Low Range
CVH	CV Static High Range
CPL	CP Low Range
CPH	CP High Range

Go/NoGo SPEC If Go/NoGo is turned on,
SPEC will be displayed.

Response Speed	Slow1/ Slow2/ Slow3	In CV mode the response speed will be shown, Slow or Fast.
	Fast	

Channel Control	EXT	When Channel Control is set to External, EXT will be displayed.
-----------------	-----	---

Voltage Range	Displays the voltage range of the current setting.
---------------	--



Menu	Shows the current menu.
------	-------------------------

- main = Chan menu
- conf = Chan→Configure menu
- s_edit = Chan→Seq.Edit menu
- file s_loop = File menu
- = Chan→Seq.Edit→Loop menu

Main Screen	Main display screen.
-------------	----------------------


Menu Icons	F1~F5	Each Menu Icon is controlled by the F1~F5 function keys directly below.
------------	-------	---

Rear Panel Overview




Go/NoGo Output

GO / NG OUTPUT The Go/NoGo Output terminal outputs a pass (high)/fail (low) voltage for each channel.



See page 277, 59 for details.

GPIB port




The GPIB port is used for remote control connections.

GPIB: 24-pin female

See pages 270 for remote control details.

LAN port



Ethernet port for controlling the PEL-2000B remotely.


See pages 237 for remote control details.

USB-B (Device) port



The USB-B (device) port, like the RS232C/RS485/GPIB/LAN port is used for remote control.

Frame Control Port



The Frame Control port is used for Frame Link connections. Mainframes are daisy-chained together. There are two Frame control ports.


1: Slave

2: Master

Connection type: MIL 20-pin connector.


For details about frame link connections see page 54, 274.

Power Switch



External Power Switch

Power Socket/
Fuse




The power supply socket accepts the AC mains Voltage. The fuse holder is located below the power socket.

Power: 47~63Hz
Fuse: T3.15A/250V

For fuse replacement details see page 289.

Channel
Control port
(1~8)




Each channel has a dedicated Channel control port to enable external monitoring and control. The channel control port has 6 wire sockets that are screw-less and self clamping.

Required wire gauge: 24 AWG

For connection or specification details see pages 56 & 272.

Remote-IN port



Two different types of cables can be used for RS232 or RS485-based remote control.

RS232-232: RS232 cable with DB9 connector kit.


RS485-485: RS485 cable with DB9 connector kit.

Remote-OUT
port



RJ-45 connector that is used to daisy chain power supplies with the Remote-IN port to form a communication bus.

Front Panel Overview – Load Module



LED display 2x5 digit custom LED display.

Right/Left Key
or
A/B Key



The L/R key is used to switch between the right and left load channel on a dual channel load module. The A/B key is used to switch between A&B Values for single channel load modules.

Display Key



Used to alternate the display output on the load module.

0.0000 **A** Current

0.000 **V** Voltage

0.00 W Power


0.0 s Load time

Load Key




Activates the load for the active channel. (Right or Left)(A or B)

Left Voltage Sense



The voltage sense terminals are used when precise measurement is needed. V Sense terminals are used to compensate for voltage drops across the main terminals caused by the resistance of the load wires.


Right Voltage Sense



It is automatically activated when connected to a DUT.


The voltage difference between the DUT and load voltage should not exceed 2V, otherwise you will get incorrect measurement for the voltage. (applicable to all models)

Positive and Negative Terminals Left



The terminals for both the left and right side of a load can draw differing amounts depending on the load module specifications.

Positive and Negative Terminals Right



For 2 channel load modules, the left terminals are used for the 1st channel and the right terminals are used for the 2nd channel.

On single channel load modules, the left terminals are the lower (-) potential terminals, whilst the right terminals are the positive (+) potential terminals.

Static/Dynamic
Selector Key




The STATIC/DYNA. Key manually switches the load from Static (manual) to Dynamic loads.

Dynamic loads are only supported in CC and CR mode.

For more information see page 61 & 64.

Slave Knob
(Load)



The Slave Knob is used to edit and vary parameters for the active channel on the local load.

Depending on the Mainframe setup, the Slave Knob will either only update the load (locally) or will update both the local module and the mainframe*. The Slave Knob can also be configured to display measured or set values on the local load module**.

* For more information on “Knob Type”, see page 206.

** For more information on “Slave Knob”, see page 209.

Short Key




The SHORT key is used to manually short circuit the active channel on the local active load.

The Short key can be set to enable or disable in the configure setting.

Please refer to page 181 for details.

Load on: Pressing or holding the SHORT key will short the load, depending on the short type selected.

LED Display Overview – Load Module



① & ②
Channel Display



R_{or}L Left and right channel indicator.



5 digit display.

③ & ⑦
Channel Number Indicator



CH Indicates the channel number (1-8).

L-ON Indicates if the load is active on the load module. (Dual channel load modules)

ON Indicates if the load is on for single channel load modules.

④

Mode Indicator

The Mode Indicator LEDs will indicate what the current mode or settings are on the active channel(s).

AB CC CV CR CP Disp. GO
LR Static Dyna. Short NG

- A_{or} B** Value A or B for a single channel load module. Applies to CR, CV, CP and CC static mode only.
- CC** Constant Current Mode (CC) mode activated.
- CV** Constant Voltage Mode (CV) mode activated.
- CR** Constant Resistance Mode (CR).
- CP** Constant Power Mode (CP).
- Disp.** Display is shown on dual channel load modules when both left (L) and right (R) channel information is displayed.
- Press the Display button repeatedly to show information for both channels.
- GO** Lights up when Go/NoGo is activated and the load passes (GO) the Go/NoGo limits.
- L_{or} R** L or R will light up when the left or right channel is selected.
- Static** Lights up when in Static mode.
- Dyna.** Lights up when in Dynamic mode.
- Short** Lights up when a load is shorted.

NG Lights up when Go/NoGo is activated and the load fails (NG) the Go/NoGo limits.

⑤ & ⑥
Channel Unit
Indicators

VΩ
SAW

The Unit Indicators display the current unit.

V Voltage

Ω Resistance

A Current

W Power


S Second


Installation

The installation chapter describes how to load the different load modules, install the optional GPIB card, the rack mount kit and how to determine each channel number.

If you need to move all installed device to another location, please disassembly the modules first, and then reassembly the modules after moving to the desired location.

Load Module Installation

 **WARNING** To avoid static electricity, please use appropriate anti-static work practices.


 **Note** If your Master is PEL-2004A/ PEL-2002A, the mainframe firmware version must be V3.01.UPG or above.

The firmware file and upgrade procedure can be downloaded on the GWInstek website.


Module installation The PEL-2004B and PEL-2002B can accommodate 4 and 2 load modules, respectively. Module loads can have 1 or 2 channels. Installation of load modules is the same for both models.

Steps


1. Ensure the mainframe is turned off from the rear panel.
Disconnect the power cord.




- Slide the module onto the rails of an empty load slot.




- Use the supplied screw to fix the module to the load slot, located under the load terminals.



- Install any additional modules as described above.
- If there are any slots empty, install the supplied panel cover (part number: PEL-003). The panel cover will improve safety and increase air flow.



6. Use the supplied screws to fix the panel cover(s) over the load slot.



GPIB Installation



WARNING



To avoid static electricity, please use appropriate anti-static work practices.

GPIB Card installation

The PEL-2004B/PEL-2002B has GPIB as an option (part no. PEL-001).

Steps

1. Ensure the mainframe is disconnected from mains power.
2. Remove the screws from the GPIB cover plate and remove the cover plate from the rear panel.
3. Slide the GPIB card into the slot and push gently until the back plate is flush with the rear panel.



4. Use the screws that were removed from step 1 to secure the GPIB card.


Rack Mount Installation

Background The PEL-2004B can be used in a standard 19" rack mount enclosure with the optional rack mount kit (part no. 11EL-20040201). Each unit requires a rack height of 4U with a 1U space for ventilation top and bottom. The rear of the rack mount enclosure must be free of obstruction to allow heat to dissipate from the mainframe(s).


Steps

1. Screw the rack mount brackets as shown below using the supplied bolts.

PEL-2004B



2. Insert into a standard 19" rack enclosure with at least 1U of space top and bottom for ventilation.




Channel Number

Description The channel number for a module load is determined by which slot it occupies on the mainframe chassis. There can be 1 or 2 channels per slot, depending on the load module type.

The PEL-2002B has two slots; The PEL-2004B has 4 slots. Channel 1 is the farthest away from the main display panel and channel 8 (PEL-2004B) or channel 4 (PEL-2002B) is the closest to the main display panel.

Below the PEL-2004B has all 4 slots occupied with the PEL-2020B, PEL-2030B, PEL-2040B and 2135MH load modules (LM), respectively. The PEL-2020B & 2225ML have 2 channels per load module, the PEL-2040B & PEL-2041B have only 1. So the channel determination is:


LM1: CH1, CH2; LM2: CH3, CH4; LM3: CH5;
LM4: CH6.




Power Up & Self Test

Panel operation

1. Connect the power cord to the power socket.




2. Turn the external power switch on.



3. Hold the power button on the front panel to turn on the power.



The power button turns green from red (standby).



 **WARNING**

Ensure that the power outlet has a ground socket. The power outlet will have a ground connection if it is a 3 socket type.


Upon turning on, the Mainframe will perform a self-test. The self-test checks the System, followed by any attached channels.

 **Note**

When the firmware version of the mainframe and the slave are not identical, a message will appear on the mainframe.

Initial	System	Success
	CH1	Success
	CH2	Success
	CH3	Success
	CH4	Success
	CH5	Success


When the system check happens, the load modules will display each channel as it is checked, then display the current mode.



- If any of the System checks fail, please power down the load and reinstall the appropriate load module(s).
- To turn off the load, hold the power button for a few seconds.



The PEL-2000B mainframe will return to standby mode.



Load Connections

Precautions and Procedures

Introduction	<p>The PEL-2000B series supports a number of different load configurations for flexible operation.</p> <ul style="list-style-type: none">• Single DUT, single load• Single DUT, parallel load• Multiple DUTs, multiple loads• Multiple DUTs, multiple mainframe loads• Single DUT, parallel mainframes <p>The PEL-2000B series also supports a number of different control methods and interfaces. The connections used are described here:</p> <ul style="list-style-type: none">• Frame link• Channel control• Go/NoGo
Wire Gauge considerations	<p>Before connecting the PEL-2000B series, wire gauge must be taken into account. Load wires must be large enough to resist overheating when a short-circuit condition occurs as well as maintain a good regulation. The size, polarity and length of a wire are all factors in determining if a wire will withstand short circuiting.</p>

Wire Selection Wires that are selected must be large enough to withstand a short circuit and limit voltage drops to no more than 2V per wire. Use the table below to help make a suitable selection.

AWG	Max Current A(Amp)
24	7.64
22	10.0
20	13.1
18	17.2
16	22.6
14	30.4
12	40.6
10	55.3

Load Line Inductance Considerations When using the PEL-2000B series, voltage drop and voltage generated due to load line inductance and current change must be taken into account. Extreme changes in voltage may exceed the minimum or maximum voltage limits. Exceeding the maximum voltage limit may damage the PEL-2000B series.

To determine the voltage generated, the following equation can be used.

$$E = L \times (\Delta I / \Delta T)$$


E= voltage generated

L=load line inductance

ΔI = change of current (A)

ΔT = time (us)


Load line inductance (L) can be approximated as 1uH per 1 meter of wire. ($\Delta I / \Delta T$) is the slew rate in A/us.



The diagram above shows how changes in current can affect voltage.

Limiting Load line inductance Load line inductance can be reduced by ensuring load wires are as short as possible and by twisting positive and negative load wires together. Current change can be limited by limiting the slew rate when switching.

“Twisted pair” will be shown on any connection diagram where the load wires should be twisted together.



Load module considerations


The PEL-2000B series supports single and dual channel load modules.

Single channel load modules have one bank of negative terminals and one bank of positive terminals. Each terminal pair has a 40A capacity. For higher loads, each terminal can be wired in parallel to increase capacity.

Dual channel load modules have one bank of positive and negative terminals for each channel.

Single Channel Load Module

Dual Channel Load Module



Connection

Follow the procedure below for all load connections.




CAUTION

Ensure that power is off from the load and the DUT before making any connections.

Steps

1. Carefully lift the terminal covers.
2. Connect the positive (+) terminal on the load module to the high potential output of the DUT.
3. Connect the negative (-) load terminal to the low potential output of the DUT.




4. Close the terminal cover securely. Ensure the wires are secured properly and that the wires are not exposed when the cover is in place.

 **WARNING**

Ensure that the wires are tied or twisted together to prevent noise and inductance.



 **CAUTION**

Ensure the polarity is correct before proceeding with any connections. Using the wrong polarity could result in reverse voltage damage.




Ensure the input voltage doesn't exceed specifications. Exceeding the voltage specifications could result in damage to the instrument.

Terminal description and screw type





Remote (Sense) Connection

Background The electronic load modules have two voltage sense contacts: $V_{sense +}$, $V_{sense -}$. Voltage sense can be used to help compensate for long cable length. The longer the cable, the higher the potential resistance and inductance, therefore a short cable is best. Twisting the cable can help reduce induced inductance and using the V_{sense} terminals compensates the voltage drop seen across the load leads, especially leads with higher resistance. This is useful when used in CV, CR or CP mode.

 **WARNING** $V_{sense +}$ must have a higher potential than $V_{sense -}$.


Connection The diagram below shows how a DUT can be connected using voltage sense. Note that the sense wires are also twisted pairs.



 **Note** The wire gauge for the sense wires should be no smaller than 16 gauge.

Input The voltage sense terminals must use a wire gauge of 16 to 14 (Diameter 1.29mm ~ 1.63mm).


Remote Sense Terminal connection The voltage sense terminals use a screw-less clamp connector. The clamp must be opened prior to inserting a wire. Use a small screwdriver to push the clamp release mechanism. Insert both wires then release the clamp mechanism.



Single Load Connections


Dual Channel Load Module Connection

A dual channel load module can be used to sink two loads concurrently.




Single Channel Load Module Connection

On a single channel load module, the left terminals are both negative (-), whilst the right terminals are both positive (+). Note this also applies to the voltage sense terminals.




CAUTION

For loads exceeding 40A, both positive and both negative terminals must be used in parallel.



DC Connection For purely DC operation, a resistor and capacitor can be connected in parallel to the electronic load to reduce oscillation. The capacitor and resistor values are dependent on the load settings. Ensure the capacitor ripple current is within allowable limits.




Low Voltage Connection Using the load with low voltage loads is generally limited to over 1 volt (load module dependent). In order to support low voltage loads, an auxiliary power supply is needed to boost the voltage to a range suitable for the load.

Precautions:

- Take into account the combined power of the load and auxiliary power supply.
- Make sure the auxiliary power supply is able to provide enough current.
- Take into account any noise or irregularities from the auxiliary supply.

The diagram below shows a typical connection.



Using an auxiliary power supply may induce reverse current. The PEL-2000B series has reverse voltage protection. For details see the protection section on page 82.


Parallel Load Connections

Parallel load modules

When the power output of a DUT exceeds the power rating of a channel or load module, the channel terminals, load modules or mainframes can be used in parallel to dissipate more power when used in CC or CR mode. Each channel will sink the amount of current specified. The total power sunk is the sum of all channels/modules. The amount of power can vary from each channel. For example if CH1 is 25A and CH2 is 20A, then the total current sunk is 45A. Parallel loads are supported for both static and dynamic loads (see page 80 for a description on parallel dynamic loading). Note that the same modules must be used when operating the parallel.

The PEL-2000B series also features a dedicated parallel configuration setting known as Group Unit. When Group Unit is turned on, load modules of the same type and rating to be used in parallel for CC and CR mode. See page 71 and 195 for more information.

Parallel load






Note

Please note that the same load modules must be used in parallel.


Parallel loads using frame link connections

The PEL-2000B series mainframes can also be connected in parallel. Please note, when using a frame link connection there is a delay between the master and the slave. Please see page 54 for details.



Multi-output power supply load

The PEL-2000B series is also able to sink a number of loads concurrently from multiple DUTs or sink a number of loads from the same DUT (i.e. multiple output power supply).




Frame Link Connection

Background

Frame link control involves connecting multiple mainframes using the frame link connections. Up to 4 slave mainframes can be connected to the master mainframe. The first mainframe (master) can be used to control the other slave frames. There is a delay time of $2\mu\text{s}$ between the master and first slave mainframe, and $4\mu\text{s}$, $6\mu\text{s}$, and $8\mu\text{s}$ to the second, third, and fourth slave mainframes, respectively. The connectors used are standard MIL 20-pin connectors. For pin arrangement, see page 274. The frame link cable (part no. GTL-249) is an optional accessory, see page 16 for details.


Frame Link Connection




The first mainframe that is connected is the master frame; any additional frames are slave units. The ribbon cable connects to the master from connector 2, and the slave from connector 1. Each successive slave unit is connected in a cascading manner the same way.

Ensure the Mainframes are turned off before connecting the ribbon cables. Push the cable into the frame link connector. Ensure the arrows line up. The latches will close when the connection is complete. To remove, pull the latches out and connector will come out.

Insertion



Removal



WARNING

Ensure all the mainframes are off and disconnected from mains power before connecting.


Channel Control Connection

Background


The Channel Control connectors are located on the rear panel of each mainframe. There are two channel control connectors for each load slot, one for each channel, if applicable. The channel control connector is used to externally:

- Turn on/off loads.
- Supply a reference voltage.
- Monitor the load input.

For further details on channel control and the interface see pages 87, 272.




The Channel Control input/output pin layout is shown below.



External Voltage Connection

The external voltage reference input must be between 0~10V.




Ensure the external voltage reference is stable and has low noise. The External Voltage should be no more than 10V.

The input impedance of the EXT VREF pin is 500kΩ.

No more than 12 volts may be used as an external voltage. More than 12 volts may damage the load.

Load on connection

To turn a load on, an active low voltage (0-1V) must be applied across Load On (pin 5) and GND (pin 1), similarly an active high voltage (2.4-5V) must be applied to turn a load off. The Load On input must be TTL.




Voltage and Current Monitor Output

The Voltage Monitor Output (VMON) and Current Monitor Output (IMON) output the load input voltage and load input current as a percentage of rating current/voltage. Where 0 volts = 0% rating and 10 volts = 100% load input rating voltage or current.


The voltage monitor output is across pins 1 & 3, and the current monitor output is across pins 1 & 2. Pin 6 outputs a +15V reference voltage.

Below shows the pin configuration of the voltage and current monitor outputs.



Connector Connection

The channel control connector is a screw less clamp connector. The internal clamp mechanism must be opened before a wire can be inserted. To open the internal clamp, push the button above the wire socket, to close, release the button. Ensure at least 10mm is stripped from the wire. The diagram below shows the wire insertion procedure.



! WARNING

All connections to the channel control connector must use a 24 AWG wire gauge.

The output impedance of the V MON and I MON pins is 10kΩ.


The “+15V on pin6” used by customer application < 100mA Hold on 200mA.

Go/NoGo Connection

Background

The Go/NoGo port is a 15 socket port. Each channel has a dedicated line for a Go/NoGo output. The ports are open-collector with active high (30V) indicating a pass and active low (1.1V) as fail (an alarm). The Go/NoGo terminal is a DB-15 female.

For more details on the Go/NoGo interface see page 277.



OPERATING DESCRIPTION

Operating Mode Description	61
Constant Current Mode	61
Constant Resistance Mode	64
Constant Voltage Mode	66
Constant Power Mode	69
Group Unit Mode	71
Run Program	73
Sequence	76
OCP Test Automation	80
Parallel Dynamic Loading	81
Configurations Description	82
Protection Modes	82
Operating Configurations	84
Channel Control	88
Interface and System	91
Interface	91
File System	91
File Format	96


Operating Mode Description

There are four basic operating modes: constant current (CC), Constant Resistance (CR), Constant Voltage (CV/CV+CC) and Constant Power (CP). All channels operate using any of the modes. Each mode has a number of configurable options including slew rate, levels, protection modes, Go/NoGo and extensive save options.

Constant Current Mode

Background In Constant Current Mode the load units will sink the amount of current programmed. Regardless of the voltage, the current will stay the same. There are two ranges in CC mode: High and Low. There are two main modes in CC mode: Static and Dynamic. Static mode can be used for stability tests and dynamic mode can be used to test transient load conditions.

Go/NoGo is supported for both High and Low range as well as Static and Dynamic mode.




Range There are two selectable ranges for constant current mode: high and low range.

Low range has a higher resolution, but a lower range. If the current exceeds the Low Range, High range must be used.

Static Functions Static mode tests the stability of the voltage output from a power source. Single channel load modules can have two 2 current levels A (A Value) & B (B Value). A & B have the same range. Pressing the A/B key on the module load will cycle through the A and B states. Alternatively, the mainframe can select A or B Value.

Dual channel load modules only have one current level (A Value) per channel in static mode.


Static Mode:
Single Channel Load module.



Dynamic Functions


Dynamic load functions allow you to set load levels (Level1, Level2), load time (Timer1, Timer2), and the slew rate (rising, falling). Depending on the settings, the load will switch automatically between levels 1 and 2.

Dynamic loading can be used for charge discharge cycle testing etc.



Slew rate


The slew rate is the rate at which the current will increase to a set level. There are two slew rates: rising slew rate & falling slew rate. In CC mode the slew rate is defined as A/uS.




As can be seen above, the rising and falling slew rate need not be the same.

Go/NoGo

Using Go/NoGo, the Center, High and Low voltage limits can be set for both Static and Dynamic modes. A delay time of up to 1 second can also be set.






GO is specified as between the Low and High Go/NoGo limits. NoGo is specified as outside the Go/NoGo limits.

Constant Resistance Mode

Background


In Constant Resistance Mode the load units will linearly sink current and voltage to match a set resistance. CR mode has two different values (single load modules), two different ranges and rising and falling slew rates. Like CC mode, Constant resistance mode supports both dynamic and static loads. As with the other modes, Go/NoGo is supported.




Resistance Range There are two ranges: High and Low. The Low range is used for low voltage ranges, whilst the High range uses high voltage ranges. The current range always remains in High range, regardless of the selected resistance range.

Static Functions A/B range For static mode, single channel load modules have two resistance levels. A & B have the same range. The A/B key can be used to switch between these resistance levels. Dual channel load modules only have one resistance level, A Value.

Single Load Module




Dynamic Functions CR mode supports Dynamic loading. Dynamic load has two resistance levels (Level 1&2), and two timers (Timer 1&2) to switch between the resistance levels. Rising and falling slew rates can be set to determine the speed at which the load switches between load levels.



Slew Rate The rising and falling slew rate (A/uS) determines the speed at which the load levels change from A to B Value (Static mode) or from Level1 to 2 (Dynamic mode) and vice versa.

Go/NoGo Go/NoGo is also supported. Center, High and Low limits can be set as either percentages or voltage values. A delay time of up to 1 second can also be set.




Constant Voltage Mode

Background In Constant Voltage Mode the load units will sink current whilst keeping the voltage constant.


Single channel load modules support 2 values (A Value, B Value) and have an adjustable cut-off current limit. Dual channel load modules only have A value.

Response speed can also be set to fast (Fast) or slow (Slow). The response speed relates to the slew rate of the current response.

Go/NoGo functionality is also supported either as a percentage or as a current value.




Voltage levels Two voltage levels can be set: A & B (single channel load module).



CV + CC When using CV mode, a current limit can be set for CV + CC mode.


When the voltage input is greater than A Value (load voltage) then the channel will operate in CV mode if the input current is less than the current limit. When the input current exceeds the current limit, the channel will operate in CC mode.

When the voltage input is less than A Value (load voltage) current stops flowing.



Response Speed Response speed can be set to fast, slow1, slow2 or slow3. Fast response and slow1 (slow2/slow3) response are determined by the load module specifications. Slow response speeds are suitable for large loads as quick current changes will induce induction which can cause large voltage drops. The PEL-2000B series will try to rectify any voltage drops. However if voltage drops are too large, they may cause the load to go into oscillation. Large voltage drops caused by line voltage induction may damage the machine.

Go/NoGo Go/NoGo testing can be with either current (Ampere) values (High, Low) or percentage values (Center, High %, Low %). A delay time of up to 1 second can also be set.




Constant Power Mode

Background In Constant Power Mode the load units will ensure a constant power load for the power supply.


Single channel load modules support 2 values (A Value, B Value) and have an adjustable cut-off current limit. Dual channel load modules only have A value.

Constant power mode can operate in high or low range.

Go/NoGo functionality is also supported either as a percentage or as a current value.




Power levels Two power levels can be set: A & B (single channel load module).




CP + CC When using CP mode, a current limit can be set for CP + CC mode.
 When the constant power current is less than current limit, the channel will operate in CP mode.
 When the constant power current exceeds the current limit, the channel will operate in CC mode.

High/Low Range There are two ranges: High and Low. The Low range is used for low power ranges, whilst the High range uses high power ranges.



Go/NoGo Go/NoGo testing can set High and Low Current limits as a Value (in Amperes) or as a percentage. A delay time of up to 1 second can also be set.



Group Unit Mode

Background The Group Unit menu allows load modules of the same type and rating to be configured as a single unit when used in parallel. This saves the hassle of configuring each channel individually.

Group Unit is only supported under CC and CR mode.

Group Unit has three configuration settings: Total Unit, Group Mode and Display Mode.

Total Unit This configuration setting sets the number units that are to be used in parallel and enables or disables the Total Unit mode.

Group Mode The Group Mode setting determines how the Current Levels/Resistance Values are set when used in parallel. There are two settings: Para and Sync.

The Para setting allows the all the parallelized load modules to be operated as a single large load module.

Sync mode allows the settings of a single unit to be synchronized across all the other parallelized load modules.

CC Example Consider 3 load modules set to CC mode in Parallel.



In CC mode the total current for all units is the sum of each unit.

$$\text{Total } I = I_1 + I_2 + I_n$$

For example, to set a total load current of 90A, the Current Level setting in Para mode would be 90A, whilst it would be 30A in Sync mode.

Para mode

Sync Mode



CR Example



When used in CR mode, the equation for equivalent resistance for all the parallel loads is:

$$\frac{1}{R_{e q}} = \frac{1}{R_1} + \frac{1}{R_2} + \frac{1}{R_n}$$

For example, if 2 load modules have a set resistance of 100Ω each, the equivalent resistance of the load modules would be 50Ω. The Level setting in Para mode would be 50Ω and 100Ω in Sync mode.

Para mode

Sync Mode



Display Mode


Display mode determines what units are displayed on the local load modules: V/I, V/W, I/W, S. The displayed units can only be controlled through this menu.

Run Program

Background The Program function on the PEL-2000B series supports a total of 12 different programs at any one time with 10 sequences to each program. Up to 12 programs can be chained together. The Program function is able to create a number of Go/NoGo tests.

Run Program is not supported in Group Mode (page 71).

Program Sequence A program sequence is simply a single load test. A program is a battery of each of these tests run in succession. Each sequence loads the settings for each channel from Memory Data (Memory MXXX). The Memory Data stores settings such as the operating mode and range for each channel. Each sequence loads all channels at the same time, unless programmed otherwise. Sequences for each channel run synchronously.




Each Sequence has a number of configuration options that apply to all the channels equally.

Sequence Item	Description
Memory	Loads the channel settings for each load module Range: M001~M120


Run	<p>Sets the running configuration for the current sequence. The sequence can be skipped, run or run manually only.</p> <p>Range: Auto Skip Manual</p>
On-Time	<p>Sets the Sequence Run On-Time</p> <p>Range: 0.1 ~ 60.0s</p>
Off-Time	<p>Sets the Sequence Off-Time</p> <p>Range: Off 0.1 ~ 60.0s</p>
Short-time	<p>Sets whether the Short-Time for the sequence.</p> <p>Range: Off 0.1s ~ On-time</p>
P/F-Time	<p>Sets the Pass/Fail time for the sequence</p> <p>Range: Off 0.1 ~ (On-Time+Off-Time)-0.1s</p>
Short Channel	<p>Selects which channel will be shorted during the sequence</p> <p>Range: CH1 ~ CH8</p>

Program

Sequences are run sequentially to create a Program. There are 10 Sequences in each Program.



If less than 10 Sequences are desired for a Program, any additional Sequences can be skipped (not run).



Sequence 2 & 3 are skipped.

Program Chain Any of the 12 programs can be chained together to create a Program Chain. Unlike Program Sequences, Program Chains need not be run sequentially in numerical order. Any program can be chained to any program. It is possible to chain programs into an infinite loop to continue a program indefinitely.



Above, a program chain running sequences out-of-order.

Go/NoGo Results If Go/NoGo limits have been configured, the Pass/Fail results for each channel will be displayed for all the sequences and programs.

The screenshot shows a device display with the following content:

- Header: 05/04/22, 16 : 50, and a green **PROG** indicator.
- Title: **Channel** in green.
- Table of results:

Program no.	S	1	2
P	1	G	N
S	1	G	N
1	2	G	N
1	3	G	N
1	4	G	G

The text 'Go/NoGo' is displayed to the right of the table. At the bottom right, there is an 'Exit' button.

Sequence

Background The Sequence function is used to create high resolution load simulations. Each Sequence can be configured to create a unique load profile to accurately simulate loads in real time. Sequences are only applicable for CC (Static) and CR (Static) modes.




Note

Sequences are not to be confused with the sequences used to create a program. They are not the same and cannot be used interchangeably. Sequences (SEQ memory) cannot be used in Programs and Programs cannot load Sequences.

Load Profiling The Sequence function is able to simulate a load to a high resolution. Each channel is able to change its load sink within 25us ~ 60000s per point independently. When used in parallel, multiple loads can be set concurrently to simulate the loads placed on multiple output power sources.


The diagram below shows the load profile of a DUT at start-up.



Points

Up to 120 points can be used with each Sequence. Each point can have a different duration, slew rate and value.


A new point can be inserted or deleted at any stage of a Sequence. Any new points that are inserted will have a value averaged from its neighbors as default.



A new point is inserted after Point 3.

Loop

Sequences can be programmed to loop a number of times starting from any point in the sequence.




From Point3 the sequence is looped two times.


Trig In The Trigger In setting allows a sequence to start after a trigger (Trig Out) has been received via the frame link connector. The Trig In setting is used for frame linked mainframes.

Channel Duration Time Setting The Channel Duration Time Setting feature allows the point time duration of one Sequence to be imported by another Sequence. If the receiving sequence doesn't have enough points, more will be created (without values).

For example, the sequences for CH1 and CH2 are shown below. CH1 has a total of 6 points with long durations, whilst CH2 has only 2 points, looped 5 times. The points from CH2 are also significantly shorter in duration.



Below shows the resulting sequence when CH1 imports CH2. CH1 imports the duration time settings and number of points from CH2, but not the value data.




OCP Test Automation

Background The OCP test function creates an automatic test to test the over current protection of power supply products. See page 167 for operation details.

This test will test to see when the over current protection of a power supply is tripped and return the measurements for the voltage and current when the over current protection was tripped. The PEL-2000B series also has a user-defined OCP setting in the event that the power supply OCP fails.

The diagram below shows an example of the OCP Test Automation function.




Parallel Dynamic Loading

Background

The PEL-2000B series of DC electronic loads support parallel dynamic loading. This simply means that when the load modules of a mainframe are connected in parallel and set to dynamic mode, they can perform dynamic tests synchronously following the same clock. Under dynamic mode, load current or resistance is pulsed between two preset levels. When used in parallel, higher powered outputs can be tested. This ability gives the PEL-2000B series the flexibility to perform dynamic tests over a wide range of power outputs.

For connection details see the Parallel Load Connections section on page 52.

The diagram below shows how two load modules are able to sink a higher load when used in parallel under dynamic mode.



Note

The same type of load modules must be used operated in parallel.

Configurations Description

There are a number of different configurations for the PEL-2000B series including protection modes, operating configurations, and file system configurations. The Configuration Description section describes what the different configurations are used for and how they can be relevant to different operations.

Protection Modes


Background The PEL-2000B series include a number of protection modes: Over Current Protection, Over Voltage Protection, Over Power Protection, Under voltage protection and Constant Power Protection.

The protection modes are useful to protect both the load modules and the DUT(s). A buzzer can be set to notify when a protection setting has been tripped. When a protection feature is activated and has been tripped then the load unit will display an alarm. The Mainframe will also display an alarm. When an alarm has been tripped the load will stop sinking current/voltage. There are three Over load protection settings: ON, OFF and Clear.

05/04/22 16 : 50		Alarm	
OCP Level	5.075 A	CH1 CCDH 80V Conf	
OCP Setting	OFF		
OVP Level	81.6 V		
OVP Setting	ON		
OPP Level	29.75 W		
OPP Setting	OFF		
Protection	Other	Go-NoGo	Previous Menu


Over Current Protection

When a load unit is operating in CR, CV or CP mode, the unit may need over current protection to prevent excessive current being set. Over current protection stops the load from sinking more current than its recommended limit which can cause damage to the unit.



Over Voltage Protection

Over voltage protection is used to limit the amount of voltage sunk. If the OVP trips, the PEL-2000B series load will stop sinking voltage.




Over Power Protection

Over power protection is used to limit the amount of power sunk. When OPP is tripped power will cease to be sunk.


Reverse voltage Protection	Reverse voltage protection prevents reverse voltage damage to the PEL-2000B series up to the specified rating. When Reverse voltage protection has been tripped an alarm tone will sound until the reverse voltage is removed.
Under voltage Protection	Under voltage protection will turn off the load when the voltage drops below a set limit. UVP does not work when set to “CH CONT: External”.
Constant Power Protection	Constant power protection will prevent excessive power draw.

Operating Configurations

Background	There are number of operating configuration settings. Configuration settings are for the following: CC Vrange, Von Voltage, Von Latch, CH Cont, Independent, load D-Time, Response settings, Step resolution settings, Short settings.
CC Vrange	CC Vrange (page 178) is used to set the voltage range as High or Low for CC mode. CC voltage range is dependent on the load module specifications.
Von Voltage	Von Voltage is the voltage limit at which the load will start to sink current. There are two operation modes for Von Voltage: Von latched: ON and Von latched: OFF. Latched: ON will sink current when Von has been tripped, and will continue to sink current even if the voltage drops below the Von Voltage. Von Latched: OFF will sink current when Von has been tripped, but will stop sinking current when the voltage drops below the Von Voltage setting.



As can be seen in the diagram below, when Von-Latch is set to off, the load module will start to sink current when the Von-voltage limit has been tripped. It will stop sinking current when the output drops below the Von voltage limit.



CH CONT

Channel Control. When Channel control is activated (External) it can be used to monitor the voltage and current output of the load as well as turn loads on or off remotely from the Channel Control (CH CONT) connectors located on the rear panel.

For more information about channel control, see external voltage control on page 87.

Independent

The Independent setting will allow the load modules to be controlled independently from the mainframe.

- Load D-Time** Load Delay time is used to delay activating a load (up to 10 seconds) after the load key has been pressed. However the Load D-Time setting will only work for loads that are initiated manually or when the PEL-2000B series mainframe is configured to Auto load (page 201) at run time.
- Response** The Response setting sets the bandwidth of the load to 200Hz (normal) or 20kHz (fast).
- If the DUT voltage range is below 1V, set the normal bandwidth to 200Hz, and set the fast bandwidth to 20kHz. If the DUT voltage range is above 1V, set the normal or fast bandwidth to 20kHz.
- The Response setting is particularly important for limiting startup current.
- Step Resolution** The current, resistance, voltage and power setting can have the step resolution configured for each channel. The step resolution refers to the step resolution of the *coarse adjustment* of these settings. The *fine adjustment* cannot be configured, see page 188 for details.
- For example if the step resolution for CCH (CC high range) is .5 A, then the resolution can be incremented in .5A steps;

$$8.0 \leftarrow \rightarrow 8.5 \leftarrow \rightarrow 9.0 \leftarrow \rightarrow 9.5$$

The step resolution parameters apply to the following:

CCH Step – CC high range

CCL Step – CC low range

CRH Step – CR high range

CRL Step – CR low range

CVH Step – CV high range

CVL Step – CV low range

CPH Step - CP high range

CPL Step - CP low range

Step Resolution Range The step resolution range is dependent on the load module and the range:

Max resolution: Module dependent, see page 188

Min resolution: Module dependent, see page 188

Short Key When short mode is on, the load unit can simulate a short circuit.

Shorting can be individually set for each channel when programming sequences.

To initiate a short circuit manually, the short key is used. It can be used at any time during an operation. It will not affect the settings. After a short circuit has finished, the load unit will resume the previous operation.

The short function can be set ON or OFF. When setting to ON, the short key is enabled. When setting to OFF, the short key is disabled.

The short key can be set to toggle or hold. When pressed in toggle mode, shorts are toggled on and off. When pressed in hold mode, the key needs to be held to short the load.

The Short Safety can be used to set the short operation mode. When setting to ON, the short

function must be used in the case of Load ON. When setting to OFF, the short function can be used directly.




Note

A short circuit may trip a protection mode if too much current is sunk.

Channel Control


Background

External channel control is used with the Channel Control connectors. Each channel control connector can activate each load, monitor voltage and current and has an external voltage reference input. The voltage and current monitors output 0~100% of the rated current/voltage as a voltage of 0~10V.



External Voltage Reference

A voltage reference of 0-10V is used to represent 0-100% of the rating voltage/current of a load module. As seen below the external voltage reference and the rating voltage/current have a linear relationship. By varying the reference voltage between 0~10V the voltage/current setting will be changed accordingly.




To determine the Percent Rating (voltage or current load input), use the following formula;

$$Load\ Input = \frac{External\ Voltage}{10(V)} \times Rating\ VorA$$

Where "Rating V or A" is the rating voltage/current of the load module.

Current Monitor The load current input can be externally monitored using the IMON pin of a channel control connector. The IMON pin outputs a voltage of 0~10V to represent the input current as a percentage (0~100%) of rating current.




To determine the Current Monitor Output (IMON) , use the following formula;

$$IMON = \frac{Load\ input\ current}{Rating\ A} \times 10V$$

Where "Rating A" is the rating current of the load module.

Voltage Monitor The input voltage, like the load input current can be externally monitored with the channel control connectors. The VMON pin of the channel control connector outputs a voltage of 0~10V to represent the load input voltage as a percentage (0~100%) of the rating voltage.



To determine the Voltage Monitor Output (VMON) , use the following formula;

$$VMON = \frac{\text{Load input voltage}}{\text{Rating V}} \times 10V$$

Where "Rating V" is the rating voltage of the load module.

Turning on the Load A load is turned on when Load On input is set to On (active low). A load is turned off when the Load On input is set to Off (active high).

When a load is turned on from the channel control interface, the load can be turned off from the mainframe, local module and via remote control. However the opposite is not true; when a load is turned off using the channel control interface, the load cannot be turned on via the mainframe, local module or via remote control.

For connections and configurations, see pages 56 and 272 respectively.

Interface and System

Interface

Background The PEL-2000B series support RS232/RS485, GPIB, LAN and USB remote frame control. Only one type of connection is supported at any one time. For more information on remote control please see your local distributor about the PEL-2000B series programming manual.

For connection options and configurations see the options below.

RS232 or RS485 configuration	Page 222
Configure RS232 or RS485 interface	Page 279
LAN configuration	Page 286
GPIB configuration	Page 227
GPIB pin configuration	Page 270
USB configuration	Page 224

File System

Background The PEL-2000B series is able to save and recall a number of different data types for each channel:

Presets

Memory

Setup

SEQ (Sequence)

All data types can be saved and recalled to internal memory or saved to a USB flash drive.

Each channel has its own dedicated memory for each data type. Thus files are saved/recalled for each channel and each data type.

Preset Data Preset data can be saved into 10 memory slots for each channel. Preset data contains the mode, range, CV response speed and Go/NoGo settings.

Internal Format P0~P9

External Format 20X0X_XX.P

Preset Contents Preset data contains the following data;

- | | | |
|---------|---|---|
| CHAN | <ul style="list-style-type: none"> • Mode • Range | <ul style="list-style-type: none"> • Static/Dynamic • CV response speed |
| Go/NoGo | <ul style="list-style-type: none"> • SPEC Test • High • Center | <ul style="list-style-type: none"> • Entry Mode • Low |

Memory Data Each channel can save up to 120 different Memory data types (M001~M120) into internal memory. Memory data contains general channel settings and is used when programming sequences. Memory data can be stored both internally and externally through the USB A port on the front panel of mainframe. Preset data and Memory data store the same contents.

Internal Format M001~M120

External Format 20X0X_XX.M

Memory Contents Memory data contains the following data;

- | | | |
|---------|---|---|
| CHAN | <ul style="list-style-type: none"> • Mode • Range | <ul style="list-style-type: none"> • Static/Dynamic • CV response speed |
| Go/NoGo | <ul style="list-style-type: none"> • SPEC Test • High • Center | <ul style="list-style-type: none"> • Entry Mode • Low • Delay Time |

SEQ Data	<p>SEQ data contains Sequence data. SEQ data can only be saved to and from USB. SEQ refers to Sequence data, not Program sequences.</p> <hr/> <p>Internal Format N/A (Internal buffer)</p> <p>External Format 20X0X_XX.A</p> <hr/>												
SEQ Contents	<p>SEQ data contains the following data;</p> <hr/> <table border="0" style="width: 100%;"> <tr> <td style="vertical-align: top; padding-right: 20px;">Seq.Edit</td> <td> <ul style="list-style-type: none"> • No. (Points) • Slew rate ⌘ • Duration time </td> <td style="vertical-align: top; padding-left: 20px;"> <ul style="list-style-type: none"> • Value • Slew rate ↵ </td> </tr> <tr> <td style="vertical-align: top; padding-right: 20px;">Loop</td> <td> <ul style="list-style-type: none"> • Repeat • On End Load </td> <td style="vertical-align: top; padding-left: 20px;"> <ul style="list-style-type: none"> • Start of Loop • CC Vrange </td> </tr> </table> <hr/>	Seq.Edit	<ul style="list-style-type: none"> • No. (Points) • Slew rate ⌘ • Duration time 	<ul style="list-style-type: none"> • Value • Slew rate ↵ 	Loop	<ul style="list-style-type: none"> • Repeat • On End Load 	<ul style="list-style-type: none"> • Start of Loop • CC Vrange 						
Seq.Edit	<ul style="list-style-type: none"> • No. (Points) • Slew rate ⌘ • Duration time 	<ul style="list-style-type: none"> • Value • Slew rate ↵ 											
Loop	<ul style="list-style-type: none"> • Repeat • On End Load 	<ul style="list-style-type: none"> • Start of Loop • CC Vrange 											
Setup Data	<p>Setup data can be saved to 4 internal memory slots. Setup data contains Memory data, Program Sequence, Chain data, configuration settings and operation settings for every channel. Setup data can be saved to Internal memory or to USB.</p> <hr/> <p>Internal Format Setup Memory 1~4</p> <p>External Format 200X0_XX.S</p> <hr/>												
Setup Contents	<p>Setup data contains the following data;</p> <hr/> <table border="0" style="width: 100%;"> <tr> <td style="vertical-align: top; padding-right: 20px;">Program</td> <td> <ul style="list-style-type: none"> • PROG • Memory • On-Time • P/F-Time • Short Channel </td> <td style="vertical-align: top; padding-left: 20px;"> <ul style="list-style-type: none"> • SEQ (program sequence no.) • Run • Off-Time • Short-Time </td> </tr> <tr> <td style="vertical-align: top; padding-right: 20px;">Chain</td> <td> <ul style="list-style-type: none"> • Start </td> <td style="vertical-align: top; padding-left: 20px;"> <ul style="list-style-type: none"> • Program Sequence (P01~P12) </td> </tr> <tr> <td style="vertical-align: top; padding-right: 20px;">Run</td> <td> <ul style="list-style-type: none"> • Active Channel (CH01~08) </td> <td></td> </tr> <tr> <td style="vertical-align: top; padding-right: 20px;">CHAN</td> <td> <ul style="list-style-type: none"> • Mode </td> <td style="vertical-align: top; padding-left: 20px;"> <ul style="list-style-type: none"> • Static/Dynamic </td> </tr> </table>	Program	<ul style="list-style-type: none"> • PROG • Memory • On-Time • P/F-Time • Short Channel 	<ul style="list-style-type: none"> • SEQ (program sequence no.) • Run • Off-Time • Short-Time 	Chain	<ul style="list-style-type: none"> • Start 	<ul style="list-style-type: none"> • Program Sequence (P01~P12) 	Run	<ul style="list-style-type: none"> • Active Channel (CH01~08) 		CHAN	<ul style="list-style-type: none"> • Mode 	<ul style="list-style-type: none"> • Static/Dynamic
Program	<ul style="list-style-type: none"> • PROG • Memory • On-Time • P/F-Time • Short Channel 	<ul style="list-style-type: none"> • SEQ (program sequence no.) • Run • Off-Time • Short-Time 											
Chain	<ul style="list-style-type: none"> • Start 	<ul style="list-style-type: none"> • Program Sequence (P01~P12) 											
Run	<ul style="list-style-type: none"> • Active Channel (CH01~08) 												
CHAN	<ul style="list-style-type: none"> • Mode 	<ul style="list-style-type: none"> • Static/Dynamic 											

- | | | |
|--|--|--|
| | <ul style="list-style-type: none"> • Range • SPEC Test • High • Center | <ul style="list-style-type: none"> • CV response speed • Entry Mode • Low |
|--|--|--|

Save: Internal memory

When saving data to internal memory, either the current channel or all the channel data can be saved. Not all data types can save the current channel or all the channel data.


Data Type	Current Ch	All Ch
Preset	✓	✓
Memory	✓	✓
SEQ	✓ (single save)	—
Setup	—	✓

Save: External memory

Only SEQ, Memory and Preset data can be saved for a single channel to USB. All four data types (SEQ, Memory, Setup, Preset) can save all channels to USB.

Data Type	Current Ch	All Ch
Preset	✓	✓
Memory	✓	✓
SEQ	✓	✓
Setup	—	✓


Save/Recall USB In order to save data from a single channel to USB, data must first be saved to the internal memory. After data is saved to internal memory, all the files can be saved to USB.



To recall saved files, the reverse is also true. Files must be recalled from the USB flash drive to internal memory. Then from internal memory the data can be recalled to each channel*.

*Excluding SEQ data.

Save/Recall All The SEQ, Preset, Memory or Setup data can be saved from every channel into USB. SEQ, Preset and Memory data is saved into a directory (ALL0000-ALL0099) with a file for each channel, whilst Setup data is saved in a single file.



To recall saved files, the reverse is not true. Files must be recalled to each channel separately.

File Format

Current Channel Filename format

Memory data 2030R_00.M 1: PEL-2000B series Load module
 Preset data type:

SEQ data

1 2 3 4

2020 = PEL-2020B

2030 = PEL-2030B

2040 = PEL-2040B

2041 = PEL-2041B

2: Channel location or Voltage range of single channel model.

R = Right

L = Left

0 = Single channel or not used

3: Save file number:

0 ~99

Incremented after each consecutive save.

4: File extension

M = Memory data

P = Preset data

A= SEQ data

All Channel

Directory Format



ALL_0000

1 2

1: All Channel common directory name

2: Directory number:

0000 ~ 0099

All Channel	File Format	
Memory data	2230R_C1.M	1: PEL-2000B series Load module
Preset data		type:
SEQ data		2020 = PEL-2020B
Setup Data	20040_00.S	2030 = PEL-2030B
		2040 = PEL-2040B,
		2041 = PEL-2041B
		2: Channel, Voltage range of single channel model or Mainframe indication
		R = Right
		L = Left
		0 = Single channel
		3: Channel number:
		C1 = CH1
		C2 = CH2
		Etc.
		00 = All channels (Setup data)
		4: File extension
		M = Memory data
		P = Preset data
		A= SEQ data
		S= Setup data


TUTORIALS

Local loads	99
Single Channel Load	101
Parallel Load Modules	103
Programming.....	105
Sequences	107
Frame Link.....	108
Channel Control.....	110
General Configuration Options	112

Local loads

Local mode operation is useful to quickly test loads using the load module control panel rather than the mainframe control panel. Local load modules can be configured to operate independently to the mainframe. This can be useful when settings need to remain unchanged on the mainframe. Note however that the local modules cannot change the modes (CC, CV, CR, CP), only the values.

Group Unit mode is not supported for local module control.



Step	Description	Details
1. Setup	Ensure the channel load is set up as desired.	Pages 36, 44
2. Channel selection	Ensure the correct channel or Value (A/B) is selected by using the R/L or A/B key.	Page 117
3. Measurement Mode selection	If in CC or CR mode, Static or Dynamic mode can be selected.	CC Pages 118, 129 CR Pages 133, 135
4. Run the Load	Press the LOAD key to start/end loading the device under test.	Page 119


Optional

5. Short configuration	Configure the SHORT settings.	Page 181
6. Display	To change the display output, use the DISPLAY key.	Page 120
7. Shorting the load	To short the load, use the SHORT key.	Page 120


- | | | |
|-----------------------------------|---|----------|
| 8. Independent load | The local load modules can be set to independent load. | Page 185 |
| 9. Independent control | Slave knobs can be configured to be independent to the mainframe. | Page 206 |
| 10. Configure Slave Knob Settings | Display Measured or Set Values with the selector knob. | Page 209 |
-

Single Channel Load

Single channel loads are used to manually test a DUT quickly or to configure channel settings for Program Sequences using the mainframe panel.




Step	Description	Details
1. Setup	Choose the appropriate load module and make sure it is installed.	Page 36
2. Connection	Connect the terminals to the DUT.	Page 44
3. Channel selection	Select the load channel on the mainframe.	Page 123
4. Measurement mode selection	Select measurement mode (CC, CV, CR, CP).	CC Page 125 CV Page 138 CR Page 131 CP Page 142
5. Range selection	Set the range to high or low (CC, CR, CV and CP mode).	CC Page 125 CR Page 132 CP Page 145
6. Mode selection	Choose Static or Dynamic mode (CC & CR mode only).	CC Pages 126, 129 CR Pages 133, 135
7. Dynamic levels (CC,CR)	Set the dynamic levels, slew rate and timers. Applicable to CC & CR mode only.	CC Page 127 CR Page 133

8.	Static Values (CC, CR, CV, CP)	Set the A(B) Value, slew rate (CC, CR) and current limit (CV, CP)	CC Page 129 CR Page 136 CV Page 139 CP Page 143
9.	Go/NoGo	Set the Go/NoGo configurations, if applicable.	Page 191
10.	Protection Modes	Configure the protection modes.	Page 174
11.	Run	Activate the load by pressing the load key.	
Optional			
12.	Configuration	There are number of configurations that apply to all channels. For details see the Configuration Tutorial.	Page 112

Parallel Load Modules

The Group Unit setting allows for a quick and easy parallel setup for load modules of the same type and rating. However, the Group Unit settings only apply for CC and CR modes.




Step	Description	Details
1. Setup	Choose the appropriate load modules and make sure they are installed. All load modules must be of the same type and rating.	Page 36
2. Connection	Connect the terminals to the DUT.	Page 44
3. Group Unit mode configuration	Enable Group Unit Mode and configure.	Page 195
4. Measurement mode selection	Select measurement mode (CC, CR).	CC Page 125 CR Page 131
5. Range selection	Set the range to high or low (CC, CR mode).	CC Page 125 CR Page 132
6. Mode selection	Choose Static or Dynamic mode.	CC Pages 126, 129 CR Pages 133, 135
7. Dynamic levels	For Dynamic mode, set the dynamic levels, slew rate and timers.	CC Page 127 CR Page 133
8. Static Values	For Static mode, set the A(B) Value and slew rate.	CC Page 129 CR Page 136

9. Go/NoGo Set the Go/NoGo configurations, if applicable. Page 191

10. Protection Modes Configure the protection modes. Page 174

11. Run Activate the load by pressing the load key.




Optional

12. Configuration There are number of configurations that apply to all channels. For details see the Configuration Tutorial. Page 112

Programming

When creating a Program Sequence or Chain, all channels are used at the same time unless programmed otherwise. Program Sequences use the channel settings stored from Memory Data. Program sequences are primarily used to perform a battery of pass/fail tests on DUTs.




Step	Description	Details
1. Setup	Choose the appropriate load module(s).	Page 36
2. Connection	Connect the terminals to the DUT.	Page 44
3. Channel selection	Select the load channel(s) on the mainframe.	Page 123
4. Channel setup	See the “Single channel load” tutorial to configure a single channel. Do not activate the load.	Page 101
5. Save channel	Save the configured channel.	Page 229
6. Multiple channels	If multiple channels need to be configured, follow steps 1-5 for any remaining channels.	
7. Program menu	Enter the Program menu.	Page 147
8. Configure the sequence	Configure the program.	
9. Save sequences	Save the Program in the FUNC →Program menu.	
10. Program Chains	If required, Program chains can be created.	Page 150

- 11. Save Program Save the chain in the Chain menu.
- 12. Save Setup Save everything to the internal Setup memory. Page 237
- 13. Run Run the Program Sequence/Chain. Page 153

Sequences


Sequences are used to accurately simulate loads. As each Sequence is independent, Sequences are ideally suited to test multiple output power sources.



Step	Description	Details
1. Setup	Choose the appropriate load module(s).	Page 36
2. Connection	Connect the terminals to the DUT.	Page 44
3. Channel selection	Select a load channel with the mainframe.	Page 123
4. Channel setup	Create a sequence.	Page 158
5. Sequence loop	Create a sequence loop if necessary.	Page 160
6. Multiple channels	If multiple channels need to be configured, follow steps 1-5 for any remaining channels.	
7. Channel Duration menu	Edit the sequence channel duration information. Ensure that the channels containing Sequences are not set to OFF.	Page 162
8. Trigger Settings	Set Trigger Out and In channels, if appropriate.	
9. Run	Run the Sequence(s)	Page 165

Frame Link

Frame link connections are used connect up to four slave main frames to a master main frame. When using frame link connections it is possible to perform a number of operations in parallel under the control of the master unit.



Step	Description	Details
1. Setup	Connect the mainframes together.	Page 54
2. Configure	Configure the Frame CONT to ON for all mainframes.	Page 204




At first both the master and slaves are independent. FRM (Frame Master) can be seen on the top panel of the each mainframe. When a mainframe is connected as a slave unit, the FRM icon will change to FRS (Frame Slave). The front panel keys are disabled on slave units when in slave mode (FRS).

Slave mode FRM → FRS

Master/Independent FRM

3. Program	See the tutorial sections for programming or channel configuration.	Pages 101, 103
------------	---	----------------

- 4. Run Run the loads. To run the loads, press the LOAD key on the master mainframe. To stop, press again. When the LOAD key is pressed all loads will be active.



Options

- 5. Load Preset memory Load preset memory on the mainframe and all frame-linked slaves. Page 264

- 6. Load Setup Memory Load setup memory on the mainframe and all frame-linked slaves. Page 263

- 7. Set slave to independent Press shift + CHAN on the slave unit to enable local control on a slave unit.



FRS → **FRM**




Note

When a load is run or memory is recalled from the master mainframe, the slave unit will return to mainframe control.

Ensure the same firmware is installed on both master and slave mainframes.

Channel Control

The Channel Control connectors on the rear panel can be used to control and monitor the status of up to 8 channels. For more information on channel control, see page 87.



Step	Description	Details
1. Setup	Ensure the load and PEL-2000B series mainframe is turned off.	
2.	Choose the appropriate load module(s).	Page 36
3. Connection	Connect the terminals to the DUT.	Page 44
4.	Connect the channel control connectors on the rear panel.	Page 56 & 272
5.	Turn on the PEL-2000B series mainframe and DUT (load).	
6. Configure	Select the Mode* and Range* via the front panel.	CC Pages 125, 125 CV Page 138
7.	Activate channel control for each channel that will be used for external control, i.e., set CH CONT to External.	Page 183

- | | | |
|------------|--|--------------|
| 8. Run | Run the load. Turn the load on by either outputting an active low signal to the appropriate channel control connector or control connector, or press the LOAD key on the load module or mainframe**. | Page 56 & 87 |
| 9. Monitor | Use IMON and VMON to monitor the current and voltage of load outputs. | Page 87 |
| 10. End | To turn the load off, output an active high signal to the channel control connector, or press the LOAD key on the load module or mainframe**. | |

* Mode and Range cannot be configured via the Channel Control (CH CONT) interface. Mode and Range can only be configured via the front panel.

** The LOAD key cannot always be used to turn on/off the load. See page 87 for details.

General Configuration Options

There are number of different options for each channel. The different options are described below.

Options	Description	Details
1. CC Vrange	Configure the CC Voltage range from high or low.	Page 178
2. Von Voltage	Configure the Von Voltage settings.	Page 179
3. Short Settings	Configure the short key settings.	Page 181
4. CH CONT	Turn channel control on/off	Page 183
5. Independent load	Turn the load module control to dependent (via mainframe) or independent control.	Page 185
6. Delay Time	Configure the load delay time for each channel. (0-10 seconds).	Page 186
7. Clear All Protection	Clear all the Protection Alarms.	Page 177
8. Display	Adjust display settings.	Page 202
9. Control type	Configure the Knob control.	Page 206
10. Slave Knob Setting	Display Measured or Set values with the selector knob.	Page 209
11. Alarm	Configure alarm settings.	Page 207
12. Step resolution	Configure the step resolution. Applicable to CC high and low range, CR high and low range, CV high and low range and CP high and low rang.	Page 188
13. Response	Configure the Response setting.	Page 191

14. Sound

Turn the sound on/off for the mainframe IU.

Page 202

OPERATION

The PEL-2000B series operation is described in the chapters below. The sections are broken down into small operations. For thorough examples on the operation of the load, please see the tutorial section on page 99.

Local Mode Operation	117
Selecting a Channel	117
Selecting Static/Dynamic	118
Turning on the Load	119
Shorting.....	120
Display Output View.....	120
Editing CC/CR/CV/CP A/B Value.....	121
Mainframe Basic Operation	123
Help Menu	123
Channel Selection	124
Select CC Mode.....	125
Select CC Range	125
Select CC Dynamic Mode	126
Editing CC Dynamic Parameters	127
Select CC Static Mode	129
Editing CC Static Parameters	129
Set to CR Mode	131
Select CR Range	132
Select CR Dynamic Mode	133
Editing CR Dynamic Parameters	133
Select CR Static Mode	135
Editing CR Static Parameters	136
Select CV Mode.....	138
Editing CV Parameters.....	139
Select CV Range	140
Select CV Response Speed	141
Select CP Mode.....	142
Editing CP Parameters.....	143

Select CP Range	145
Creating a Program Sequence	146
Program Chains	150
Running a Program	153
Edit Sequence	158
Create Sequence Loop	160
Channel Duration Time Settings	162
Run Sequence	165
OCP Test Automation	167
Channel Configuration	173
Accessing the Configuration Menu	173
Setting (OCP/OVP/OPP/UVP)	174
Protection Clear	177
Setting the CC Voltage Range	178
Adjusting the Von Voltage and Latch	179
Configuring the Short settings	181
Configuring Channel Control	183
Configuring the Independent Setting	185
Configuring the Load Delay Time	186
Configuring Step Resolution	188
Configuring Response Time	191
Go/NoGo	192
Group Unit	195
Mainframe Configuration	199
Accessing System Information	199
Accessing the Load Menu	201
Adjusting the Speaker	202
Adjusting the Display Settings	203
Adjusting the Frame Control	204
Adjusting the Knob Control Type	206
Configuring Alarm Sound	207
Configuring Go/NoGo Alarm Sound	208
Adjusting Slave Knob Settings	209
View Language Settings	211
Adjusting the High Resolution	212
Adjusting the System Mode	213
Adjusting the Von Latch Clear	214
Adjusting the Measure Period	216
Adjusting the Jog Shuttle Control	218
Adjusting the RVP Load Off	219

Setting the Date and Time.....	220
Interface Configuration (settings)	222
Configuring RS232 or RS485 Connection	222
Configuring USB Connection	224
Configuring the GPIB Address	227
RS232 or RS485, LAN and USB CDC	
Function Check	229
GPIB Function Check	232
Saving/Recalling Channels	234
Saving/Recalling Preset memory	236
Saving/Recalling Setup Memory	238
Setting the Default USB Path/File.....	240
Saving Setups to USB Memory	245
Saving/Recalling Memory Data to USB	247
Saving/Recalling Presets to USB.....	252
Saving/Recalling Sequences to USB	257
Quick Preset Recall/Save.....	262
Recall Setup Memory (Frame link).	263
Recall Preset Memory (Frame link)	264
Recall Factory/User's Defaults	265

Local Mode Operation

Each channel can be edited by its local load module. Depending on the configuration, local changes can be reflected on the mainframe. For this section all operations refer to knobs and buttons on the local load module panels, unless stated otherwise.

Selecting a Channel

Background	Each channel can be individually selected by using its load module panel. Changing channels on a load module only applies to dual channel load modules.
Single Channel Panel operation	Press any key on a load module to select its channel.
Dual Channel Panel Operation	For dual channel load modules, press any key on a load module that has the desired channel. Press the R/L key to cycle between the channels on the load module. L or R will be displayed on the bottom left hand to indicate which channel (left or right side) is active on the load module.




LR



On single channel modules, pressing the A/B key repeatedly will change the level from A or B when in Static mode.

Channels cannot be selected in Group Unit Mode.



Selecting Static/Dynamic


Background Each load channel can be individually switched from Static to Dynamic using the local load module.

1. Select a channel on the load module. Page 117

Panel operation 2. Press the STATIC/DYNA. key to switch from dynamic to static mode and vice versa.



All changes will be shown on the display and depending on the configuration, reflected on the mainframe.



Turning on the Load

Background Loads can be individually selected to be turned on using local operation.

1. Select a channel on the load module. Page 117

Panel operation 2. Press the LOAD key to turn on the load.



Note


When a channel load is activated, the load on symbol will be displayed under the channel number.

Range

L-ON Left channel

R-ON Right channel

ON Single channel



Turning the load off 3. Press the LOAD key.




Shorting

Background The Short Key is used to simulate a short circuit.

1. Configure the Short settings. Page 181
2. Select a channel on the load module. Page 117

Panel operation 3. Press the SHORT key to enter the shorting modes.



Shorting 4. a. Press the SHORT key (toggle mode).



Or

b. Hold the SHORT key (hold mode).



Note

The load cannot be shorted from the local load module in Group Unit mode.

Display Output View

Background The DISPLAY key can be used to switch the display output to different views.

Panel operation 1. Press the DISPLAY key repeatedly to switch between the different views.



V

Voltage

- A** Current
- W** Power
- S** Load on time.



Note

The Display mode cannot be changed in Group Unit mode.

Editing CC/CR/CV/CP A/B Value

Background The Slave Knob is used to edit the A Value or B Value (single channel load module) when in static mode. The Slave Knob can also operate in fine or coarse editing mode.


Panel Operation 1. Ensure the mode is in static mode. Page 118

2. Choose a channel (or choose A or B Value) by pressing the R/L or A/B key.



3. Press the Slave Knob to toggle between fine and coarse editing mode.


SEt_C = coarse mode.
SEt_F = fine mode.




Fine mode example:



Coarse mode example:



4. Turn the Slave Knob to edit the A/B Value for the selected mode.





When the Slave Knob is set to “Measure”, the slave knob must be pressed first to display the values on the load module display.

Editing the A/B Value is not possible with this method in Group Unit mode.

Mainframe Basic Operation

For the Mainframe Basic Operation section, all operations refer to the knobs and keys on the main configuration panel, unless otherwise stated.

Help Menu


Background When any function key has been pressed or when a menu has been opened, the HELP key can be used to display a detailed description.

1. Press a function or system key on the front panel or open a menu.

Help Selection 2. Press the HELP key to display the built-in help.




3. Use the scroll wheel to scroll down if necessary.



05/04/22				
16 : 50				
File System				
The system is able to save and recall a number of different data types for each channel: Memory , Preset , Sequence And, a data type for all channels is Setup .				
All data types can be saved and recalled to internal memory or saved to a external				
Help On Help				Exit

A detailed description of the function or menu item is shown.

4. Press F5 to exit.



Channel Selection

Background There are up to 2 channels per load module, depending on the model. The main display can be used to control each channel individually.




Note

When Group Unit Mode is enabled, channel selection is disabled. See page 117 for details.


Mainframe Channel selection 5. Press the CHAN button.




6. Select a channel by turning the Variable knob.



The channel selection appears highlighted in orange on the top right of the screen.





7. Press the Selector knob or Enter to confirm.



Select CC Mode

Background The PEL-2000B series loads operate in four different modes: Constant Current (CC), Constant Resistance (CR), Constant Voltage (CV), and Constant Power (CP).

When a channel is active, the F1 key can be used to switch between each operating mode.



- Panel Operation**
1. Select a channel using the CHAN button and selector knob.
 2. Press F1 repeatedly until CC mode is displayed in the display panel.



Mode CC	Range High	Dynamic		Configure
------------	---------------	---------	--	-----------



Note

Changing the operating mode will only affect the current (active) channel. Other channels will not be affected by any changes.

Select CC Range


Background Constant current mode can run in high and low range. Maximum range is dependent on the load module. Some models are only high range.

Ensure the menu is in CC Mode. See page 125.

Mode CC	Range High	Dynamic		Configure
------------	---------------	---------	--	-----------

- Panel Operation 1. Press the F2 (Range) key repeatedly until High or Low range is selected.

F2



The range will be reflected in both the bottom menu system and the Current Operation Channel Status panel.

CC Dynamic Low CCDL

CC Dynamic High CCDH

CC Static Low CCL

CC Static High CCH



Note

Changing the range will only affect the current (active) channel. Other channels will not be affected by any changes.

Not all load modules support dual ranges. If only one range is supported, it is usually high range.

Select CC Dynamic Mode


Background Constant current mode can be set to dynamic or static mode. Dynamic mode is used to automatically set varying load rates.

Ensure the menu is in CC Mode. See page 125.



- Panel Operation 1. Press the F3 key until Dynamic Range mode is selected.

F3





Note

Changing from static to dynamic mode will only affect the current (active) channel.

Editing CC Dynamic Parameters

Background

Dynamic Constant Current Mode has two operating current levels, slew rates and timers.



Slew rates determine the speed at which the load will change from one level to the next.

The timers determine how long the load module/channel will stay at level 1 or level 2.

Ensure the menu is in CC Dynamic Mode. See page 126.

Mode CC	Range High	Dynamic		Configure
------------	---------------	---------	--	-----------

Parameters

Level1	0 ~ Setting Max A
Level2	0 ~ Setting Max A
SlewRate 	Load module dependent
SlewRate 	
Timer1	0.025 ~ 30000.0 ms
Timer2	0.025 ~ 30000.0 ms




Note

When used in Group Unit mode, the Level1 & Level2 range is the combined rating of all the units used in Group Unit mode.


Panel Operation

1. Use the Selector knob to highlight Level1.



05/04/22 16 : 50			
Level1	0.80	A	CH1P
Level2	0.50	A	CCDH
SlewRate ↑	0.80	A/uS	
SlewRate ↓	0.80	A/uS	
Timer1	0.025	mS	
Timer2	0.025	mS	80V main
Mode CC	Range High	Dynamic	Configure

2. Press the Selector knob to edit the selected level, then turn to increase or decrease the value*.




OR

Use the number pad to enter a number.



Level1 **0.80** **A**

3. Press the Selector knob or Enter to confirm selection.
4. Repeat steps 1-3 for the remaining parameters.



Note

Level1 & Level2 can be set for both High and Low Range.

*Press Shift to toggle between coarse and fine adjustment when editing the Level1 and Level2 parameters. See page 188 for details.

Select CC Static Mode

Background Constant current mode can be set to dynamic or static mode. Static mode is for manually varying the load for single channel load modules or to set a static load on dual channel modules.

Ensure the menu is in CC Mode. See page 124.

Mode CC	Range High	Dynamic		Configure
------------	---------------	---------	--	-----------

Panel Operation 1. Press the F3 key until Static mode is selected.

F3



Note

Changing from static to dynamic mode will only affect the current (active) channel.

Editing CC Static Parameters

CC Values When using a single channel load module, Static Constant Current Mode has two operating current values, A&B. If a dual channel load is used, only one current value is available per channel: A Value.

If Group Unit Mode is enabled, an additional parameter, Switch Value, is available to switch from A Value to B Value.

Ensure the menu is in CC Static Mode. See page 129.

Mode CC	Range High	Static	Seq. Edit	Configure
------------	---------------	--------	--------------	-----------


Parameters	A Value	0 ~ Setting Max A
	B Value	0 ~ Setting Max A
	SlewRate	↕ Load module dependent
	SlewRate	↘
	Switch Value	A/B (Group Unit Mode only)



Note

When Group Unit Mode is enabled, the A Value & B Value range is the combined rating of all the units used in Group Unit Mode, see page 71.

- Panel Operation
1. Use the Selector knob to highlight A Value.




Single Channel Configuration

05/04/22 16:50		LOAD	USB	CH1
A Value	0.80	A		CH1P
B Value	0.80	A		CH1P
SlewRate	↕	0.80	A/uS	
SlewRate	↘	0.80	A/uS	
Mode	Range	Static	Seq. Edit	Configure
CC	High			

Group Unit Mode Configuration

05/04/22 16:50		LOAD	USB	CH1P
A Value	0.80	A		CH1P
B Value	0.80	A		CH1P
SlewRate	↕	0.80	A/uS	
SlewRate	↘	0.80	A/uS	
Switch Value	A			
Mode	Range	Static	Seq. Edit	Configure
CC	High			

2. Press the Selector knob to edit the selected value, then turn to increase or decrease the value*.




OR

Use the number pad to enter a number.



A Value **0.80** **A**

3. Press the selector knob or Enter to confirm selection.



- Repeat steps 1-3 for the remaining parameters.



Note

The last Value (A Value or B Value) that is set becomes the active setting. To swap between A Value and B Value, use the A/B keys on the local load module. This is not applicable to Group Unit mode.

For Group Unit mode, use the Switch Value parameter to switch between A and B Value.

A/B Value and rising/falling SlewRate can be set for both High and Low Range.


*Press Shift to toggle between coarse and fine adjustment when editing the A Value and B Value parameters. See page 188 for details.

Set to CR Mode

Background

The PEL-2000B series load operates in four different modes, Constant Current (CC), Constant Voltage (CV), Constant Resistance (CR) and Constant Power (CP). Constant Resistance mode will maintain a constant resistive load, using variable current and voltage levels.

When a channel is active, the F1 key can be used to switch between each operating mode.



Panel Operation

- Press the CHAN button and use the selector knob to select a channel.
- Press F1 until CR mode is displayed in the display panel.



Mode CC	Range High	Dynamic		Configure
------------	---------------	---------	--	-----------



Note

Changing the operating mode will only affect the current (active) channel. Other channels will not be affected by any changes.

Select CR Range

Background

Constant Resistance mode can run in high and low range. Range is dependent on the load module.


Ensure the menu is in CR Mode. See page 131.

Mode CC	Range High	Dynamic		Configure
------------	---------------	---------	--	-----------

Panel Operation

1. Press the F2 (Range) key repeatedly until High or Low range is selected.

F2



The range will be reflected in both the bottom menu system and the Current Operation Channel Status panel.

CR Static Low	CRL
CR Static High	CRH
CR Dynamic Low	CRDL
CR Dynamic High	CRDH



Note

Changing the range will only affect the current (active) channel. Other channels will not be affected by any changes.

All resistance values and slew rates are dependent on Range, i.e., A Value in low range can be different from A Value in high range.

Select CR Dynamic Mode


Background Constant Resistance mode can be set to dynamic or static mode. Dynamic mode is used to automatically set varying load rates.

Ensure the menu is in CR Mode. See page 131.



Panel Operation 1. Press F3 until Dynamic Range mode is selected.

F3



Note

Changing from static to dynamic mode will only affect the current (active) channel.

Editing CR Dynamic Parameters

CR levels Dynamic Constant Resistance Mode has two operating resistance levels, slew rates and timers.

Slew rates determine the speed at which the load will change from one level to the next.

The timers determine how long the load module/channel will stay at level 1 or level 2. See the CR operating description for details about slew rates and timers, page 64

Ensure the menu is in CR Dynamic Mode. See page 133.




Parameters	Level1	Minimum ~ Rating Ω
	Level2	Minimum ~ Rating Ω
	SlewRate \uparrow	Load module dependent
	SlewRate \downarrow	
	Timer1	0.025 ~ 30000.0ms
	Timer2	0.025 ~ 30000.0ms



Note


When used in Group Unit Mode, the Level1 & Level2 range is the combined rating of all the units used in Group Unit Mode.

- Panel Operation 1. Use the Selector knob to highlight Level1.



05/04/22		16 : 50			
Level1	100.000 Ω			CH1	
Level2	100.000 Ω			CRDL	
SlewRate \uparrow	0.40 A/uS				
SlewRate \downarrow	0.40 A/uS				
Timer1	0.025 mS				
Timer2	0.025 mS			80V	main
Mode	Range	Dynamic		Configure	
CR	Low				

2. Press the Selector knob to edit the selected level, then turn to increase or decrease the value*.




OR

Use the number pad to enter a number.



Level1 100.000 Ω

3. Press the Selector knob or Enter to confirm selection.



4. Repeat steps 1-3 for the remaining parameters.



Note

Level1 & Level2 can be set for both High and Low Range.

*Press Shift to toggle between coarse and fine adjustment when editing the Level1 and Level2 parameters. See page 188 for details.

Select CR Static Mode

Background

Constant Resistance mode can be set to dynamic or static mode. Static mode is for manually varying the load for single channel load modules or to set a static load on dual channel modules.


Ensure the menu is in CR Mode. See page 131.

Mode	Range	Dynamic		Configure
CC	High			

Panel Operation

1. Press the F3 key until Static mode is selected.

F3



Note

Changing from static to dynamic mode will only affect the current (active) channel.



Editing CR Static Parameters

Background Single channel load modules have two resistance levels, A Value & B Value. Dual channel load modules have only one resistance level per channel, A Value.

When Group Unit Mode is enabled, an additional parameter, Switch Value, is available to switch from A Value to B Value.

Ensure the menu is in CR Static Mode. See page 135.

Mode	Range	Static	Seq. Edit	Configure
CR	Low			


Parameters	A Value	Setting Min ~ Rating Ω
	B Value	Setting Min ~ Rating Ω
	SlewRate 	Load module dependent
	SlewRate 	
	Switch Value	A/B (Group Unit Mode only)



Note

When Group Unit Mode is enabled, the A Value & B Value range is the combined rating of all the units used in Group Unit Mode.


- Panel Operation**
1. Use the Selector knob to highlight A Value.




Single Channel Configuration



Group Unit Mode Configuration



2. Press the Selector knob to edit A Value /B Value, then turn to increase or decrease the value*.




OR

Use the number pad to enter a number.



A Value 100.000 Ω

3. Press the selector knob or Enter to confirm selection.



4. Repeat steps 1-3 for B Value (if applicable), rising and falling SlewRate.



Note

The last Value (A Value or B Value) that is set becomes the active setting. To swap between A Value and B Value, use the A/B keys on the local load module (not applicable to Group Unit mode).

For Group Unit mode, use the Switch Value parameter to switch between A and B Value.

A/B Value and rising/falling SlewRate can be set for both High and Low Range.



*Press Shift to toggle between coarse and fine adjustment when editing the A Value and B Value parameters. See page 188 for details.

Select CV Mode


Background The PEL-2000B series electronic load operates in four different modes, Constant Current (CC), Constant Resistance (CR), Constant Voltage (CV), and Constant Power (CP).

CV Mode cannot be used with the Group Unit mode.

When a channel is active, the F1 key can be used to switch between each operating mode.



- Panel Operation**
1. Press the CHAN button and use the selector knob to select a channel.



2. Press F1 until CV mode is displayed in the display panel.



Mode	Range	Response		Configure
CV	High	Slow1		



Note

Changing the operating mode will only affect the current (active) channel. Other channels will not be affected by any changes.

Editing CV Parameters

Background Constant Voltage mode can be set to a maximum limit (Curr Limit). Using the current limit enables limiting the current draw.


When using CV mode on single channel load modules, two voltage levels can be set, A Value and B Value. On a dual channel load module, only one voltage level can be set per channel: A Value.

Ensure the menu is in CV Mode. See page 138.

Mode CV	Range High	Response Slow1		Configure
------------	---------------	-------------------	--	-----------


Parameters	A Value	0 ~ Setting Max V
	B Value	0 ~ Setting Max V
	Curr Limit	Load module dependent

Panel Operation 1. Use the Selector knob to highlight A Value.



05/04/22				
16 : 50				
A Value	80.00 V			CH1
B Value	80.00 V			CVH
Curr Limit	70.00 A			
				Slow
				80V main
Mode CV	Range High	Response Slow1	I _{Mea} High	Configure

2. Press the Selector knob to edit the selected value, then turn to increase or decrease the value*.




OR

Use the number pad to enter a number.



A Value **10.00 V**

3. Press the selector knob or Enter to confirm selection.
4. Repeat steps 1-3 for the remaining parameters.



Note

The last Value (A Value or B Value) that is set becomes the active setting. To swap between A Value and B Value, use the A/B keys on the local load module.

When setting the current limit, please ensure that the current limit is within the test device's limits.

A/B Value can be set for both High and Low Range.

*Press Shift to toggle between coarse and fine adjustment when editing the A Value and B Value parameters. See page 188 for details.

Select CV Range

Background

Constant Voltage mode can run in high and low range. Range is dependent on the load module.


Ensure the menu is in CV Mode. See page 144.

Mode	Range			Configure
CP	Low			

Panel Operation

1. Press the F2 (Range) key repeatedly until High or Low range is selected.





The range will be reflected in both the bottom menu system and the Current Operation Channel Status panel.



CV High Range CVH

CV Low Range CVL



Note

Changing the range will only affect the current (active) channel. Other channels will not be affected by any changes.


Select CV Response Speed

Background

Constant voltage mode has fast and slow response speeds. Quick current changes can induce line voltage, making it more difficult for the PEL-2000B series load to maintain a constant current. In these types of conditions, slow response speed is recommended.


Maximum current range is dependent on the load module type.

Ensure the menu is in CV Mode. See page 138.



Panel Operation

1. Press F3 (Response) to switch between Fast and Slow response speeds.



Response speed settings will be reflected in the Current Operation Channel Status panel.

CV Slow Response Slow

CV Fast Response Fast



Note

Changing the response speed will only affect the current (active) channel. Other channels will not be affected by any changes.


Select CP Mode

Background

The PEL-2000B series electronic load operates in four different modes, Constant Current (CC), Constant Resistance (CR), Constant Voltage (CV), and Constant Power (CP).

CP mode cannot be used with the dedicated Group Unit mode.

When a channel is active, the F1 key can be used to switch between each operating mode.



Panel Operation

1. Press the CHAN button and use the selector knob to select a channel.
2. Press F1 until CP mode is displayed in the display panel.



Mode	Range			Configure
CP	Low			



Note

Changing the operating mode will only affect the current (active) channel. Other channels will not be affected by any changes.

Editing CP Parameters

Background

Constant Power mode can be set to have a maximum limit (Curr Limit). Using the current limit enables limiting the current draw.

When using CP mode on a single channel load module, two power levels can be configured, A Value and B Value. On a dual channel load module, only one power level can be configured per channel: A Value.

Ensure the menu is in CP Mode. See page 138.

Mode	Range			Configure
CP	Low			

Parameters


A Value 0 ~ Setting Max W

B Value 0 ~ Setting Max W

Curr Limit Load module dependent


Panel Operation

1. Use the Selector knob to highlight A Value.





2. Press the Selector knob to edit the selected value, then turn to increase or decrease the value *.




OR

Use the number pad to enter a number.



3. Press the selector knob or Enter to confirm selection.



4. Repeat steps 1-3 for the remaining parameters.



Note

The last Value (A Value or B Value) that is set becomes the active setting. To swap between A Value and B Value, use the A/B keys on the local load module.

A/B Value can be set for both High and Low Range.

When setting the current limit, please ensure that the current limit is within the test device's limits.

*Press Shift to toggle between coarse and fine adjustment when editing the A Value and B Value parameters. See page 188 for details.


Select CP Range

Background Constant Power mode can run in high and low range. The maximum range is dependent on the load module. Some models are only high range.

Ensure the menu is in CP Mode. See page 138.



- Panel Operation** 1. Press the F2 (Range) key repeatedly until High or Low range is selected.



The range will be reflected in both the bottom menu system and the Current Operation Channel Status panel.

CP High Range CPH

CV Low Range CPL



Changing the range will only affect the current (active) channel. Other channels will not be affected by any changes.

Not all load modules support dual ranges. If only one range is supported, it is usually high range.

Creating a Program Sequence


Background

The PEL-2000B series has a total of 12 different programs and 10 sequences to each program. That totals to 120 different configurations.

Each Sequence in each program uses the settings saved from Memory Data (Memory MXXX). Memory Data contains settings such as the mode and range for each channel. Different Sequences can use the same Memory Data repeatedly. Each Sequence loads all channels at the same time, unless programmed otherwise.


Sequence1	
CH1 M001	Run
CH2 M001	On-Time
CH3 M001	Off-Time
CH4 M001	Short-Time
CH5 M001	P/F-Time
CH6 M001	Short CH1
CH7 M001	~
CH8 M001	Short CH8

Sequences are run sequentially to create a Program. There are 10 Sequences in each Program.



If less than 10 Sequences are desired for a Program, any additional Sequences can be skipped (not run).

Sequence 2 & 3 are skipped.



Parameters	Memory	M001~M120
	Run	Skip-Auto-Manual
	On-Time	0.1 ~ 60.0 seconds
	Off-Time	Off - 0.1 ~ 60.0 seconds
	P/F Time	Off - 0.1 ~ (On-Time+Off-Time)-0.1
	Short-Time	Off - 0.1 ~ On-Time
	Short Ch	Off - 1~ 8 (CH1~CH8)




Note


Before a program can be created, the settings for each sequence for every channel that is to be used in the program must first be pre-configured and saved into Channel Memory (MXXX).

Sequence Settings


1. Press the FUNC key then F1 (Program) to access the Program menu.



2. Use the Selector Knob to highlight PROG:.



- Press the selector knob to edit PROG:, then turn to select the program number.




OR

Use the number pad to enter a program number.

Program: 01 ~12

- Press Enter or push the selector knob to confirm.



Repeat steps 2-4 to choose the sequence number (SEQ:).

Sequence: 01 ~ 10

- As sequences are executed sequentially, start at SEQ: 01.

05/04/22		16 : 50		USB
		LOAD		
Timing Edit for Program				
PROG:	01	SEQ:	01	
Memory:	M001	Off-Time:	Off	
Run:	Skip	P/F-Time:	Off	
On-Time	0.1	Short-Time:	Off	
Short Ch:	1	2	3	4 5 6 7 8
Chain	Active Channel	Save	Recall Default	

- Repeat steps 2-4 to configure the following for the current Program Sequence:

Memory: M001 ~M120

Choose which Memory data will be used for the sequence. M001 ~ M120

Run: Skip – Auto - Manual

Choose whether to run the sequence in the program automatically, skip the sequence or manually start the sequence.

On-Time: 0.1 ~ 60.0 seconds

Determines how long the sequence will run for (seconds).

Off-Time: Off – 0.1 ~ 60.0 seconds

Sets how long the sequence will stay off for (in seconds) between each sequence. Assuming Short time is not set to OFF, Off-Time will always run after On-Time.

Short Time: Off – 0.1 ~ On-Time (seconds)

Determines how long a short circuit will last (seconds). However the shorting time cannot be longer than the On-time. Short Time will start at the same time as On-time.

P/F Time: Off – 0.1 ~ (On-Time+Off-Time)-0.1 (seconds)

The Pass(P)/Fail(F) Delay Time can be set to 0.1 seconds less than the total test time. The total test time is defined as:

$$\text{On-Time} + \text{Off-Time (seconds)}$$

If Go/NoGo is turned on but the pass fail time is off, then Go/NoGo test will continue, but there will not be a specified pass/fail time window.

Short Channel: Off – 1~ 8 (CH1~CH8)

Each channel can be individually set to simulate a short circuit (CH1~8) or can have shorting disabled (Off). When Short Channel is set to Off, the channel will ignore the execution of Short-Time.

7. Repeat the above steps for all ten sequences for the same (current) program.

Save Sequence

8. Press F3 (Save) to save all the sequence data for all of the program.

F3



Note

Note the program data is not yet saved into Setup Memory. If you wish to save the Program to Setup Memory see page 238.

Recall Default

9. To recall the Default Program settings, press F4.

F4




Note

If the Default is recalled, all data will be lost. This does not include the internal Setup Memory. To see the default settings, see page 299.

Timing Diagram for Single Step

Below is a timing diagram of a single step in a program.




Program Chains

Background



On the PEL-2000B, there are up to 12 different programs containing 10 sequences.

If 10 sequences in a Program Sequence prove to be inadequate for testing, the PEL-2000B series can chain different programs together, effectively making a larger Program Sequence.



Unlike Program Sequences, Program Chains do not need to be run in numerical order. Up to 12 Program Sequences can be chained together




- Panel operation
1. Create 1 or more Program Sequences. Page 142
 2. If Program Sequences were created in a different session, ensure the programs have been loaded from Setup Memory. Page 238
 3. Press the FUNC key, then Program (F1), followed by Chain (F1).



4. Press F1 (Edit Start) and use the selector knob to edit Start and confirm which Program Sequence (PXX) will start the program chain. Any Program (P01~P12) can be used to start a Program Chain.
5. Use the Selector knob to scroll down to P01 (Program 1).



6. Use the Selector knob to choose the program that will execute after P01 (P02~P12).



OR

Select (Off) to end the Program Chain after (P01).

OR

Select (P01) to execute after P01, this will create a continuously looping Program Chain.

P01 → Off – P01~P12

7. Repeat the above procedure to P02~P12 to complete the program chain.

The Program Chain ends at the first Program (PXX) that is followed by Off. It is possible to create continuously looping program chains.

Save Program Chain

8. Press F3 (Save) to save the program chain.

F3



Note

The Program Chain data is not yet saved into Setup Memory. If you wish to save the Program Chain to Setup Memory see page 236.

Recall Default

9. To recall the Default program chain, press F4.

F4



Note

If the Default is recalled, Start will revert to P01 and all program sequences will be set to Off.

Previous Menu

10. Press F5 (Previous Menu) to return the Sequence menu.


F5

Running a Program


Background Once a Program Chain/Program Sequence has been created, it can be executed. As Program Sequences apply to all the channels, any channels that don't need to be active (load off) can be programmed in the Active Channel menu. At Default, all channels are set to (load) Off.

EXT will be shown next to any channels set to external channel control.


- Panel operation**
1. Create 1 or more Program Sequences. Page 142
 2. Create a Program Chain. Page 150
 3. Press the FUNC key, Program (F1) and Active Channel (F2).





Channel 1 (CH01) will be highlighted. Note CH1 has CH CONT set to External



4. Edit the channel using the Selector knob.



CH 01~08: ON (activate channel) – OFF (not activated)

5. Press Enter or push the selector knob to confirm the selection.  or 
6. If needed, repeat steps 4-5 for the remainder of the channels.




Note

If all channels are Active OFF, a program cannot be run as there will be no channels active.


Save Program

7. To save press F3.



Recall Default

8. To recall default settings press F4




Note

If the Default is recalled, all channels will revert to Active OFF.


Previous Menu

9. Press F5 (Previous Menu) to return to the Sequence menu.




Turn Program On/Off

10. Press F1 (Prog) to turn On or Off the current Program.



Pressing F1 will cycle from Program On to Off.




11. PROG will appear on the mainframe status panel when the program is turned on.



Run Program

12. Press the load key on the mainframe to start the Program.



13. The Run Program screen appears, and the PROG icon turns orange.




As each sequence or program is completed the screen will update to display the active sequence/program. Notice that if a channel has been set up with Go/NoGo limits, a pass (GO) or fail (NG) will be displayed on the main display as well as the local load module display.



Note

If the Active = OFF for all the channels then “No Active Channel” will be displayed instead of channel numbers.




Each active load module will display the output as the program runs.

14. If Run was configured to manual in any of the program sequences, press F2 (Next) to continue the program sequence, otherwise the program will continue automatically.

F2

15. Press F1 (Stop) at any time to abort the program when it is running.


F1



When the program has finished, the physical channels that have run will be displayed, a PASS or FAIL will be displayed if Go/NoGo testing has been set.


16. When the program has finished, press F1 to see any result details.

F1



The Program (P) and Sequence (S) numbers for the Program are displayed on the left hand side and the Go/NoGo (G/N) results are displayed on the right hand side for each channel in the program.

Use the Selector knob to scroll down to view the remainder of the list if necessary.



17. Press F5 to exit at any time.



Upon exiting, the previous menu before running the program will load.

Edit Sequence



Background The Sequence function can be configured to create a unique load profile to accurately simulate loads in real time for single or multiple loads. Sequence can only be used with CC static or CR static modes. For details see page 76.


Each Sequence is composed of a number of points with customizable current/resistance, slew rate and duration times. Each sequence can be looped an infinite amount of times. Sequences are only applicable for CC (Static) and CR (Static) modes.




Note


The sequence function should not be confused with program sequences. They are not the same. Program sequences cannot be used with the Sequence function and vice versa.

Parameters	Value	Setting Min ~ Setting Max	Ω/A
SlewRate		Load module dependent	
SlewRate			
Duration Time	0.000025 ~ 60,000 seconds		


- | | | |
|-----------------|--|---|
| Panel operation | 1. Choose a channel and mode. | Page 123,
125 |
| | 2. Press the CHAN key, F4 (Seq. Edit) to enter the Sequence Edit menu. |  |



3. Use the Selector knob to highlight Value.



4. Press the Selector knob to edit the Value, then turn to increase or decrease the value.




OR

5. Use the number pad to enter a number.




6. Press the Selector knob or Enter to confirm selection.



7. Repeat for rising and falling Slew Rate and Duration Time.

Add Point

8. To add an extra point after the current point, press Add Point (F1).



Range 001~120



Note

Add Point will insert a new point directly after the current point. The value of the current/resistance of the inserted point will be the average of the point before and after. All other settings will remain unchanged.


Delete Point

9. To delete the current point, press Delete Point (F2).

F2

Edit previous point

10. Use the selector knob to change the current point number.



001 Point



Note

The Point number can only be changed if more points have already been added.

Save Sequence

11. Press Save (F3) to save the sequence.

F3



Note

The save icon will only appear after a change has been made in the menu.

Create Sequence Loop

Background

Sequences can be looped a number of times. The loops can be started at any point in the sequence. The Start of Loop function determines which point will start each repeating loop.


The On End of Seq. function will hold the load current (of the selected sequence) to a designated value until all the other sequences have finished running.

CC Vrange sets the range in CC mode for Sequences. See page 76 for more details.


Ensure the menu is in the Seq. Edit menu and that a sequence has been created. See page 158

	Add Point	Delete Point	Loop	Previous Menu
Parameters	Repeat	1~9999/Infinity (0)		
	Start of Loop	001~ last point		
	On End of Seq.	OFF / Setting Min ~ Setting Max		
	CC Vrange (CC mode only)	High/Low		


- Panel operation 1. Press Loop (F4) to enter the Loop menu.



2. Use the Selector knob to highlight Repeat.



3. Press the Selector knob to edit Repeat, then turn to increase or decrease the value.



OR

4. Use the number pad to enter a number.



Select 0 to choose infinity.

Repeat 0005 Times


5. Press the Selector knob or Enter to confirm selection.



6. Repeat for the remaining parameters.

Save Loop

7. Press Save (F3) to save the loop.



Channel Duration Time Settings

Background

Each sequence can have the timing duration data of another sequence. For example CH1's sequence can import the timing duration settings of CH2's sequence.

This is useful to quickly compare two different loads to the same timing characteristics. See page 76 for more details.

Each channel's sequence can be turned off by configuring the channel Setting to OFF. If a channel uses the same channel number, i.e. CH 01 → 01, then the duration time settings will not be altered for that channel.



At least one channel must output a Trigger Sequence Signal via PIN4 of the first frame link connector (master) if a sequence is run. For more details see page 76.


The Trigger In signal is used to start any sequence that has TRIG set to IN. The trigger input signal is input via PIN4 of the first frame link connector (slave). For more details, see page 76.

Any channels with channel control (CH CONT) set to external will be shown on the right side as EXT. See page 183 for details on setting channel control.

Parameter	CH 01~08 Setting OFF ~ maximum channels
	CH 01~08 TRIG IN , OUT , IN/OUT, OFF

Ensure at least one sequence has been created and saved. Page 158


- Panel operation
1. Press FUNC, then Sequence (F2)  →  to enter the Channel Duration Time menu.




Note

CH3 is set to TRIG OUT, whilst CH1 & CH3 are set to TRIG IN. CH2 has no trigger settings and has CH CONT set to external.

2. Use the Selector knob to highlight a channel.




3. Press the Selector knob to edit the channel, and then turn to choose which channel's Duration Time Setting to import.



Range Ch 01~08 / OFF




4. Press the Selector knob or Enter to confirm selection.



Trigger Out Channel


5. Press Define TRIG OUT (F2) if you want the currently selected channel to output the Trigger sequence signal.



One channel must be set as the TRIG OUT channel.


Trigger In Channel

6. Press TRIG In Channel (F4) to allow the current sequence to be triggered with the Input trigger.



Trigger In On/Off


7. To turn the Input trigger source on, press Trig In (F5).



8. Repeat the above steps for any other remaining channels.

Save settings

9. Press Save (F3) to save the settings.



Run Sequence



Background Like Programs, Sequences must be turned “ON” before they can be run.


When running a Sequence, the front panel function keys, number pad, operation keys and selector knob are disabled for the specific channel(s). The load module panel is also disabled (bar the display key) for the specific channel.

Channels that do not have a Sequence can still be edited by changing channels via the CHAN key or by using the local load module.

Ensure at least one Sequence has been created and saved. Page 158

Ensure the Channel Duration Time Settings have also been configured and that no Sequence (CH01~08) that you wish to run are set to OFF. Page 162

- Panel operation**
1. Press FUNC, then Sequence (F2) to enter the Channel Duration Time Setting menu.  → 



2. Press Seq. (F1) to turn on the Sequences.




3. SEQ will be displayed on the Mainframe Status panel.



4. Press the LOAD key to run all the Sequences. If a channel has TRIG set to IN, that channel will now wait for a trigger before running.




5. Run SEQ Mode will be displayed on the bottom of the display for the specific channels. On the Mainframe Status panel, SEQ will turn orange.



Run SEQ Mode

Stop the load

6. Press the LOAD key again or wait for the Sequence (if not infinitely looped) to end/stop the load.



Turn off SEQ


7. Press Seq. (F1) to turn OFF the Sequence(s) when the load is not running.



All UI keys/knob will be disabled for all channels that run a Sequence, bar the function keys and R/L keys.

OCP Test Automation

Background The OCP test function creates an automatic test to test the OCP of power supply products.



Parameters	Active Channel	Applies the setting to the load channel.
	Range	High(CC Mode High) or Low(CC Mode Low)
	Start Current(Start C)	Starting current value for the test.
	End Current(End C)	The current value that will end the test. The value must be higher than the OCP value of the DUT you are testing. This parameter is used as a fail-safe for if the over current protection of the DUT fails.
	Step Current(Step_C)	Sets the step resolution of the current.

Last Current(Last_C)	Sets the final current value after OCP has been tripped. This is the steady-state current draw after the OCP has been tripped.
Step Time(Step_T)	Sets the execution time of each step. (50mS to 1600S)
Delay Time(Delay)	The OCP testing delay time. Sets the how long to delay starting the test after the Load On key has been pressed. (0 ~ 160S)
Trig Voltage(Trig_V)	Sets the voltage trigger level needed see whether the power supply OCP has been triggered. When the power supply OCP has been triggered, its voltage output will drop. The voltage trigger level is used to test to see if the voltage output has been drop.
Keep Time(Keep_T)	Set the how long to enter the Last Current after detect the OCP.(0~160S)



Note

This mode can only be used under CC mode.


Panel operation

1. Press the FUNC key, F4 (OCP) to enter the OCP Test Automation menu.




05/04/22		FRM	USB
16 : 50		SEQ	
OCP Function		Chan: 1	
Range:	High	Step_T:	0.05
Start C:	0.000	Delay:	0.000
End C:	71.400	Trig_V:	0.0000
Step_C:	0.002	Keep_T:	0.000
Last_C:	0.000		
OCP	Active		
On	Channel		

- Use the Selector knob to highlight the parameter you want to edit.



- Press the Selector knob to edit the parameter, then turn to increase or decrease the value.




OR

Use the number pad to enter a number.




- Press the Selector knob or Enter to confirm selection.




- Repeat steps 2 -4 for all the parameters.

Save the OCP Test Automation Settings




- Press Save (F3) to save the OCP Test Automation settings.








Select Active Channel


- To select the load channels for the test, press Active Channel (F2).





8. Use the selector knob to Enter key  or  to turn the Active value to ON.

Save the OCP Test Automation Channel


9. Press Save (F3) to save the OCP test automation channel. 

10. Press Previous Menu (F5) to return to the OCP Test Automation menu. 


11. Press OCP (F1) to turn OCP to ON. 



Save the OCP Test Automation Parameters

12. Press Save (F3) to save the OCP test automation parameters. 

Start the OCP Test Automation

13. Press the Load key to start to OCP Test Automation. 

Test Results

05/04/22
16 : 50
USB

OCP

Run OCP Test

CH: 1

4.8550V

1.10A

Voltage Reading: The voltage of the DUT before the OCP was triggered.


Current Reading: The current of the DUT before the OCP was triggered.



Note

In addition to the setting the OCP test parameters as described above, the VON voltage settings must also be set according to the output characteristics of the DUT.

An OCP Test Automation example using actual current and voltage waveforms.



Channel Configuration

The Channel Configuration chapter describes the configuration options for individual channels. Any configuration settings that are changed only apply to the current channel, other channels will not be changed.



Accessing the Configuration Menu

Background The configuration menu is used to access instrument settings and properties as well as set the protection levels for each channel.

Panel operation 1. Select the channel to be configured by pressing the CHAN key and using the Selector knob.



2. Press the F5 (Configure) key to enter the configuration (Protection) menu.



Setting (OCP/OVP/OPP/UVP)

Background Over Protection is used to set the voltage, current or power limit. In the event that the current, voltage or power exceeds the over protection settings, the load module display will show an error message and beep an alarm.


When tripped, Under Voltage Protection (UVP) will turn off the load. UVP trips when the load voltage drops below a set limit.

Only when the protection settings are set to On (XXP Setting -On) will the protection modes be active.


All protection settings can be set to 2% higher than specification rating.

Parameters	OCP Level	1.25% Rating A ~ 102% Rating A
	OCP Setting	ON/OFF/Clear
	OVP Level	1.25% Rating V ~ 102% Rating V (0.5% Rating V ~ 102% Rating V for PEL-2041B)
	OVP Setting	ON/OFF/Clear
	OPP Level	PEL-2020B : 1W ~ 102W PEL-2030B(L) : 0.9W ~ 30.6W PEL-2030B(R) : 1.25W ~ 255W PEL-2040B : 1.75W ~ 357W PEL-2041B : 1.75W ~ 357W
	OPP Setting	ON/OFF/Clear
	UVP Level	OFF ~ current using operating voltage range of slave module.
	UVP Setting	Clear
	Protection Clear	All


Panel operation Ensure the menu is the configuration menu. See page 173.



1. Use the Selector knob to highlight OCP Level.



2. Press the Selector knob to edit the selected level, then turn to increase or decrease the value.




OR


3. Use the number pad to enter a number.




4. Press the Selector knob or Enter to confirm selection.



5. Use the Selector knob to highlight OCP Setting.



6. Use the selector knob to turn ON, OFF or CLEAR the OCP Setting. 
7. Repeat steps 1-5 for :


OCP Level	OPP Setting
OVP Level	UVP Level
OVP Setting	UVP Setting
OPP Level	

Clearing an Alarm When any of the protection settings are tripped, Alarm will be shown on the Mainframe Status Panel and an alarm tone will sound by default.



On the local load module, the protection setting that has been tripped will be displayed.

OCP	<i>0</i>	<i>[</i>	<i>P</i>
OVP	<i>0</i>	<i>U</i>	<i>P</i>
REV*	<i>r</i>	<i>E</i>	<i>U</i> <i>_</i> <i>U</i>
OPP	<i>0</i>	<i>P</i>	<i>P</i>
OTP*	<i>0</i>	<i>t</i>	<i>P</i>
CPP*	<i>[</i>	<i>P</i>	<i>P</i>
UVP	<i>U</i>	<i>U</i>	<i>P</i>

8. Turn the load off by pressing the Load key and turn off the load input. 
9. Change the XXP Setting to Clear to clear the alarm.





Note

*REV, OTP and CPP cannot be cleared using this method, the Protection Clear function must be used instead, see page 177.

See pages 59 and 277 to output alarms via the Go/NoGo output terminal.

The configuration settings only apply to the current channel.

Protection Clear

Background

When any of the protection circuits have been tripped, the Protection Clear function can be used to reset the alarms.


Alarm will be shown on the Mainframe Status Panel and an alarm tone will sound by default when any of the protection settings are tripped.

05/04/22
16 : 50

Alarm

On the local load module, the protection setting that has been tripped will be displayed.

Example: Reverse voltage protection




OCP	0	C	P
OVP	0	U	P
REV	r	E	U
OPP	0	P	P
OTP	0	t	P
CPP	C	P	P

UVP **U U P**

Panel operation Ensure the menu is in the configuration menu. See page 173.



1. Turn the load off by pressing the load key if necessary.
2. Use the selector knob to scroll down to Protection Clear.



3. Press the Selector knob or Enter to clear all.



Note

The configuration settings only apply to the current channel, other channels will not be affected.

Setting the CC Voltage Range


Background The Constant Current Voltage range can be set to high or low.


Parameter CC Vrange High/Low

Panel operation Ensure the menu is in the configuration menu. See page 173.




1. Press the F2 (Other) key to enter the other menu.






- Use the Selector knob to highlight CC Vrange.




- Press the Selector knob to edit CC Vrange, then turn to increase or decrease the range.



CC Vrange High

- Press the Selector knob or Enter to confirm selection.



Note

The configuration settings only apply to the current channel.

Adjusting the Von Voltage and Latch

Background



The Von Voltage is the voltage point at which the load module will start to sink current. When Von latch is set to ON, the load will continue to sink current after being tripped, even if the voltage drops below the Von Voltage level. The step resolution of Von Voltage is load module dependent.

Parameters	Von Voltage	0.0~Rating volts
	Von Latch	ON/OFF


Panel operation Ensure the menu is in the configuration menu. See page 173.




1. Press the F2 (Other) key to enter the other menu.



2. Use the Selector knob to highlight Von Voltage.



3. Press the Selector knob to edit the selected value, then turn to increase or decrease the value.




OR

Use the number pad to enter a number.



4. Press the Selector knob or Enter to confirm selection.



5. Repeat steps 3 to 5 to turn Von Latch ON or OFF

For details about Von and Latch settings please see page 84.



Note

The configuration settings only apply to the current channel, other channels will not be affected.

Configuring the Short settings

Background	<p>The Short Key option is used to simulate a short circuit.</p> <p>The Short Function option is used to set whether short function is enabled or disabled.</p> <p>The Short key option can be configured to toggle (press SHORT on the load module to toggle ON or OFF) or to Hold (the SHORT key is held to short the load).</p> <p>The Short Safety option can be used to set whether short function enabled depends on Load ON or not. When setting to ON, short function enabled only when Load ON mode is enabled. When setting to OFF, short function directly enabled independent of Load ON mode.</p>						
Parameter	<table border="0" style="width: 100%;"> <tr> <td style="padding-right: 20px;">Short Function</td> <td>ON/OFF</td> </tr> <tr> <td style="padding-right: 20px;">Short Key</td> <td>Hold/Toggle</td> </tr> <tr> <td style="padding-right: 20px;">Short Safety</td> <td>ON/OFF</td> </tr> </table>	Short Function	ON/OFF	Short Key	Hold/Toggle	Short Safety	ON/OFF
Short Function	ON/OFF						
Short Key	Hold/Toggle						
Short Safety	ON/OFF						
Panel operation	<p>Ensure the menu is in the configuration menu. See page 173.</p>						

Protection



Other

Go-NoGo


Group

Previous
Menu


1. Press the F2 (Other) key to enter the other menu.



2. Use the Selector knob to highlight Short Function.




3. Press the Selector knob to edit the selected setting, turn to change the setting.




Short Function ON


4. Press the Selector knob or Enter to confirm selection.





5. Use the Selector knob to highlight Short Key.






6. Press the Selector knob to edit the selected setting, turn to change the setting.





Short Key Toggle

7. Press the Selector knob or Enter to confirm selection.  or 

8. Use the Selector knob to highlight Short Safety. 

9. Press the Selector knob to edit the selected setting, turn to change the setting.  → 

Short Safety **ON**

10. Press the Selector knob or Enter to confirm selection.  or 


Configuring Channel Control


Background When Channel Control (CH CONT) is set to External, it will disable editing the active channel load. Instrument buttons and knobs can still be used to access the menu for the active channel or to edit other channels that do not have channel control active. This prevents settings on the active channel from being changed on the local machine. See pages 56 & 87 for details.

Parameter	CH CONT	Panel/External
------------------	---------	----------------


Panel operation Ensure the menu is in the configuration menu. See page 173.

Protection	Other	Go-NoGo	Group	Previous Menu
------------	-------	---------	-------	---------------


1. Press the F2 (Other) key to enter the other menu. 




2. Use the Selector knob to highlight CH CONT.



3. Press the Selector knob to edit the selected setting, turn to change the setting from Panel to External.



4. Press the Selector knob or Enter to confirm selection.



Channel control is now activated. To turn Channel Control off, CH CONT must be set to Panel again. When Channel Control is active, EXT will be displayed on the side panel for the active channel.



Channel Control can only be activated on the active channel; other channels will not be affected.

Configuring the Independent Setting


Background The Independent setting allows a channel to be load independent from the mainframe. What this means is that a load module with Independent set to ON can only load from the local load module. If the LOAD ON/OFF key is pressed from the mainframe, the channel with Independent set to ON will be unaffected by the mainframe, except when running a program.

Parameter Independent ON/ OFF


Panel operation Ensure the menu is in the configuration menu. See page 173.




1. Press the F2 (Other) key to enter the other menu.




2. Use the Selector knob to highlight Independent.



3. Press the Selector knob to edit the selected setting, turn to change the setting. 

Independent **OFF**

4. Press the Selector knob or Enter to confirm selection. 



Note

When a channel has been set to independent, an asterisk (*) will be shown next to the channel number indicator in the Current Operation Channel Status panel.

The configuration settings only apply to the current channel, other channels will not be affected.




Configuring the Load Delay Time

Background The mainframe can delay loading a channel by up to 10 seconds. However the Delay Time is only applicable for manual loading. Delay Time is not applicable to Programs or Sequences.


Parameter Load D-Time 0~10 S

Panel operation Ensure the menu is the configuration menu. See page 173.




1. Press the F2 (Other) key to enter the other menu.






2. Use the Selector knob to highlight Load D-Time.



3. Press the Selector knob to edit the selected setting, turn to change the setting.




OR

Use the number pad to enter a number.



Load D-Time **0.0 S**

4. Press the Selector knob or Enter to confirm selection.



Note

The Delay Time only applies to the current channel; other channels will not be affected.

Delay time only applies when the load is manually turned on or during start up with the Auto Load On setting (page 201).

Configuring Step Resolution

Background The CC, CR, CV and CP step resolution settings can be edited in the configuration menu. These step resolution settings directly correspond to the step resolution of the coarse adjustment when setting the CC, CR, CV and CP parameters.

The minimum and maximum step resolution that can be set for each channel is dependent on the load module. For more information on step resolution see page 84.

Step Resolution		Minimum*1	Maximum*2	Unit
PEL-2020B	CCH Step	HR/20000	HR/2	Amperes A
	CCL Step	LR/20000	LR/2	Amperes A
	CRH Step	HR/40000	HR/2	Siemens Ū
	CRL Step	LR/40000	LR/2	Siemens Ū
	CVH Step	HR/40000	HR/2	Voltage V
	CVL Step	LR/40000	LR/2	Voltage V
	CPH Step	HR/10000	HR/2	Watt W
	CPL Step	LR/10000	LR/2	Watt W
PEL-2030B (L)	CCH Step	HR/40000	HR/2	Amperes A
	CRH Step	HR/40000	HR/2	Siemens Ū
	CRL Step	LR/40000	LR/2	Siemens Ū
	CVH Step	HR/40000	HR/2	Voltage V
	CVL Step	LR/40000	LR/2	Voltage V
	CPH Step	HR/30000	HR/2	Watt W

PEL-2030B (R)	CCH Step	HR/40000	HR/2	Amperes A
	CCL Step	LR/40000	LR/2	Amperes A
	CRH Step	HR/40000	HR/2	Siemens U
	CRL Step	LR/40000	LR/2	Siemens U
	CVH Step	HR/40000	HR/2	Voltage V
	CVL Step	LR/40000	LR/2	Voltage V
	CPH Step	HR/25000	HR/2	Watt W
	CPL Step	LR/25000	LR/2	Watt W
PEL-2040B	CCH Step	HR/35000	HR/2	Amperes A
	CCL Step	LR/35000	LR/2	Amperes A
	CRH Step	HR/40000	HR/2	Siemens U
	CRL Step	LR/40000	LR/2	Siemens U
	CVH Step	HR/40000	HR/2	Voltage V
	CVL Step	LR/40000	LR/2	Voltage V
	CPH Step	HR/35000	HR/2	Watt W
	CPL Step	LR/35000	LR/2	Watt W
PEL-2041B	CCH Step	HR/20000	HR/2	Amperes A
	CCL Step	LR/20000	LR/2	Amperes A
	CRH Step	HR/40000	HR/2	Siemens U
	CRL Step	LR/40000	LR/2	Siemens U
	CVH Step	HR/50000	HR/2	Voltage V
	CVL Step	LR/50000	LR/2	Voltage V
	CPH Step	HR/35000	HR/2	Watt W
	CPL Step	LR/35000	LR/2	Watt W

¹ HR = High range rated value, LR = Low range rated value.


² Maximum value = HR (LR)/2 * 1.02.




Note

Use the Shift key to toggle between coarse and fine adjustment mode when editing the CC, CR, CV and CP values with the Selector knob on the main display. The fine adjustment resolution varies between the function and load module used.

Coarse mode:



Fine mode:





Panel operation


Ensure the menu is the configuration menu. See page 173.



1. Press the F2 (Other) key to enter the other menu.




2. Use the Selector knob to scroll down to highlight CCH Step.



Note

CCH Step is off-screen when entering Other menu.

- Press the Selector knob to edit the selected setting, turn to change the setting.




OR

Use the number pad to enter a number.



CCP Step 0.002 A

- Press the Selector knob or Enter to confirm selection.



- Repeat steps 2-4 to edit the step resolution of:

CCL Step	CVH Step	CPH Step
CRH Step	CVL Step	CPL Step
CRL Step		



Note


The Step resolution settings only apply to the active channel, other channels will not be affected.

Configuring Response Time

Background The Response time setting is used to limit current draw when input voltage less than 1V. The Response setting sets the bandwidth of the load to Fast (20kHz) or as Normal (200Hz).


Parameters Response Normal, Fast

Panel operation Ensure the menu is the configuration menu. See page 173.




- Press the F2 (Other) key to enter the other menu.





- Use the Selector knob to scroll down to highlight Response.




Note

Response is off-screen when entering Other menu.

Response Normal

- Press the Selector knob or Enter to confirm selection.



Note

The Response settings only apply to the active channel, other channels will not be affected.

Go/NoGo

Background

Go/NoGo mode is used to set threshold limits. When a load is within the limit(s) it is considered to be “Go”, when the load has exceeded the limit it is considered to be “NoGo”.

Go/NoGo limits can be set as either absolute values (Entry Mode set to “Value”) or as a percentage offset from a nominal (Center) value (Entry Mode set to “Percent”).

Go/NoGo can be used in both high and low ranges, as well as CC, CV, CR and CP Modes. The Go/NoGo status can be read using the rear Go/NoGo output.

A delay time can also be imposed for up to 1 second.



Note

Any Go/NoGo configuration only applies to the current channel with the same mode and range.

Parameters	Entry Mode	Value	Percent
	CC Mode	High: V	High: %
	CR Mode	Low: V	Low: %
			Center: V
	CV Mode	High: A	High: %
	CP Mode	Low: A	Low: %
			Center: A
	Delay Time	0.0~1.0 seconds	
	SPEC Test	ON/OFF	


Panel Operation Ensure the menu is in the Configuration menu. See page173.



Choose Absolute/ Percentage limits 1. Press (F3) Go-NoGo to access the Go/NoGo menu.



2. Use the selector knob to edit Entry Mode.



3. Choose Value for absolute limits or Percent for percentage offset limits.

Entry Mode Value



Or

Entry Mode Percent


- The menu changes according to the selection.

Value


Percent



- Use the Selector knob and number pad to edit Delay time, High, Low and Center (Percent mode only).




- Press the selector knob or Enter to confirm each value.



Turn Go/NoGo On/Off

- Use the Selector knob to edit Spec Test.



- Choose ON to turn on Go/NoGo.

SPEC Test ON

- Choose OFF to turn off Go/NoGo.

SPEC Test OFF

When SPEC test is set to ON, SPEC will be displayed in the Current Operation Channel Status panel.



Group Unit

Background The Group Unit menu allows load modules of the same type and rating to be configured as a single unit when used in parallel. Up to 4 load modules can be used in this mode.

Operating the PEL-2000B series load modules in Group Unit mode is almost identical to using the load modules separately. The only difference is that the channel configuration only needs to be setup for channel 1 and not individually for each channel.

There are two mode types: Para and Sync. The Para setting allows the all the parallelized load modules to be operated as a single large load module. Sync mode allows the settings of a single unit to be synchronized across all the other parallelized load modules.

The Display Mode will determine which parameters are displayed on the local load modules.



Note

Only CC or CR mode can be used in Group Unit.

For the single channel load modules, PEL-2040B and PEL-2041B are fully support these two modes (Para, Sync) of group function.

The PEL-2030B does not support group function.

The dual channel of PEL-2020B does support group function partially. It can support to group 2 units of same module under the Sync mode only. That means the PEL-2020B can be 2chx100W or 1chx200W.

Ensure the same firmware used for both units.

Parameters

Total Unit 2/3/4/OFF

Group Mode Para/Sync

Display Mode V,I /V,W/I,W/S



Note

If “Total Unit: 2” is set on a 4-channel mainframe, the modules of channels 3 and 4 won't be set to the group unit function.

Panel Operation


1. Ensure current channel is selected Page 124 as the active channel.
2. Ensure the menu is in the Configuration menu. See page 173.




Parallel Setup



3. Press (F4) Group to access the Group menu.






4. Use the Selector knob to change Total Unit from the OFF setting to the number of parallel units. 

Total Unit 2


5. Press the selector knob or Enter to confirm.  or 

Parallel Mode

6. To change the type of mode, use the Selector knob to edit Group Mode. 
7. Choose Para to operate the units as a single large load module, or choose Sync to synchronize the load settings across each parallel unit.

Group Mode Para

Display Mode

8. Use the selector knob to change the display settings on the local load modules. 
9. Choose from V, I / V, W / I,W or S.

Display Mode V,I

When Para Unit is active, an indicator will be displayed on the screen. The indicator depends on the Group Mode. P will be displayed for Para Mode and S will be displayed for Sync Mode.

CHXP Para Mode


CHXS Sync Mode



The PEL-2000B is now ready to operate in Parallel Mode.

Turn Parallel Mode Off

10. To disable Parallel Mode, use the selector knob to change Total Unit to OFF.



Total Unit OFF

Mainframe Configuration

The Mainframe Configuration chapter describes configuration settings that apply to all channels and general interface settings.

Accessing System Information

Background	The System Information displays the mainframe and load module(s) serial numbers.
------------	--

Parameters	<p>MainFrame Ver: Mainframe firmware version.</p> <p>PEL-200X SN: Mainframe Serial number.</p> <p>SlotX(Y)Ver: The version number of the Xth load module occupying the Xth slot with channel number Y.</p> <p>PEL-20XX SN: The serial number and module model of the Xth load module</p> <p>Y designates the channel of each installed load module. For example if dual channel load modules are installed, then Ch (1,2) will be used for the firmware and serial number.</p>
------------	--

Panel operation	<ol style="list-style-type: none"> 1. Press the Shift Key then the Help key to access the Utility menu/System Info menu.
-----------------	---



05/04/22		LOAD		USB
16 : 50				
MainFrame Ver: 3.XX XXXX				
PEL-2002 SN: EJXXXXXX				
Slot1(1)Ver: 3.XX				
PEL-2041 SN: EJXXXXXX				
Slot2(2)Ver: 3.XX				
PEL-2041 SN: EJXXXXXX				
System Info	Load	Interface	Time Set	Other



Note

If you have set Memo through command, you can see the Memo information by pressing System Info (F1) once again. (Please refer to the chapter contains commands “:MEMo” and “:CHANnel:MEMo” in the programming manual for details)

05/04/22		LOAD		USB
16 : 50				
MainFrame (PEL-2004B) MEMO:				
No Memo				
CH1 (PEL-2040B) MEMO:				
123				
CH2 (PEL-2040B) MEMO:				
123				
System Memo	Load	Interface	Time Set	Other




Accessing the Load Menu


Background The PEL-2000B series is able to automatically start loading from the last program or load setting.




If Auto Load On is set to Load, the last load setup used before the machine was reset will automatically start to load upon startup.

If Program is set as the Auto Load On configuration, the last program executed will start upon the next start up.

Parameters Auto Load ON/OFF
Auto Load On Load/Program

- Panel operation**
1. Press the Shift Key then the Help key to access the Utility menu.  
 2. Press F2 (Load). 



3. Press the Selector knob, then turn to choose Auto Load. 
4. Press the Selector knob or Enter to confirm selection.  or 



5. Scroll to Auto Load On and choose Load or Program for the next time the PEL-2002B starts up.

Adjusting the Speaker


Background The PEL-2000B series has an internal speaker for both the mainframe and load modules. The speaker function turns On/Off the sound for the UI (key presses and scrolling). The speaker setting will not alter the sound for protection alarms or Go/NoGo alarms.


Parameter Speaker ON/OFF

- Panel operation**
1. Press the Shift Key then the Help key to access the Utility menu.
 2. Press F5 (Other Menu).




3. Use the Selector knob to highlight Speaker.



4. Press the Selector knob to edit Speaker, then turn to change from On to Off and vice versa. 



Speaker ON

5. Press the Selector knob or Enter to confirm selection. 

Adjusting the Display Settings

Background The PEL-2000B series has a TFT LCD display. The display brightness and contrast can be controlled via the utility menu.

Parameters	Brightness	50~90	50(low)	90(bright)
	Contrast	3~13	3(low)	13(high)

- Panel operation**
1. Press the Shift Key then the Help key to access the Utility menu. 
 2. Press F5 (Other Menu). 

05/04/22 **USB**
16 : 50 **LOAD**

Other Setting

Speaker ON

Contrast 8


Brightness 64

Frame CONT OFF


Alarm Tone(M) OFF

System Info	Load	Interface	Time Set	Other
-------------	------	-----------	----------	-------

- Use the Selector knob to highlight Contrast.




- Press the Selector knob to edit contrast, then turn to increase or decrease the value.



Contrast

8

- Press the Selector knob or Enter to confirm selection.



- Repeat steps 3-5 for the Brightness.

Adjusting the Frame Control

Background Frame control is used to control a number of different frame linked mainframes (slaves) with a master mainframe. For information on frame control, frame control interface and connection see pages 54 & 274.




Note

When using frame control, ensure the same firmware is installed in both master and slave units.


Parameters Frame CONT ON/OFF


- Panel operation**
- Connect the mainframes using a frame link connection. Page 54.

- On the master mainframe, press the Shift Key then the Help key to access the Utility menu.




- Press F5 (Other Menu).







4. Use the Selector knob to highlight Frame CONT.



5. Press the Selector knob to edit, then turn to turn Frame CONT (frame control) ON or OFF.



When Frame CONT is set to ON the mainframe will display FRM (Master) or FRS (Slave) on the top of the display.

- Repeat the above steps for any connected slave mainframe units.

Frame control is now ready for both master and slave mainframes.




Adjusting the Knob Control Type


Background The mainframe control knob can be set to “Update” or “Old” mode.

When setting to Update mode, rotating the mainframe knob will change the setting value of load module at the same time.


When setting to Old mode, rotating the mainframe knob won’t change the setting value of load module unless pressing the knob or Enter key.

Parameter	Knob Type	Updated/Old
-----------	-----------	-------------


- | | | |
|-----------------|--|---|
| Panel operation | 1. Press the Shift Key then the Help key to access the Utility menu. |   |
| | 2. Press F5 (Other Menu). |  |



- Use the Selector knob to move the cursor down to Knob Type (below the initial screen).




- Press the Selector knob to highlight Knob Type, then turn to change to Old/Updated.





Knob Type Updated


- Press the Selector Knob or Enter to confirm selection.




Configuring Alarm Sound

Background	<p>The PEL-2000B series has two different types of alarms, one located on the mainframe (Alarm Tone M) and one for each load module (Alarm Tone S).</p> <p>Alarm Tone (M)/(S) can individually be set ON or OFF.</p>	
Parameter	Alarm Tone(M)	ON/OFF
	Alarm Tone(S)	ON/OFF
Panel operation	<ol style="list-style-type: none"> Press the Shift Key then the Help key to access the Utility menu. Press F5 (Other Menu). 	






- Use the selector knob to highlight Alarm Tone(M)



- Press the Selector knob to select the master alarm (Alarm Tone (M)), turn to edit and press to confirm selection.



Alarm Tone(M) ON

- Repeat the steps to edit the slave alarm (Alarm Tone(S)).


Configuring Go/NoGo Alarm Sound

Background When any Go/NoGo limits are tripped from any channel, a tone can be set as an alarm.


The Go_NoGo tone alarm settings apply to all channels.

Parameter Go_NoGo Tone ON/OFF


- Panel operation**
- Press the Shift Key then the Help key to access the Utility menu.




2. Press F5 (Other Menu).



3. Use the Selector knob to move the cursor down to Go_NoGo Tone (below the initial screen).




4. Press the Selector knob to highlight Go_NoGo Tone, then turn to change to ON/OFF.



Go_NoGo Tone OFF

5. Press the Selector Knob or Enter to confirm selection.



Adjusting Slave Knob Settings



Background Channel loads can be edited using the local load module or the Mainframe. When using the slave knob to edit a load, the load module display can be set to two different types: SetValue and Measured.


When a load is ON, SetValue will always display



the set value (A Value, B Value) on the local load module display whilst “Measure” will show the actual measured value when editing the load. These settings apply to all channels.

The “Measure” setting can be temporarily disabled by pressing the Slave Knob to display the “SetValue” instead of the “Measure” value in the local load module display.

Parameter	Slave Knob	Measure/SetValue
-----------	------------	------------------


- Panel operation
1. Press the Shift Key then the Help key to access the Utility menu. 
 2. Press F5 (Other Menu). 



3. Use the Selector knob to move the cursor down to Slave Knob (below the initial screen). 
4. Press the Selector Knob to highlight Slave Knob, then turn to change to Measure/SetValue. 

Slave Knob **SetValue**

- Press the Selector Knob or Enter to confirm selection.





View Language Settings

Background The language settings can be viewed in the Utilities menu.


- Panel operation**
- Press the Shift Key then the Help key to access the Utility menu.



- Press F5 (Other Menu).



- Use the Selector knob to move the cursor down to Language (below the initial screen).







Adjusting the High Resolution

Background


ON: When there is difference between the measured value of voltage, current or power which displayed on the module panel and the setting value, the system will fine tune the load value so that the measured value close to the setting value. The system will perform and complete this action after loading is on in one second.

OFF: The system won't perform any action when there is difference between the measured value of voltage, current or power which displayed on the module panel and the setting value.


Parameter	High Resolution	ON/OFF
Panel operation	<ol style="list-style-type: none"> 1. Press the Shift Key then the Help key to access the Utility menu. 2. Press F5 (Other Menu). 	  



- Use the Selector knob to highlight High Resolution.




- Press the Selector knob to edit High Resolution, then turn to change from ON to OFF and vice versa.




High Resolution ON

- Press the Selector knob or Enter to confirm selection.




Adjusting the System Mode

Background	1: When any command is received, the Master panel will automatically enter the Remote fast mode.
	0: The Master panel won't automatically enter the Remote fast mode.


 **Note** For details about remote mode fast/normal, please refer to command :UTILity:REMote:MODE in the programming manual.


Parameters	System Mode	0/1
------------	-------------	-----

- Press the Shift Key then the Help key to access the Utility menu.




- Press F5 (Other Menu).






3. Use the Selector knob to highlight System Mode.




4. Press the Selector knob to edit System Mode, then turn to change from 0 to 1 and vice versa.



System Mode 0

5. Press the Selector knob or Enter to confirm selection.




Adjusting the Von Latch Clear

Background

Auto: Load starts when the terminal voltage of module is higher than Von value. The system stops loading when the terminal voltage of module is close to 0V for more than 25ms and system is under the state of detecting Von again.

Manual: The load starts when the terminal voltage of module exceeds the Von setting value. Loading keep going even if the terminal voltage of module close to 0V.



Note

This feature is only available when Von Latch is set to ON.

Parameters

Von Latch Clear Auto/Manual


Panel operation

1. Press the Shift Key then the Help key to access the Utility menu.




2. Press F5 (Other Menu).






- Use the Selector knob to highlight Von Latch Clear.



- Press the Selector knob to edit Von Latch Clear, then turn to change from Auto to Manual and vice versa.



Von Latch Clear Auto


- Press the Selector knob or Enter to confirm selection.

Adjusting the Measure Period


Background You can select a measure sample rate through this setting. 200ms or 20ms are available for voltage and current sampling rate.

Parameter Measure Period 200ms/20ms


- Panel operation**
- Press the Shift Key then the Help key to access the Utility menu.




2. Press F5 (Other Menu).



3. Use the Selector knob to highlight Measure Period.




4. Press the Selector knob to edit Measure Period, then turn to change from 200ms to 20ms and vice versa.



Measure Period 200ms




5. Press the Selector Knob or Enter to confirm selection.




Adjusting the Jog Shuttle Control


Background **ON:** After this setting is enabled, the settings value will be adjusted by slave knob in Jog Shuttle mode when you adjust the setting value. The interval value is adjusted according to the knob speed.


OFF: If this setting is disabled, the settings value will be adjusted by slave knob in the form of fixed compartment when you adjust the setting value.

Parameter	Jog Shuttle Control	ON/OFF
Panel operation	<ol style="list-style-type: none"> Press the Shift Key then the Help key to access the Utility menu. Press F5 (Other Menu). 	  



- Use the selector knob to highlight Jog Shuttle Control




4. Press the Selector knob to edit Jog Shuttle Control, then turn to change from OFF to ON and vice versa. 

Jog Shuttle Control OFF



5. Press the Selector knob or Enter to confirm selection.


Adjusting the RVP Load Off

Background	ON: When RVP is detected, Alarm will display on the screen and stop loading. OFF: When RVP is detected, Alarm will display on the screen but loading is kept on.
------------	---


 **Note** This setting applies to all channels. But each channel independently detects RVP and performs the action of emitting alarm and stopping load.

Parameter	RVP Load Off	ON/OFF
-----------	--------------	--------


- Panel operation
1. Press the Shift Key then the Help key to access the Utility menu. 
 2. Press F5 (Other Menu). 



- Use the Selector knob to highlight RVP Load Off.




- Press the Selector knob to edit RVP Load Off, then turn to change from OFF to ON and vice versa.





RVP Load Off OFF

- Press the Selector Knob or Enter to confirm selection.



Setting the Date and Time

Description	The date and time settings are used to time-stamp files when saving files.	
	<ul style="list-style-type: none"> The date is shown on top of the display. 	
Parameters	Month	1~12
	Day	1~31
	Year	1990~2038
	Hour	0~23
	Minute	0~59
Panel operation	<ol style="list-style-type: none"> Press the Shift Key then the Help key to access the Utility menu.  Press F4 (Date/Time Menu).  	
	Settings: Month, Day, Year, Hour, Minute	

05/04/22		RS232		
16 : 50		LOAD		
Date/Time				
Month		6		
Day		15		
Year		18		
Hour		16		
Minute		50		
System Info	Load	Interface	Time Set	Other

Interface Configuration (settings)

The Interface Configuration chapter describes configuration settings that apply when using the PEL-2000B mainframe with a remote connection. There are three interface options for remote control: RS232 or RS485, GPIB, LAN and USB. Only one interface can be used at a time. For more details about remote control and interface connections, see the Interface section on page 269.



Configuring RS232 or RS485 Connection


Background When using UART (RS232 or RS485) a number of parameters need to be set. These include Baud rate, Data Bits, Stop Bit, Parity and Address [This is available when Mode is RS485]. When setting RS232/RS485 parameters, ensure they match that of the host machine.

Parameters	Connector RJ-45
	Baud Rate 2400/4800/9600/19200/38400/57600/115200
	Data Bits 7bits/8bits
	Stop Bit 1Bit/2Bits
	Parity None/Odd/Even
	Address 0 ~ 30 [This is available when Mode is RS485]

UART mode RS232 / RS485 (Switchable)

- Operation**
1. Connect an RS232 or RS485 series cable from the PC to the Remote IN port on the real panel.
 2. Connect the other end of the cable to the PC.
 3. If the Interface is not UART, use the Selector knob to edit Interface.







4. Choose RS232.




5. Press the Selector knob to confirm.




6. The RS232 Menu appears.




7. Use the Selector knob to edit Baud rate, Stop Bit and Parity.



- Choose RS485 and the RS485 Menu appears.



- Use the Selector knob to edit Baud rate, Data Bit, Stop Bit, Parity and Address.



Note


The Baud Rate, Data Bits, Stop Bit, Parity and Address must match that of the host machine.

For RS232 or RS485 function check, please refer to the section “RS232 or RS485, LAN and USB CDC function check” on page 229.



Configuring USB Connection

Background	Of the three interface options, USB is the easiest to use.	
USB connection	PC side connection	Type A, host
	PEL-2000B side connector	Type B, device
	Speed	1.1/2.0(full speed)


- Panel operation
- Press the Shift Key then the Help key to access the Utility menu.



2. Press F3 (Interface Menu).




3. If the Interface mode is not USB, use the Selector knob to edit Interface.




4. Choose USB.



5. Press the Selector knob to confirm.



6. The Interface will become USB.



7. Connect the USB cable to the USB-B slave port on the rear.



8. When the PC asks for the USB driver, select gw_pel2k.inf



Note


For USB CDC function check, please refer to the section “RS232 or RS485, LAN and USB CDC function check” on page 229.

Configuring the GPIB Address



Background When using GPIB, an address must be specified.

Parameters Address 01~30


Panel operation 1. Press the Shift Key then the Help key to access the Utility menu.



2. Press F3 (Interface Menu).




3. If the Interface mode is not GPIB, use the Selector knob to edit Interface.




4. Choose GPIB.





5. Press the Selector knob or Enter to confirm selection.




6. The GPIB menu appears.



7. Use the selector knob to edit the GPIB address.  or 

8. Edit the GPIB address.

Range 1 ~ 30

9. Connect the GPIB cable to the rear panel port: 24-pin female connector. 

- GPIB constraints
- Maximum 15 devices altogether, 20m cable length, 2m between each device
 - Unique address assigned to each device
 - At least 2/3 of the devices turned On
 - No loop or parallel connection



Note

The GPIB Address must match that of the host machine.

For GPIB function check, please refer to the section “GPIB function check” on page 232.

RS232 or RS485, LAN and USB CDC Function Check

Background To test the RS232 or RS485, LAN and USB CDC functionality, National Instruments Measurement and Automation Explorer can be used.

Requirements Operating System: Windows XP, 7, 8, 10




Note

Functionality check can only be performed after the cable connection has been completed and the PEL-2000B interface has been set.


**Functionality
check**

1. Start the NI Measurement and Automation Explorer (MAX) program. Using Windows, press:


Start>All Programs>National Instruments>Measurement & Automation
2. From the Configuration panel access, **My System>Devices and Interfaces**, select the corresponding port which is connected to PEL-2000B via USB, RS232 or RS485 or LAN interface.
3. In this example (NI MAX Version 18.0.0f0), we assume that PEL-2000B series is connected COM 1(ASRL1), after selecting the ASRL1::INSTR "COM1", click the Open VISA Test Panel.



4. In the ASRL Settings page. You can see the information of Serial Settings.



5. Click on I/O Settings.
6. Make sure the *Enable Termination Character* check box is checked, and the terminal character is \n (Value: xA).
7. Click *Apply Changes*.




- Click the *Input/Output* icon.
- Enter `*IDN?\n` in the *Select or Enter Command* dialog box if it is not already.



- Click the *Query* button.
- The `*IDN?\n` query will return the Manufacturer, model name, serial number and firmware version in the dialog box.

GW Instek,PEL-2000B,00000001, V3.01\n



The COM port corresponding to the USB CDC will exist until the USB driver is well installed. If you want to do the USB CDC function check, the VISA resource name should be changed to the COM port which is occupied by the USB CDC protocol as a virtual com port in your system.

GPIB Function Check


Background To test the GPIB functionality, National Instruments Measurement and Automation Explorer can be used.

Requirements Operating System: Windows XP, 7, 8, 10

Functionality check Please use the National Instruments Measurement & Automation Controller software to confirm GPIB functionality.

Operation

1. Start the NI Measurement and Automation Explorer (MAX) program. Using Windows, press:
Start>All Programs>National Instruments>Measurement & Automation
2. From the Configuration panel access;
My System>Devices and Interfaces>GPIB0
3. Press the *Scan for Instruments* button.
4. In the *Connected Instruments* panel the PEL-2000B should be detected as *Instrument 0* with the address the same as that configured on the PEL-2000B.
5. Double click the *Instrument 0* icon.




6. Click on *Communicate with Instrument*.
7. In the *NI-488.2 Communicator* window, ensure **IDN?* is written in the *Send String*: text box.

Click on the *Query* button to send the **IDN?* query to the instrument.

8. The *String Received* text box will display the query return:

GW Instek,PEL-2000B,xxxxx, xxx

(manufacturer, model, serial number, version)



9. The function check is complete.

Saving/Recalling Channels

Background

The PEL-2000B series can save data for up to 120 different channel configurations. Each channel is represented by 120 memory slots using the onboard memory.


Memory is used in program sequences or for individual channel setups. For further details on memory, see page 91.

Panel operation


1. Press the File key.



2. Press F1 repeatedly until the Media Memory menu appears.




3. Use the Selector Knob to edit Channel Data and Data Type.



4. Choose Current or All and Memory.

Channel Data	Current
Data Type	Memory

5. Press the Selector knob to edit Memory (M001-M120)



OR

Use the number pad to enter a number.



6. Press F3 to Save or F4 to Recall the memory settings.



7. A message will indicate when a save has been successful

Memory No 001 Save OK



Note

The display will revert to the channel menu after recalling memory.

Saving/Recalling Preset memory


Background The PEL-2000B series can store up to 10 presets for each channel. The presets can be saved or recalled either individually for each channel (Channel Data: Current) or at the same time (Channel Data: All), using the All option.

For further details on memory, see page 91.


Panel operation 1. Press the File key.



2. Press F1 repeatedly until the Media Memory menu appears.



3. Use the Selector Knob to edit Channel Data and Data Type.



4. To save or recall only the active channel, choose Current and Preset. To save or recall all the presets choose All and Preset.


Save / Recall
Current Channel

Channel Data	Current
Data Type	Preset

Save / Recall All
Channels


Channel Data	All
Data Type	Preset

5. Press the Selector knob to edit Preset (P0-P9)




OR

Use the number pad to enter a number.



6. Press F3 to Save or F4 to Recall the Presets.



7. A message will be displayed when the save is complete.

Preset P0 Save OK



Note

The display will revert to the channel menu after recalling memory.


Saving/Recalling Setup Memory

Background The PEL-2000B series can store up to 4 different setups using the onboard memory. Each setup can be saved from the file menu. Using Setup Memory, each channel will be saved. For further details on memory, see page 91.


Panel operation 1. Press the File key.



2. Press F1 repeatedly until the Media Memory menu appears.




3. Use the Selector Knob to edit Channel Data and Data Type.



4. Choose All and Setup.




- Press the Selector knob to edit Setup Memory (1~4)




OR

Use the number pad to enter a number.



- Press F3 to Save or F4 to Recall the Setup Memory.




- A message will be displayed when the save/recall is complete.


Setup Memory 1 Save OK
Setup Memory 1 Recall OK


Setting the Default USB Path/File


Background When saving files to a USB memory stick the files will be saved into the root directory if a file path has not been set.


Panel operation 1. Insert a USB flash drive into the front panel USB slot. 

2. Press the File key. 

3. Press F1 repeatedly until the Media USB menu appears. 



4. Press F5 (File Utility). 




The top section (window) shows the current USB path.

There are 4 options:

- **Select;** Selects the current USB path as the default file path to save. (Step 5)
- **New Folder;** Creates a new folder (Step 7)
- **Rename;** Renames the current folder/path (Step 13)
- **Delete;** deletes the current file/path name. (Step 20)


Select Default Path

5. Use the Selector knob to highlight the new path directory



6. Press F1 (Select) to select the new default directory path.






The new path will be shown in the upper Path box in green.




Create New Folder


- To create a new directory, Press F2(New Folder)




The On-Screen keyboard (OSK) appears. The directory has an 8 character size limit.



- Use the Selector knob to scroll left and right through the keys.



- When a key is highlighted, use the selector knob, F1 or Enter to confirm a key entry.





10. Use F2 (Back Space) to delete any previous entries/mistakes. F2

11. Press F3 (Save) to save the directory name. F3

12. Press F5 (Previous menu) to continue to the previous menus F5

Rename Folder

13. Use the Selector knob to highlight the file/ directory that needs to be renamed.




14. Press F3 (Rename) F3


The On Screen Keyboard appears



15. Use the Selector knob to scroll left and right through the keys.



16. When a key is highlighted, use the selector knob, F1 or Enter to confirm a key entry.



17. Use F2 (Back Space) to delete any previous entries/mistakes.




18. Press F3 (Save) to save the directory name.



19. Press F5 (Previous menu) to continue to the previous menus



Delete File Name 20. Use the Selector knob to highlight a file/directory.



21. Press (F4) Delete.




Note

If there is any content in the folder, you cannot delete it and the message **Error! This folder may be not empty!** will be displayed on the screen.

22. To confirm deletion, press F4 again.








Saving Setups to USB Memory

Background Setup data contains all the channel data including Memory, Presets and Program Sequences.


There are four setups in internal memory. When saving to USB, all four setups will be saved. Conversely, when recalled, all four setups will be recalled to main memory.

The file extension *.S is used for Setup data only.


Parameters	Save File	200X0_XX.S
------------	-----------	------------

- Panel operation**
1. Insert a USB flash drive into the front panel USB slot. 
 2. Ensure the USB path has been set. Page 240.
 3. Press the File key. 
 4. Press F1 repeatedly until the Media USB menu appears. 






5. Use the Selector Knob to edit Save Chan and Data Type.




6. Choose All and Setup.



The screen will update to only show Setup files (*.S) that are available to save/recall in the root directory. Press F5 (File Utility) to select the directory to save.


Save/ Recall
Setups to USB

- Use the Selector Knob to edit Save File or Recall File. Rotating the selector knob will scroll through all the available setup files (*.S).



- Choose a file name.

- Press F3 (Save) to save the setup data or F4 (Recall) to recall the setup data.



- A screen message will appear when the save/recall has completed.

20040_01.S Save Ok

20040_00.S Recall Ok



Note

Setups can only be saved if they have been saved to internal memory first. For details on how to save to internal memory see page 238.

Saving/Recalling Memory Data to USB

Background

There are two options to save or recall Memory data to a USB flash drive:

Save Chan Current: Saves the active Channel's Memory data (M001~M120) into the root directory (20XXX_XX.M). Press F5 (File Utility) to select the directory to save.




Save Chan All: Every channel's Memory data (CH1 M001~120 ~ CH8 M001~M120) will be saved into a directory (ALL00XX) as separate files for each channel (P0X0X_C1.M ~ P0X0X_C8.M).


Recall File: Recalls the selected file to the active channel's Memory. It is not possible to update all the channels at once, only one channel at a time can be recalled.

The file extension *.M is used for Memory data only.


For more information about the file structures see, page 91.

Parameters	Save Channel Data: Directory ALL0000 ~ ALL0099 All File: P0X0X_CX.M
	Save Channel Data: File: 20XXX_XX.M Current
	Recall Channel File: 20XXX_XX.M Data: Current


- Panel operation
1. Insert a USB flash drive into the front panel USB slot. 
 2. Ensure the USB path has been set. Page 240.
 3. Press the File key. 
 4. Press F1 repeatedly until the Media USB menu appears. 



Save all Channels 5. Use the Selector knob to edit Save Chan and Data Type.




6. Choose All, and Memory



The screen updates to show Save Folder. Note it is not possible to recall all channels at once, only save.

7. Use the Selector Knob to edit Save Folder.




8. Choose a directory name (ALL0000 ~ ALL0099).



Note

Any used directories will not be available. It is not possible to over-write older directories. They must be deleted first.


9. Press F3 (Save)




10. A screen message will be displayed when complete.

ALL0003 Save Ok

Save /Recall File 11. Use the Selector Knob to edit Save Chan and Data Type.




12. Choose Current and Memory.



13. Use the selector knob to edit Save or Recall File.

14. Choose a file name.

15. Press F3 (Save) to save or F4 (Recall) to recall the current channel memory.




16. A save or recall message will be displayed when complete.


2030L_00.M Save Ok
2030L_00.M Recall Ok

Recall File from USB path

17. Press F5 (File Utility).
18. Use the selector knob to select path for saving memory. usb:\ALLXXXX\File: 2XXXX_XX.M



19. Press the selector knob, Enter or F1
20. A recall message will be displayed when complete.



Remember only data that has been saved to internal memory will be saved to USB. Only the active channel will be saved.

If you try to recall data that originated from a different load module than the active channel, an error message will appear. The filename must reflect the active channel's load module type.

Machine Type Error

Saving/Recalling Presets to USB

Background	<p>There are two options to save or recall Channel Presets to a USB flash drive:</p> <p>Save Chan Current: Saves the active Channel's Presets (P0~P9) into the root directory (20XXX_XX.P). Press F5 (File Utility) to select the directory to save.</p> <p>Save Chan All: Every channel's Presets (CH1 P0~P9 ~ CH8 P0~P9) will be saved into a directory (ALL00XX) as separate files for each channel (P0X0X_C1.P ~ P0X0X_C8.P)</p> <p>Recall: Recalls the selected file to the active channel's Presets (P0~P9). It is not possible to update all the channels at once, only one channel at a time can be recalled.</p> <p>The file extension *.P is used for channel Presets only.</p> <p>For more information about the file structures see page 91.</p>
------------	--

Parameter	Save Channel Data: All	Directory: ALL0000 ~ ALL0099 File: P0X0X_CX.P
	Save Channel Data: Current	File: 20XXX_XX.P
	Recall Channel Data: Current	File: 20XXX_XX.P

Panel operation

1. Insert a USB flash drive into the front panel USB slot.




2. Ensure the USB path has been set. Page 240.

3. Press the File key.




4. Press F1 repeatedly until the Media USB menu appears.




Save all Channel Presets

5. Use the Selector knob to edit Save Chan and Data Type.




6. Choose All, and Preset





The screen updates to show Save Folder. Note it is not possible to recall all presets at once, only save.


7. Use the Selector Knob to edit Save Folder. 
8. Choose a directory name (ALL0000 ~ ALL0099).



Note

Any used directories will not be available. It is not possible to over- write older directories. They must be deleted first.


9. Press F3 (Save)




10. A screen message will be displayed when the save is complete.

ALL0001 Save Ok


11. Use the Selector Knob to edit (current channel) Save Chan and Data Type.



12. Choose Current and Preset.




13. Use the selector knob to edit Save File or Recall file.



14. Choose a file name.

15. Press F3 (Save) to save or F4 (Recall) to recall the Channel Presets.




16. A message will be displayed when the save or recall has completed.

2020L_01.P Save Ok
2020L_01.P Recall Ok

Recall File from USB path

17. Press F5 (File Utility).
18. Use the selector knob to select path for saving preset. usb:\ALLXXXX\File: 20XXX_XX.P



19. Press the selector knob, Enter or F1.
20. A recall message will be displayed when complete.



Remember only data that has been saved to internal memory will be saved to USB. Only the active channel presets will be saved.

If you try to recall data that originated from a different load module than the active channel, an error message will appear. The filename must reflect the active channel's load module type.

Machine Type Error

Saving/Recalling Sequences to USB

Background There are two options to save or recall Sequences to a USB flash drive. Sequences can either be saved from all channels or from the current channel only.

Save All: Every channels' sequences will be saved into a directory (ALL00XX) as separate files for each channel (20XXX_C1.A~ 20XXX_C8.A).




Save Current: The current channel's sequence will be saved into the root directory (20XXX_XX.A). Press F5 (File Utility) to select the directory to save.


Recall: Sequences can only be recalled for the current channel. It is not possible to recall all channels' Sequences at once.


The file extension *.A is used for Sequences only.



For more information about the file structures see page 91.

Parameters	Save Channel Data:Directory: ALL0000 ~ ALL0099
	All File: 20XXX_CX.A
	Save Channel Data:File: 20XXX_XX.A
Current	
Recall Channel	File: 20XXX_XX.A
Data: Current	


- Panel operation
1. Insert a USB flash drive into the front panel USB slot.  
 2. Ensure the USB path has been set. Page 240.
 3. Press the File key. 

4. Press F1 repeatedly until the Media USB menu appears. 




- Save all Channel SEQ
5. Use the Selector knob to edit Save Chan and Data Type.  
 6. Choose All, and Sequence





The screen updates to show Save Folder. Note it is not possible to recall all Sequence data at once, only save.

7. Use the Selector Knob to edit Save Folder. 
8. Choose a directory name (ALL0000~ALL0099).

Save Folder ALL0000



Note

Any used directories will not be available. It is not possible to over-write older directories. They must be deleted first.

9. Press F3 (Save)


F3

10. A screen message will be displayed when saving.


Save All Chan in ALL0000

Save/Recall SEQ
(current channel)

11. Use the Selector Knob to edit Save Chan and Data Type.



12. Choose Current and Sequence.



13. Use the selector knob to edit Save File or Recall File.

14. Choose a file name.

15. Press F3 (Save) to save or F4 (Recall) to recall the current channel's sequence.




16. A message will be displayed when the file is saved/recalled.

2030L_01.A Save OK
2030L_01.A Recall OK


Recall File from USB path

17. Press F5 (File Utility).

18. Use the selector knob to select path for saving sequence. usb:\ALLXXXX\File: 20XXX_XX.A



19. Press the selector knob, Enter or F1.
20. A recall message will be displayed when complete.



Note

Remember a sequence must first be saved to (internal) buffer before it can be saved to USB.

If you try to recall data that originated from a different load module than the active channel, an error message will appear. The filename must reflect the active channel's load module type.

Machine Type Error


Quick Preset Recall/Save

Background The PEL-2000B series mainframes have up to 10 Channel Presets (P0~P9). Quick recalling or saving presets will only be applicable to the active channel. For example, P1 on CH1 is not the same as P1 on CH2.

Parameter Presets P0 ~ P9 (current channel)


Panel Operation 1. Remove any USB devices from the front panel.
 2. Select the channel you want to save Channel Presets to. Page 123.

Save Current Channel Preset 3. To save a Channel Preset, press the Preset key and hold one of the number keys (0-9) for a short time until a beep is heard.




0 = P0
1 = P1 etc.

Save All Channel Presets 4. To save All Channel Presets, press the Shift key, the Preset key and hold one of the number keys (0-9) for a short time until a beep is heard.






0 = P0
1 = P1 etc.

5. Press the Preset key again to deactivate it.



The Preset will be saved to the one of 10 presets depending on the number pressed.

Recall Current Channel Preset	6. Press the Preset key and one of the number keys.	
	0 = P0 1 = P0 etc.	
	Only the current Channel preset will be recalled.	
Recall All Channel Presets	7. Press the Shift key, the Preset key and one of the number keys.	
	0 = P0 1 = P0 etc.	
	8. Press the Preset key again to deactivate it.	

Recall Setup Memory (Frame link).

Background A master mainframe can command all mainframes (master and slave) to recall setup memory from their internal memory. No setup data will be recalled from the master mainframe to the slave units.

Parameter Setup memory 1~4.

Panel Operation 1. On the Master mainframe, follow Page 237 the procedure for recalling setup memory for all channels.

All mainframes will update setup memory upon recall.



Note

It is necessary to save setup data before recalling both master and slave. If the setup data is not saved first, there will be no value change after recalling.

Recall Preset Memory (Frame link)

Background A master mainframe can command all units to recall preset memory from their internal memory. Only the first three preset memories (P0~P2) can be recalled.


Channel presets can be recalled via the file menu or using the quick recall feature using the number pad.

Parameters Presets P0 ~ P2 (current channel)

Panel Operation: 1. Remove any USB devices from the front panel.

Quick Keys

2. On the master mainframe, press the Shift and Preset key.



3. Press one of the number keys (0-2).



0 = P0

1 = P1 etc

The screen will flash momentarily when the presets are recalled.

Panel Operation: 4. On the master mainframe follow the procedure to recall preset memory for all channels. Page 236

File menu

The screen will flash momentarily when the presets are recalled.



Note

It is necessary to save preset data before recalling both master and slave. If preset data is not saved first, the value after recalling will be the factory default setting.


Recall Factory/User's Defaults

Background The Factory/User's defaults can be saved or recalled at any time. For details on the factory defaults please see the default settings in the appendix, page 299

Panel Operation 1. Press the File key.




2. Press F1 repeatedly until the Media Default menu appears.




3. Press Factory Default (F2) to recall the factory default settings.






4. Press F2 again to ensure recall factory default setting F2




5. Wait a short time for the settings to be recalled.
6. Press Save (F3) to save the user's default. F3



7. Press Save (F3) again to ensure save the user's default.


F3

8. Wait a short time for the settings to be saved.




9. Press Recall (F4) to recall the user's default.


F4



10. Press Recall (F4) to ensure recall the user's default



11. Wait a short time for the settings to be saved.



I NTERFACE

The Interface chapter details the pin configuration of the RS232 or RS485, LAN, GPIB, Frame Link, Channel Control and Go/NoGo interfaces.

Interface Configuration	270
Configure GPIB interface	270
Configure Channel Control interface.....	272
Configure Frame Link Interface	274
Configure Go/NoGo Interface	277
USB Interface Connection	278
RS232 or RS485 Interface Configuration.....	279
Set the UART settings	282
Multiple Unit Connection	284
LAN Interface Configuration.....	286


Interface Configuration

Configure GPIB interface


Interface function codes The interface function codes for the Electronic Load are listed as the following table.

Code	Interface function
SH1	Source Handshake capability
AH1	Acceptor Handshake capability
T5	Talker (basic talker, serial poll, unaddressed to talk on LAG)
L4	Listener (basic listener, unaddressed to listen on LAG)
SR1	Service Request capability
RL0	No Remote/Local capability
PP0	No Parallel Poll capability
DC1	Device Clear capability
DT0	No Device Trigger capability
C0	No Controller capability
E1	Open collector bus drivers
TE0	No Extended Talker capability
LE0	No Extended Listener capability

Connection Connect the GPIB cable to the rear panel port: 24-pin female connector.



Pin assignment





Pin1	Data line 1	Pin13	Data line 5
Pin2	Data line 2	Pin14	Data line 6
Pin3	Data line 3	Pin15	Data line 7
Pin4	Data line 4	Pin16	Data line 8
Pin5	EOI	Pin17	REN
Pin6	DAV	Pin18	Ground
Pin7	NRFD	Pin19	Ground
Pin8	NDAC	Pin20	Ground
Pin9	IFC	Pin21	Ground
Pin10	SRQ	Pin22	Ground
Pin11	ATN	Pin23	Ground
Pin12	Shield (screen)	Pin24	Signal ground

- GPIB constraints
- Maximum 15 devices altogether, 20m cable length, 2m between each device
 - Unique address assigned to each device
 - At least 2/3 of the devices turned On
 - No loop or parallel connection

Configure Channel Control interface

Channel control configuration	Connector	Screwless connector.
	Wire Gauge	22-28 AWG (24 AWG recommended).
	Wire connection	10 mm strip gauge for connection.




	Input	0-10V.
Pin Assignment		
	1 GND	Negative potential of the load input terminal.
	2 I MON (OUTPUT)	Load input current monitor; where 0V = 0% of input current and 10V = 100% of input current.
	3 V MON (OUTPUT)	Load input voltage monitor; where 0V = 0% of input voltage and 10V = 100% of input voltage.
	4 Ext Voltage ref (INPUT)	External voltage reference; Where 0V=0% of rating voltage/current and 10V = 100% of rating voltage/current. The external voltage reference is for CC and CV mode.

5 Load On


Load On Input.

Load on = Active low.

Load off = Active high. (Pin 5 of the connector is internally pulled up to 3.3V with a 10kΩ resistor when the switch is open. Thus when the switch is open, pin 5 is logically high. When the switch is closed, pin 5 is pulled down to the GND ground level, making pin 5 logically low)



The Load On/Off determines whether the external switch is closed (low) or open (high)



6 +15V


Internal power output. Max 50mA.

Channel Control Mode/Range Interface Constraints


Mode and Range configuration is only selected via the front panel.

Configure Frame Link Interface

Connection Connect the Frame link cable (MIL 20 pin connector) to the rear panel port: 20-pin male connector.




Pin assignment
(Frame link connector 1)



Pin number	Pin name	Description
Pin1	A	Input, Recall Preset memory 0 (All channels)
Pin2	B	Input, Recall Preset memory 1 (All channels)
Pin3	C	Input, Recall Preset memory 2 (All channels)
Pin4	TRIG_IN	Trigger input
Pin5	MEM_1	Input, Recall Setup memory 1 (All channels)
Pin6	MEM_2	Input, Recall Setup memory 2 (All channels)
Pin7	MEM_3	Input, Recall Setup memory 3 (All channels)
Pin8	MEM_4	Input, Recall Setup memory 4 (All channels)
Pin9	Enable	Input, Enable Load (On/Off), recall Preset memory (0-2) and Setup memory (1-4)

Pin10	Load On/Off	Input, Load On/Off
Pin11	N.C	No connection
Pin12	N.C	No connection
Pin13	N.C	No connection
Pin14	N.C	No connection
Pin15	Load Status	Output, load on status.
Pin16	Alarm Status	Output, alarm activated.
Pin17	+5V	Power source output, +5V, 100mA.
Pin18	N.C	No connection.
Pin19	GND	Ground
Pin20	GND	Ground

Pin assignment
(Frame link
connector 2)




Pin number	Pin name	Description
Pin1	Sync._A	Output, Sync signal, Recall Preset memory 0 (All channels)
Pin2	Sync._B	Output, Sync signal, Recall Preset memory 1 (All channels)
Pin3	Sync._C	Output, Sync signal, Recall Preset memory 2 (All channels)
Pin4	TRIG_OUT	Trigger output


Pin5	Sync._MEM_1	Output, Sync signal, Recall Setup memory 1 (All channels)
Pin6	Sync._MEM_2	Output, Sync signal, Recall Setup memory 2 (All channels)
Pin7	Sync._MEM_3	Output, Sync signal, Recall Setup memory 3 (All channels)
Pin8	Sync._MEM_4	Output, Sync signal, Recall Setup memory 4 (All channels)
Pin9	Sync._Enable	Output, Sync signal, Enable Load (On/Off), recall Preset memory (0- 2) and Setup memory (1-4)
Pin10	Sync._Load On/Off	Output, Sync signal, Load On/Off
Pin11	N.C	No connection
Pin12	N.C	No connection
Pin13	N.C	No connection
Pin14	N.C	No connection
Pin15	Load Status	Output, load on status.
Pin16	Alarm Status	Output alarm activated.
Pin17	N.C	No connection
Pin18	+5V	Power source output, +5V, 100mA
Pin19	GND	Ground
Pin20	GND	Ground

Explanation

- Input: active low (0-1V)
active high (4-5V)

 Note Input type is internally pulled up to 5V with a 10kΩ resistor.

- Output: high (floating)
low (0-1V)

 Note Output type is internally Open collector outputs, maximum 30VDC with 1.1V saturation voltage (100mA).

- When Enable (pin9) is on (active low), the following is disabled from the mainframe: Load On/Off (pin 10) activating loads and recalling preset (pin 1-3) or setup memory (pin 5-8).


Frame Link constraints

- Maximum 5 (1 master + 4 slave units) devices can be linked altogether with a maximum cable length of 30cm for each cable.
- All the connected devices must be turned on.
- No loop or parallel connections


Configure Go/NoGo Interface

Connection Use a DSUB (DB-15 Female) connector to connect to the Go/NoGo port.

The Go/NoGo port is an output only port.



Pin assignment



Pin1	Ch1_GO/NG	Pin9	Ch5_GO/NG
Pin2	GND	Pin10	GND
Pin3	Ch2_GO/NG	Pin11	Ch6_GO/NG
Pin4	GND	Pin12	GND
Pin5	Ch3_GO/NG	Pin13	Ch7_GO/NG
Pin6	GND	Pin14	GND
Pin7	Ch4_GO/NG	Pin15	Ch8_GO/NG
Pin8	GO/NG_Enable		

Connection Type Open collector output maximum 30VDC with 1.1V saturation voltage (100mA).

30 V DC (high)	Pass (Go) or SPEC Test: OFF
----------------	--------------------------------

1.1 V DC (low)	Fail (NoGo)
----------------	-------------

USB Interface Connection

Connection For USB remote connection, use the USB-B port on the mainframe front panel.





RS232 or RS485 Interface Configuration


RS232 or RS485 configuration	Connector	RJ45
	Baud rate	2400/4800/9600/19200/38400/57600/115200
	Data bits	7bits/8bits
	Stop bit	1bit/2bits
	Parity	None, Odd, Even
	Address	0 ~ 30 [This is available when Mode is RS485]

Panel operation

1. Press the Shift Key then the Help key to access the Utility menu.
2. Press the Shift Key then the Help key to access the Utility menu.



3. If the interface is not set to RS232, use the selector knob to change the interface to RS232.




- Edit the Baud rate, Stop bit and parity.

Baud rate 2400, 4800, 9600, 19200, 38400,
57600,115200

Stop Bit 1,2

Parity None, Odd, Even

- Use the selector knob to change the interface to RS485



- Edit the Baud rate, Stop bit and parity.

Baud rate 2400, 4800, 9600, 19200, 38400,
57600,115200


Stop Bit 1,2

Parity None, Odd, Even

Data Bits 7bits, 8bits

UART Address 0 ~ 30

- Connect the RS-232C to RJ45 cable to the rear panel port: RJ45 female connector.




Terminal application	<p>Invoke a terminal application such as MTTY (Multi-Threaded TTY).</p> <ul style="list-style-type: none">• For RS-232C, set the COM port, baud rate, stop bit, data bit, and parity accordingly. <p>To check the COM port No. for RS-232C, see the Device Manager in the PC. For Win XP, Control panel → System → Hardware tab.</p> <p>8. Ensure the terminal application has the following settings;</p> <p>Baud rate - as per PEL-2000B settings</p> <p>Com Port - as per PC settings (Device Manager)</p> <p>Parity - None</p> <p>Data bits - 8</p> <p>Stop bits - None</p>
Functionality check	<p>Run this query command via the terminal.</p> <pre>*idn?</pre> <p>This should return the Manufacturer, Model number, Serial number, and Firmware version in the following format.</p> <p>GW, PEL-2002B/2004B, 00000001, V3.01</p>

Set the UART settings

Overview The PEL-2000B series uses the IN & OUT ports for UART communication coupled with RS232 (GW Instek Part number: GTL-259) or RS485 adapters (GW Instek part number: GTL-260).

The pin outs for the adapters are shown below.


RS232 cable with DB9 & RJ-45 shielded connectors from GTL-259 connection kit	DB-9 Connector		Remote IN Port		Remarks
	Pin No.	Name	Pin No.	Name	
	Housing	Shield	Housing	Shield	
	2	RX	7	TX	Twisted pair
	3	TX	8	RX	
	5	SG	1	SG	



Connection diagram




RS485 cable with DB9 & RJ-45 shielded connectors from GTL-260 connection kit	DB-9 Connector		Remote IN Port		Remarks
	Pin No.	Name	Pin No.	Name	
	Housing	Shield	Housing	Shield	
	9	TXD -	6	RXD -	Twisted pair
	8	TXD +	3	RXD +	
	1	SG	1	SG	
5	RXD -	5	TXD -	Twisted pair	
4	RXD +	4	TXD +		



Connection diagram



Diagram of Intermediate connector



Intermediate connector from GTL-259 or GTL-260 connection kit.	Intermediate connector					
	8 Pin (Male)			8 Pin (Female)		
	Pin No.	Name		Pin No.	Name	Remarks
	Housing	Shield	↔	Case	Shield	
	1	SG	↔	1	SG	
	6	TXD -	↔	6	TXD -	Internal paralleled by 120 ohm
	3	TXD +	↔	3	TXD +	
	5	RXD -	↔	5	RXD -	Internal paralleled by 120 ohm
	4	RXD +	↔	4	RXD +	


Diagram of End terminal connector



End terminal connector from GTL-259 or GTL-260 connection kit.	End terminal connector	
	8 Pin Connector	
	Pin No.	Remarks
3	Internal shorted	
7		
4	Internal shorted	
8		

Multiple Unit Connection

The PEL-2000B can have up to 16 units daisy-chained together using the 8 pin connectors (IN OUT ports) on the rear panel. The first unit in the chain is remotely connected to a PC using RS485. Each subsequent unit is daisy-chained to the next using a RS485 local bus. The OUT port of the first unit must be connected to intermediate connector and the OUT port of the last unit must be connected to end terminal connector.



Each unit is assigned a unique address and can then be individually controlled from the host PC.


Operation



1. Connect the first unit's IN port to a PC using RS485 serial cable. Use the serial cables supplied in the GTL-260 connection kit.

2. Plug in intermediate connector to the OUT port on the first unit then using the slave serial link cable (black plug) to connect intermediate connector to the IN port of the second unit.

Terminate the OUT port of the last unit with the end terminal connector included in the GTL-260 connection kit.

3. Power up all units.



4. Press the Shift Key then the Help key to access the Utility menu. 
5. Press F3 and set the *Interface* setting to UART> *Mode* and set the Mode to RS485. 
6. Set the addresses and mode of all units using UART menu. It must be a unique address identifier and mode select is RS485.


11/17/22	RS485
16 : 50	LOAD
Mode	RS485
Baud rate	115200
Data Bit	8 Bit
Parity	NONE
Stop bit	1
Address	01
System Info	Load
	Interface
	Time Set
	Other

7. Multiple units can be operated using SCPI commands now. See the programming manual or see the function check below for usage details.


LAN Interface Configuration

Panel operation


1. Press the Shift Key then the Help key to access the Utility menu.




2. Press F3 (Interface Menu).



3. If the interface is not set to Ethernet, use the selector knob to change the interface to Ethernet.




4. Choose Ethernet. Confirm that connection status turn form Offline to Online



5. Check if indicator “Ethernet” turns in green and connection status becomes online status.

05/04/22 16 : 50		LOAD	Ethernet
Interface	Ethernet		
Connection status	Online		
MAC	24-22-00-D7-BA-CB		
DHCP	ON		
IP Address	172. 16. 5. 111		
Subnet Mask	255. 255. 128. 0		
System Info	Load	Interface	Time Set Other

6. Connect the LAN RJ45 connector to the RJ45 female socket on the rear panel.



FAQ

Q1. The load voltage indicated on the load module is below expected.

A1. Ensure the load leads are as short as possible, twisted and use the appropriate wire gauge. Ensure that voltage sense is used, this can help alleviate the voltage drop across the load the leads.

Q2. When I try to start a program sequence, it will not run. “No Active Channel” is displayed.

A2. Ensure the channel(s) is activated (not set to OFF) in the FUNC→Program→Active Channel menu.

Q3. When trying to save to USB, the USB memory stick is unresponsive.

A3. Try restarting the PEL-2000B mainframe. If this fails to solve the problem, ensure the USB memory is cleanly formatted.

Q4. When I try to clear an alarm, it doesn't work.


A4. Before clearing an alarm or using the Protection Clear All function, the DUT must be turned off. After the DUT is off, the alarm(s) can be cleared.

For more information, contact your local dealer.


A PPENDIX

Fuse Replacement

- Step
1. Turn off the power at the wall socket and rear panel. Remove the power cord.
 2. Remove the fuse socket using a minus driver.



3. Replace the fuse in the holder.



Rating T3.15A, 250V

Firmware Update

Background The PEL-2000B firmware can be easily updated using a USB memory stick. For the latest firmware please see your local GW Instek distributor

File Name File: P2KAXXXX.P2K



Note

Copy the firmware file (*.P2K) into the root directory of a USB stick before proceeding with the firmware update.



WARNING

Do not turn the power off or remove the USB memory when the firmware is being read or upgraded.



Note

If your Master is PEL-2004A/ PEL-2002A, the mainframe firmware version must be V3.01.UPG or above.

The firmware file and upgrade procedure can be downloaded on the GWInstek website.

Panel operation 1. Insert a USB flash drive into the front panel USB slot.

2. Press the File key.




3. Press F1 repeatedly until the Media USB menu appears.



4. Press F5 (File Utility).



- Use the selector knob to scroll down to the firmware file (*.P2K) and press the selector knob, Enter or F1.



- Press F1 to confirm the firmware upgrade.



- Wait for the firmware upgrade to finish, a message will be displayed upon completion.

- Turn the power Off.




Recall Factory Default

- Turn the power On.

- Press the File key.




- Press F1 repeatedly until the Media Default menu appears.





- Press Factory Default (F2) to recall the factory default settings.



- Firmware updating process is complete and you can use the device now.



- Press F2 again to ensure recall factory default setting



- Wait a short time for the settings to be recalled.


Calibration

Background The PEL-2000B series load modules should be calibrated at least on a yearly basis.


GW Instek does not support End-User calibration. Please see your distributor for calibration details.

Range Chart


PEL-2020B Low Range 10W




PEL-2020B High Range 100W




PEL-2020B CV Low Range




PEL-2030B (L)
High range 30W




PEL-2030B (L)
CV Low Range




PEL-2030B (R)
Low Range 25W




PEL-2030B (R)
High Range
250W




PEL-2030B (R)
CV Low Range




PEL-2040B Low
Range 35W




PEL-2040B High Range 350W




PEL-2040B CV Low Range




PEL-2041B Low Range 35W



PEL-2041B High Range 350W



PEL-2041B CV Low Range



Default Settings

Menu Item		
CC Mode	Range: High A/B Value: Min A Falling Slew Rate: Max	Mode: Static Rising Slew Rate: Max
CR Mode	Range: High A/B Value: Max Ω Falling Slew Rate: Max	Mode: Static Rising Slew Rate: Max
CV Mode	Range: High A/B Value: Max V Curr Limit: Max A	Response: Slow I Meas: High
CP Mode	Range: High Curr Limit: Max A	A/B Value: Min W
CHAN-Protection	OCP Level: Max OVP Level: Max OPP Level: Max UVP Level: OFF Protection Clear: All	OCP Setting: OFF OVP Setting: OFF OPP Setting: OFF UVP Setting: Clear
CHAN- Other	CC Vrange: High Von Latch: OFF Independent: OFF Response: Fast CCL Step: Min CRL Step: Min CVL Step: Min CPL Step: Min Short Key: Toggle	Von Voltage: 0V CH CONT: Panel Load D-Time: 0.0s CCH Step: Min CRH Step: Min CVH Step: Min CPH Step: Min Short Function: ON Short Safety: ON

CHAN-Group	Total Units: OFF Display Mode: V,I	Group Mode: Para
CHAN- Seq. Edit	NO.: 001 Rising/Falling SlewRate: Max	Value: Min Duration Time: 0.000025s
CHAN- Seq. Edit - Loop	Repeat: Infinity Times On End Of Seq.: OFF A (CC mode) OFF Ω/OFF KΩ (CR mode)	Start of Loop: 001 Point CC Vrange: High
CHAN- Go/NoGo	SPEC Test: OFF Entry Mode: Value Low: Min	Delay Time: 0.0 s High: Max
FUNC- Program	PROG: 01 Memory: M001 On-Time: 0.1 P/F-Time: Off Short Channel: All channels	SEQ: 01 Run: Skip Off-Time: Off Short-Time: Off
FUNC- Program Chain	Start: P01	P01~P12→: Off
FUNC- Program- Active Channel	CH 01~08: Active: OFF	Prog: Off
FUNC- Sequence	Seq.: Off TRIG: CH1: OUT Setting: CH01~CH08: OFF	TRIG In: Off TRIG: CH2~08: OFF
FUNC- OCP	OCP: Off Range: High End C: Setting Range Max Last_C: Min Delay: Min	Chan: 1 Start C: Min Step_C: Min Step_T: Min Trig_V: Min

	Keep_T: Min	
FUNC- OCP- Active Channel	CH 01~08: Active: OFF	
FILE- Memory	Channel Data: Current Memory: M001	Data Type: Memory
FILE- USB	Channel Data: Current Save File: No File	Data Type: Memroy Recall File: No File
UTILITY- Load	Auto Load: OFF	Auto Load On: Prog
UTILITY - Interface	USB	
UTILITY - Other	Speaker: OFF Brightness: 70 Alarm (M): ON Knob Type: Updated Slave Knob: SetValue High Resolution: ON Von Latch Clear: Auto Jog Shuttle Control: OFF	Contrast: 8 Frame CONT: OFF Alarm (S): OFF Go_NoGo Tone: OFF Language: English System Mode: 0 Measure Period: 200ms RVP Load Off: OFF

Specifications

The specifications apply when the PEL-2000B series is powered on for at least 30 minutes to warm-up to a temperature of 25°C ± 5°C, unless specified otherwise.

	PEL-2002B	PEL-2004B
MODULE SLOTS	2	4

GENERAL

Operating Environment

Temperature	0°C to 40°C
Relative Humidity	0 to 85% RH
Altitude	Up to 2000m
Location	Indoor, no direct sunlight, dust free, almost non conductive pollution.

Storage Environment

Temperature	-10°C to 70°C
Relative Humidity	< 90% RH
Location	Indoor

Power Supply	AC input voltage range: 100-120Vac / 200-240Vac (90-132Vac / 180-250Vac) Frequency: 47~63Hz Power rating: PEL-2004B: 250VA Max PEL-2002B: 150VA Max Transient overvoltage on the main supply is 2500V.
--------------	---

Fuse	T3.15A/250V
Pollution degree	2
Measurement	1
Category	
Rear panel USB class	USB 2.0 full speed (CDC-ACM)
Weight	Approx. 17.1kg (Full modules) Approx. 28.4kg (Full modules)

PEL-2020B (100Wx2)

	Low	High
RANGE		
CURRENT	0~2A	0~20A
VOLTAGE	0~80V	
MIN.OPERATING	0.4V at 2A	0.8V at 20A
VOLTAGE(dc)Typ.)	0.2V at 1A	0.4V at 10A

STATIC MODE

CONSTANT CURRENT MODE

Operating Range	0~2A	0~20A
Setting Range	0~2.04A	0~20.4A
Resolution	0.1mA	1mA
Accuracy	$\pm(0.1\%set + 0.1\%F.S.^{*1})$	$\pm(0.1\%set + 0.2\%F.S.)$

CONSTANT RESISTANCE MODE

Operating Range	0.075 Ω ~300 Ω (100W/16V) 3.75 Ω ~15k Ω (100W/80V)
Setting Range	0.075 Ω ~300 Ω (100W/16V) 3.75 Ω ~15k Ω (100W/80V)
Resolution ^{*2}	0.333ms(100W/16V) 6.667 μ s(100W/80V)
Accuracy ^{*3}	300 Ω : $\pm(0.2\%set + 0.1S)$ 15k Ω : $\pm(0.1\%set + 0.01S)$

CONSTANT VOLTAGE + CONSTANT CURRENT MODE

Operating Range	1~16V	1~80V
Setting Range	0~16.32V	0~81.6V
Resolution	0.4mV	2mV
Accuracy	$\pm(0.05\%set + 0.1\%F.S.)$	
Current Setting Range	0~2.04A	0~20.4A
Resolution	0.1mA	1mA
Accuracy	$\pm(0.1\%set + 0.1\%F.S.^{*1})$	$\pm(0.1\%set + 0.2\%F.S.^{*1})$

CONSTANT POWER + CONSTANT CURRENT MODE

Operating Range	1~10W	1~100W
Setting Range	0~10.2W	0~102W
Resolution	1mW	10mW
Accuracy	$\pm(0.5\%set + 0.5\%F.S.^{*1})$	$\pm(0.5\%set + 0.5\%F.S.)$
Current Setting Range	0~2.04A	0~20.4A
Resolution	0.1mA	1mA
Accuracy	$\pm(0.1\%set + 0.1\%F.S.^{*1})$	$\pm(0.1\%set + 0.2\%F.S.^{*1})$

NOTE : ^{*1} F.S. = Full scale of H Range

^{*2} S (Siemens) is the unit of conductance, equal to one reciprocal ohm.

^{*3} Accuracy must be calculated in conductivity units.

DYNAMIC MODE

T1&T2	0.025ms ~ 10ms / Res: 1μs 10ms ~ 30s / Res: 1ms	
Accuracy	1us / 1ms ± 100ppm	

CONSTANT CURRENT MODE

Slew Rate	0.32 ~ 80mA/μs	3.2 ~ 800mA/μs
Slew Rate	0.32mA/μs	3.2mA/μs
Resolution		
Slew Rate Setting	±(10% + 15μs)	
Accuracy		
Current Setting	0~2.04A	0~20.4A
Range		
Current	0.1mA	1mA
Resolution		
Current Accuracy	±0.4% F.S.	

CONSTANT RESISTANCE MODE

Slew Rate	3.2 ~ 800mA/μs	
Slew Rate	3.2mA/μs	
Resolution		
Slew Rate Setting	±(10% + 50μs)	
Accuracy		
Resistance	0.075Ω~300Ω(100W/16V)	
Setting Range	3.75Ω~15kΩ(100W/80V)	
Resistance	0.333ms(100W/16V)	
Resolution	6.667μs(100W/80V)	
Resistance	300Ω: ±(0.5%set + 0.1S)	
Accuracy	15kΩ: ±(0.5%set + 0.01S)	

MEASUREMENT

VOLTAGE READBACK

Range	0~16V	0~80V
Resolution	0.32mV	1.6mV
Accuracy	±(0.025% read + 0.025% F.S.)	

CURRENT READBACK

Range	0~2A	0~20A
Resolution	0.04mA	0.4mA
Accuracy	±(0.05% read + 0.05% F.S. *2)	

POWER READBACK

Range	0~10W	0~100W
Accuracy	±(0.1% read + 0.1% F.S. *1)	

NOTE : *1 Power F.S. = Vrange F.S. x Irange F.S.

*2 F.S. = Full scale of H Range

PROTECTIVE

Over Power Protection

Range	1~102W
Resolution	0.5W
Accuracy	$\pm(2\% \text{ set} + 0.25\% \text{ F.S.})$

Over Current Protection

Range	0.25~20.4A
Resolution	0.05A
Accuracy	$\pm(2\% \text{ set} + 0.25\% \text{ F.S.})$

Over Voltage Protection

Range	1~81.6V
Resolution	0.2V
Accuracy	$\pm(2\% \text{ set} + 0.25\% \text{ F.S.})$

Over $\cong 85^{\circ}\text{C}$ Temperature
Protection

Rated Power Protection(CPP)

Value	110W
Accuracy	$\pm 5\% \text{ set}$

GENERAL

SHORT CIRCUIT

Current(CC)	$\cong 2.2/2\text{A}$	$\cong 22/20\text{A}$
Voltage(CV)	$\cong 0\text{V}$	
Resistance(CR)	$\cong 3.75\Omega$	$\cong 0.075\Omega$

Input Resistance 500k Ω (Typical)

(Load OFF)

Temperature 100ppm/ $^{\circ}\text{C}$

Coefficient

Weight Approx. 3.8kg

PEL-2030B (30W/250W)

RANGE	High	Low	High
CURRENT	0~5A	0~4A	0~40A
VOLTAGE	0~80V		
MIN.OPERATING	0.8V at 5A	0.4V at 4A	0.8V at 40A
VOLTAGE(dc)	0.4V at 2.5A	0.2V at 2A	0.4V at 20A

STATIC MODE

CONSTANT CURRENT MODE

Operating Range	0~5A	0~4A	0~40A
Setting Range	0~5.1A	0~4.08A	0~40.8A

Resolution	0.125mA	0.1mA	1mA
Accuracy	±(0.1%set + 0.1%F.S.)	±(0.1%set + 0.1%F.S.*1)	±(0.1%set + 0.2%F.S.)

CONSTANT RESISTANCE MODE

Operating Range	0.3Ω ~1.2kΩ (30W/16V) 15Ω ~60kΩ (30W/80V)	0.0375Ω ~150Ω(250W/16V) 1.875Ω ~7.5kΩ(250W/80V)	
Setting Range	0.3Ω~1.2kΩ (30W/16V) 15Ω~60kΩ (30W/80V)	0.0375Ω ~150Ω(250W/16V) 1.875Ω ~7.5kΩ(250W/80V)	
Resolution*2	83.333μs (30W/16V) 1.666μs (30W/80V)	0.666ms(250W/16V) 13.333μs(250W/80V)	
Accuracy*3	1.2kΩ: ± (0.2%set + 0.1S) 60kΩ: ± (0.1%set + 0.01S)	150Ω: ±(0.2%set + 0.1S) 7.5kΩ: ±(0.1%set + 0.01S)	

CONSTANT VOLTAGE + CONSTANT CURRENT MODE

Operating Range	1~16V 1~80V	1~16V	1~80V
Setting Range	0~16.32V 0~81.6V	0~16.32V	0~81.6V
Resolution	0.4mV 2mV	0.4mV	2mV
Accuracy	±(0.05%set + 0.1%F.S.)	±(0.05%set + 0.1%F.S.)	
Current Setting Range	0~5.1A	0~4.08A	0~40.8A
Resolution	0.125mA	0.1mA	1mA
Accuracy	±(0.1%set + 0.2%F.S.)	±(0.1%set + 0.1%F.S.*1)	±(0.1%set + 0.2%F.S.*1)

CONSTANT POWER + CONSTANT CURRENT MODE

Operating Range	1~30W	1~25W	1~250W
Setting Range	0~30.6W	0~25.5W	0~255W
Resolution	1mV	1mV	10mV
Accuracy	±(0.5%set + 0.5%F.S.)	±(0.5%set + 0.5%F.S.*1)	
Current Setting Range	0~5.1A	0~4.08A	0~40.8A
Resolution	0.125mA	0.1mA	1mA

Accuracy	$\pm(0.1\%set + 0.2\%F.S.)$	$\pm(0.1\%set + 0.1\%F.S.^{*1})$	$\pm(0.1\%set + 0.2\%F.S.^{*1})$
----------	-----------------------------	----------------------------------	----------------------------------

NOTE : ^{*1} F.S. = Full scale of H Range

^{*2} S (Siemens) is the unit of conductance, equal to one reciprocal ohm.

^{*3} Accuracy must be calculated in conductivity units.

DYNAMIC MODE

T1&T2	0.025ms ~ 10ms / Res: 1μs 10ms ~ 30s / Res: 1ms
-------	--

Accuracy	1us / 1ms + 100ppm
----------	--------------------

CONSTANT CURRENT MODE

Slew Rate	0.8 ~ 200mA/μs	0.64 ~ 160mA/μs	6.4 ~ 1600mA/μs
-----------	----------------	-----------------	-----------------

Slew Rate	0.8mA/μs	0.64mA/μs	6.4mA/μs
-----------	----------	-----------	----------

Resolution

Slew Rate setting	$\pm(10\% + 15\mu s)$
-------------------	-----------------------

Accuracy

Current Setting	0~5.1A	0~4.08A	0~40.8A
-----------------	--------	---------	---------

Range

Current	0.125mA	0.1mA	1mA
---------	---------	-------	-----

Resolution

Current Accuracy	$\pm 0.4\% F.S.$
------------------	------------------

CONSTANT RESISTANCE MODE

Slew Rate	0.8 ~ 200mA/μs	6.4 ~ 1600mA/μs
-----------	----------------	-----------------

Slew Rate	0.8mA/μs	6.4mA/μs
-----------	----------	----------

Resolution

Slew Rate Setting	$\pm(10\% + 50\mu s)$
-------------------	-----------------------

Accuracy

Resistance	0.3Ω~1.2kΩ	0.0375Ω ~ 150Ω(250W/16V)
------------	------------	--------------------------

Setting Range	(30W/16V)	1.875Ω ~ 7.5kΩ(250W/80V)
---------------	-----------	--------------------------

	15Ω~60kΩ	
--	----------	--

	(30W/80V)	
--	-----------	--

Resistance	83.333μs	0.666ms(250W/16V)
------------	----------	-------------------

Resolution	(30W/16V)	13.333μs(250W/80V)
------------	-----------	--------------------

	1.666μs	
--	---------	--

	(30W/80V)	
--	-----------	--

Resistance	1.2kΩ: $\pm(0.5\%set + 0.1S)$	150Ω: $\pm(0.5\%set + 0.1S)$
------------	-------------------------------	------------------------------

Accuracy	+ 0.1S)	7.5kΩ: $\pm(0.5\%set + 0.01S)$
----------	---------	--------------------------------

	60kΩ: $\pm(0.5\%set + 0.01S)$	
--	-------------------------------	--

	+ 0.01S)	
--	----------	--

MEASUREMENT

VOLTAGE READBACK

Range	0~16V	0~80V	0~16V	0~80V
Resolution	0.32mV	1.6mV	0.32mV	1.6mV
Accuracy	±(0.025% read + 0.025% F.S.)			

CURRENT READBACK

Range	0~5A	0~4A	0~40A
Resolution	0.1mA	0.08mA	0.8mA
Accuracy	±(0.05% read + 0.05% F.S.*2)		

POWER READBACK

Range	0~30W	0~25W	0~250W
Accuracy	±(0.1% read + 0.1% F.S.*1)		±(0.1% read + 0.1% F.S.*1)

NOTE : *1 Power F.S. = Vrange F.S. x Irange F.S.

*2 F.S. = Full scale of H Range

PROTECTIVE

Over Power Protection

Range	0.9~30.6W	1.25~255W
Resolution	0.15W	1.25W
Accuracy	±(2%set + 0.25%F.S.)	

Over Current Protection

Range	0.0625~5.1A	0.5~40.8A
Resolution	0.0125A	0.1A
Accuracy	±(2%set + 0.25%F.S.)	

Over Voltage Protection

Range	1~81.6V
Resolution	0.2V
Accuracy	±(2%set + 0.25%F.S.)

Over Temperature Protection

≒85°C

Rated Power Protection(CPP)

Value	33W	275W
Accuracy	±5%set	

GENERAL

SHORT CIRCUIT

Current(CC)	≒5.5/5A	≒4.4/4A	≒44/40A
Voltage(CV)	≒0V		
Resistance(CR)	≒15Ω	≒0.3Ω	≒1.875Ω
Input Resistance (Load OFF)	500kΩ(Typical)		

≒0.0375Ω

Temperature Coefficient	100ppm/°C
Weight	Approx. 3.8kg

	PEL-2040B		PEL-2041B	
RANGE	Low	High	Low	High
CURRENT	0~7A	0~70A	0~1A	0~10A
VOLTAGE	0~80V		0~500V	
MIN.OPERATING VOLTAGE(dc)Typ.)	0.4V at 7A	0.8V at 70A	1V at 1A	2V at 10A
	0.2V at 3.5A	0.4V at 35A	0.5V at 0.5A	1V at 5A

STATIC MODE

CONSTANT CURRENT MODE

Operating Range	0~7A	0~70A	0~1A	0~10A
Setting Range	0~7.14A	0~71.4A	0~1.02A	0~10.2A
Resolution	0.2mA	2mA	0.05mA	0.5mA
Accuracy	±(0.1%set + 0.1%F.S.*1) ±(0.1%set + 0.2%F.S.) ±(0.1%set + 0.1%F.S.*1) ±(0.1%set + 0.2%F.S.)			

CONSTANT RESISTANCE MODE

Operating Range	0.025Ω~100Ω(350W/16V)	1.25Ω~5kΩ(350W/125V)	1.25Ω~5kΩ(350W/80V)	50Ω~200kΩ(350W/500V)
Setting Range	0.025Ω~100Ω(350W/16V)	1.25Ω~5kΩ(350W/125V)	1.25Ω~5kΩ(350W/80V)	50Ω~200kΩ(350W/500V)
Resolution*2	1mS(350W/16V)	20μS(350W/125V)	20μS(350W/80V)	0.5μS(350W/500V)
Accuracy*3	100Ω: ±(0.2%set + 0.1S)	5kΩ: ±(0.2%set + 0.02S)	5kΩ: ±(0.1%set + 0.01S)	200kΩ: ±(0.1%set + 0.005S)

CONSTANT VOLTAGE + CONSTANT CURRENT MODE

Operating Range	1~16V	1~80V	2.5~125V	2.5~500V
Setting Range	0~16.32V	0~81.6V	0~127.5V	0~510V
Resolution	0.4mV	2mV	2.5mV	10mV
Accuracy	±(0.05%set + 0.1%F.S.) ±(0.05%set + 0.1%F.S.)			
Current Setting Range	0~7.14A	0~71.4A	0~1.02A	0~10.2A
Resolution	0.2mA	2mA	0.05mA	0.5mA
Accuracy	±(0.1%set + 0.1%F.S.*1) ±(0.1%set + 0.2%F.S.*1) ±(0.1%set + 0.1%F.S.*1) ±(0.1%set + 0.2%F.S.*1)			

CONSTANT POWER + CONSTANT CURRENT MODE

Operating Range	1~35W	1~350W	1~35W	1~350W
Setting Range	0~35.7W	0~357W	0~35.7W	0~357W

Resolution	1mW	10mW	1mW	10mW
Accuracy	$\pm(0.5\%set + 0.5\%F.S.^{*1})$	$\pm(0.5\%set + 0.5\%F.S.)$	$\pm(0.5\%set + 0.2\%F.S.^{*1})$	$\pm(0.5\%set + 0.5\%F.S.)$
Current Setting Range	0~7.14A	0~71.4A	0~1.02A	0~10.2A
Resolution	0.2mA	2mA	0.05mA	0.5mA
Accuracy	$\pm(0.1\%set + 0.1\%F.S.^{*1})$	$\pm(0.1\%set + 0.2\%F.S.^{*1})$	$\pm(0.1\%set + 0.1\%F.S.^{*1})$	$\pm(0.1\%set + 0.2\%F.S.^{*1})$

NOTE : ^{*1} F.S. = Full scale of H Range

^{*2} S (Siemens) is the unit of conductance, equal to one reciprocal ohm.

^{*3} Accuracy must be calculated in conductivity units.

DYNAMIC MODE

T1&T2	0.025ms~10ms/Res: 1μs 10ms ~ 30s / Res: 1ms
Accuracy	1us / 1ms ± 100ppm

CONSTANT CURRENT MODE

Slew Rate	0.001 ~ 0.28A/μs	0.01 ~ 2.8A/μs	0.16 ~ 40mA/μs	1.6 ~ 400mA/μs
Slew Rate	0.001A/μs	0.01A/μs	0.16mA/μs	1.6mA/μs
Resolution				
Slew Rate Setting	±(10% + 15us)			
Accuracy				
Current Setting Range	0~7.14A	0~71.4A	0~1.02A	0~10.2A
Current	0.2mA	2mA	0.05mA	0.5mA
Resolution				
Current Accuracy	±0.4% F.S.		±0.4% F.S.	

CONSTANT RESISTANCE MODE

Slew Rate	0.01 ~ 2.8A/μs	1.6 ~ 400mA/μs
Slew Rate	0.01A/μs	1.6mA/μs
Resolution		
Slew Rate Setting	±(10% + 50μs)	
Accuracy		
Resistance Setting Range	0.025Ω~100Ω(350W/16V)	1.25Ω~5kΩ(350W/125V)
Resistance	1ms(350W/16V)	20μs(350W/125V)
Resolution	20μSs(350W/80V)	0.5μs(350W/500V)
Resistance	100Ω: ±(0.5%set + 0.1S)	5KΩ: ±(0.5%set + 0.02S)
Accuracy	5kΩ: ±(0.5%set + 0.01S)	200kΩ: ±(0.5%set + 0.005S)

MEASUREMENT

VOLTAGE READBACK

Range	0~16V	0~80V	0~125V	0~500V
Resolution	0.32mV	1.6mV	2.5mV	10mV
Accuracy	$\pm(0.025\% \text{ read} + 0.025\% \text{ F.S.})$			

CURRENT READBACK

Range	0~7A	0~70A	0~1A	0~10A
Resolution	0.14mA	1.4mA	0.02mA	0.2mA
Accuracy	$\pm(0.05\% \text{ read} + 0.05\% \text{ F.S.}^{*2})$			

POWER READBACK

Range	0~35W	0~350W	0~35W	0~350W
Accuracy	$\pm(0.1\% \text{ read} + 0.1\% \text{ F.S.}^{*1})$			

NOTE : ^{*1} Power F.S. = Vrange F.S. x Irange F.S.

^{*2} F.S. = Full scale of H Range

PROTECTIVE

Over Power Protection

Range	1.75~357W
Resolution	1.75W
Accuracy	$\pm(2\% \text{ set} + 0.25\% \text{ F.S.})$

Over Current Protection

Range	0.875~71.4A	0.125~10.2A
Resolution	0.175A	0.025A
Accuracy	$\pm(2\% \text{ set} + 0.25\% \text{ F.S.})$	

Over Voltage Protection

Range	1~81.6V	2.5~510V
Resolution	0.2V	1.25V
Accuracy	$\pm(2\% \text{ set} + 0.25\% \text{ F.S.})$	

Over $\cong 85^{\circ}\text{C}$

Temperature
Protection

Rated Power Protection(CPP)

Value	385W
Accuracy	$\pm 5\% \text{ set}$

GENERAL

SHORT CIRCUIT

Current(CC)	$\cong 7.7/7\text{A}$	$\cong 77/70\text{A}$	$\cong 1.1/1\text{A}$	$\cong 11/10\text{A}$
Voltage(CV)	$\cong 0\text{V}$			
Resistance(CR)	$\cong 1.25\Omega$	$\cong 0.025\Omega$	$\cong 50\Omega$	$\cong 1.25\Omega$

Input Resistance 500k Ω (Typical)

(Load OFF)

Temperature 100ppm/ $^{\circ}$ C

Coefficient

Weight Approx. 3.8kg




Note

If your Master is PEL-2004A/ PEL-2002A, the mainframe firmware version must be V3.01.UPG or above.


The firmware file and upgrade procedure can be downloaded on the GWInstek website.

Dimensions


PEL-2002B



PEL-2004B



PEL-2020B/PEL-2030B/PEL-2040B/PEL-2041B



Certificate Of Compliance

We

GOOD WILL INSTRUMENT CO., LTD.

declare that the CE marking mentioned product

satisfies all the technical relations application to the product within the scope of council:

Directive: EMC; LVD; WEEE; RoHS

The product is in conformity with the following standards or other normative documents:

© EMC	
EN 61326-1	Electrical equipment for measurement, control and laboratory use -- EMC requirements
Conducted & Radiated Emission EN 55011 / EN 55032	Electrical Fast Transients EN 61000-4-4
Current Harmonics EN 61000-3-2 / EN 61000-3-12	Surge Immunity EN 61000-4-5
Voltage Fluctuations EN 61000-3-3 / EN 61000-3-11	Conducted Susceptibility EN 61000-4-6
Electrostatic Discharge EN 61000-4-2	Power Frequency Magnetic Field EN 61000-4-8
Radiated Immunity EN 61000-4-3	Voltage Dip/ Interruption EN 61000-4-11 / EN 61000-4-34
© Safety	
EN 61010-1 :	Safety requirements for electrical equipment for measurement, control, and laboratory use - Part 1: General requirements

INDEX

- Alarm configuration207, 218
- All Chan save/recall
 - description95
- Baud rate configuration.....222
- Brightness & contrast....203, 213
- Calibration293
- Calibration key19
- CC vrange mode description.84
- CC+CV mode.....67
- Channel configuration
 - CC voltage range..... 178
 - Go/NoGo mode 192
 - Go/NoGo On/Off..... 194
 - Independent setting..... 185
 - Load delay time..... 186
 - Parallel mode 195
 - Protection All Clear..... 177
 - Response time..... 191
 - SPEC test ON/OFF 194
 - Step resolution..... 188
- Channel configuration
 - Configuration menu..... 173
 - OCP/OCV/OPP..... 174
- Channel configuration
 - Von voltage configuration . 179
- Channel configuration
 - Short..... 181
- Channel configuration
 - channel control 183
- Channel control
 - configuration 183, 272
 - Channel control connection...56
 - Channel control description ..88
 - Channel control mode
 - description85
- Channel duration time
 - settings mode description..79
- Cleaning the instrument.....8
- Clear key20
- Configuration mode
 - description82
- Connection
 - Channel control.....56
 - Frame link.....54
 - Go/NoGo control59
 - Remote sense.....49
 - Wire gauge45
 - Wire Inductance.....45
- Connection procedure47
- Constant power mode
 - description69
- Constant Resistance mode
 - description64
- Constant voltage + constant
 - current mode description...67
- Constant voltage mode
 - description66
- Declaration of conformity316
- Default Settings299
- Delay time mode description 86
- Dimensions313
- Display key30
- Display settings203, 213
- Disposal instructions9
- Dynamic constant current
 - mode description62
- Dynamic loads Constant
 - Resistance mode
 - description65

EN61010	Interface configuration	270
measurement category	Baud Rate	222
Pollution degree	GPIB	227
Enter key	Interface menu	222
Environment	RS232	222
operation	USB configuration	224
Storage	Internal memory save	
External memory save	description	94
description	Knob configuration	206, 216
External voltage mode	Language Settings	211
description	List of features	12
Features	Load (module)key	31
File format mode description	Load connections	44
description	Load Connections	
Firmware update	Auxiliary voltage connection	51
Frame control congifuration	DC Connection	51
.....204, 213, 215, 219	Dual channel load module ...	50
Frame Link configuration ...	Low voltage connections	51
..... 54	Multiple output power	
Frame link connection	source	53
Front panel overview	Parallel load modules	52
Function Keys	Parallel loads	52
Fuse	Parallel mainframes	53
rating	Precautions	44
..... 8	Single channel load module .	50
Fuse replacement	Single load	50
..... 289	Load delay time	
Go/NoGo Alarm Sound	configuration	186
..... 208	Load D-Time mode	
Go/NoGo connection	description	86
..... 59	Load key	22
Go/NoGo constant current	Load Menu	201
mode description	Load module installation	36
..... 63	Load module Overview	30
Go/NoGo constant Resistance	Load profiling description ...	76
mode description	Load terminals	31
..... 66	Load wire induction	45
Go/NoGo constant voltage	Load wiring	46
mode description	Local operation	
..... 68	A&B Value	117
Go/NoGo interface	Channel selection	117
configuration	coarse mode	121
..... 277	Display	120
GPIB card installation		
..... 39		
GPIB configuration		
.....227, 271		
Independent configuration .		
..... 185		
Independent mode		
description		
..... 85		
Installation		
GPIB card		
..... 39		
Load module		
..... 36		
Rack mount		
..... 40		

- Dynamic 118
- Editing the load 121
- fine mode..... 121
- Load 119
- Operation..... 117
- R/L keys 117
- Shorting 120
- Static..... 118
- Lock key 20
- Mainframe configuration
 - alarm sound 207, 218
 - Brightness & contrast.. 203, 213
 - Configuration menu..... 199
 - Frame control 204, 213, 215, 219
 - Go/NoGo Tone 208
 - Knob type 206, 216
 - Language 211
 - Load menu 201
 - Slave knob 209, 219
 - Speaker 202, 212
 - System Info..... 199
 - Utility menu 199
- Mainframe operation
 - CC Dynamic mode..... 126
 - CC Mode 125
 - CC Range..... 125
 - CC Static Values..... 129
 - Channel duration time
 - settings 162
 - Channel Selection..... 123, 124
 - CP Current limit 143
 - CP mode 142
 - CP Power values..... 143
 - CP range 140, 145
 - CR Range..... 132
 - CR Static Parameters..... 136
 - CR Dynamic mode 133
 - CR mode 131
 - CR Static mode 135
 - CV Current limit..... 139
 - CV mode 138
 - CV response speed..... 141
 - CV Voltage values 139
 - Edit Sequence..... 158
 - OCP test automation 167
 - Program chain..... 150
 - Program Execution..... 153
 - Program Sequences 146
 - Programming 146
 - Recall default chain 152
 - Recall default sequence..... 150
 - Run Sequence..... 165
 - Save chain 152
 - Save Program chain..... 152
 - Save sequence 150
 - Sequence loop 160
 - Trig out 162
- Measurement types..... 16, 17
- Memory data description..... 92
- Number pad..... 19
- OCP test automation..... 167
- OCP Test Automation
 - description 80
- Operating configurations
 - mode description 84
- Operating Description 60
- Operating Modes
 - Channel duration time
 - settings..... 79
 - Configuration..... 82
 - Configuration - Over current
 - protection 83
 - Configuration - Over power
 - protection 83
 - Configuration - Over voltage
 - protection 83
 - Constant current -
 - Go/NoGo 63
 - Constant current - Slew rate 63
 - Constant current -Dynamic.. 62
 - Constant current -static..... 62
 - Constant Power..... 69
 - Constant Resistance..... 64
 - Constant Resistance -
 - Dynamic loading 65
 - Constant Resistance - Slew
 - rate 66

Constant Resistance		Operation keys.....	21
Go/NoGo	66	Over Current mode	
Constant Voltage.....	66	description.....	83
Constant Voltage - Response		Over power mode	
speed	68	description.....	83
Constant Voltage + Constant		Over protection	
Current Mode.....	67	configuration.....	174
Constant Voltage -		Over voltage mode	
Go/NoGo.....	68	description.....	83
Constant Voltage -levels	67	Overview	14
External Voltage Control.....	88	Display Overview	23
File format.....	96	Front panel	18
File System.....	91	LED display.....	33
Go/NoGo.....	75	Load module.....	30
Interface.....	91	Rear Panel.....	27
Memory data	92	Parallel Dynamic loading	
Operating Configuration s -		description.....	81
Von Voltage.....	84	pass/ fail test	
Operating Configurations....	84	multiple step tutorial	99
Operating Configurations -		Power key	22
CC vrange.....	84	Power supply	
Operating Configurations -		Safety information.....	7
independent	85	Power up	42
Operating Configurations -		Power up sequence	42
Load D-Time	86	Preset data description	92
Operating Configurations -		Preset key	21
Short	87	Program Chain mode	
Operating Configurations -		description.....	75
Step Resolution	86	Program mode description ...	73
Parallel Dynamic Loading ...	81	Protection All clear.....	177
Preset data.....	92	Quick save Presets to internal	
Program Chain	75	memory.....	262
Reverse voltage protection ..	84	R/L key.....	30
Run Program	73	Rack mount installation.....	40
save/recall All Chan.....	95	Range Chart.....	294
SEQ data.....	93	Recall factory defaults.....	265
Sequences.....	76	Recall Memory data to USB	247
Setup data	93	Recall Presets - Framelink ...	264
Trig Out.....	78	Recall Setups - Framelink	263
USB save/recall.....	95	Remote control	
Operation		local bus configuration	284
Contents	114	multi-unit configuration.....	284
Local load.....	117		
Operation Environment	8		

- sockets function check 229, 232
- UART configuration 282
- Remote control function check
 - GPIB 232
- Remote sense connections.....49
- Response speed constant
 - voltage mode description ..68
- Response time.....191
- Reverse voltage protection.....84
- RS232 configuration.....222
- Safety Instructions.....6
- Safety symbols.....6
- Save Memory data234
- Save Memory data to USB ...247
- Save Preset memory236
- Save presets to USB.....252
- Save Sequences to USB.....257
- Save setup memory.....238
- Save setup to USB245
- Save to internal memory234, 240
- Save to internal setup
 - memory238
- Save/Recall
 - default USB path 240
 - FrameLink Preset Recall..... 264
 - FrameLink Setup Recall..... 263
 - Preset memory 236
 - Quick save Presets to internal
 - memory 262
 - Recall factory defaults 265
 - Recall Memory data to USB247
 - Save Memory data to USB.. 247
 - Save Preset Memory 236
 - Save presets to USB..... 252
 - Save SEQ (Sequences) to
 - USB..... 257
 - Save setup to USB..... 245
 - Save to internal Memory 240
 - Save to setup Memory 238
 - Setup memory..... 238
 - USB path..... 240
- Save/Recall
 - Memory data..... 234
 - Save to internal Memory234
- Selector Knob.....20
- SEQ data description93
- Sequence editing/creating...158
- Sequence mode description ...76
- Sequences mode description .73
- service contact point288
- Setting the date and time220
- Setup data description.....93
- Shift key21
- Short configuration181
- Short key32
- Shorting mode description ...87
- Slave knob
 - settings209, 219
- Slave knob
 - description.....32
- Slew rage constant current
 - mode description63
- Slew rate Constant Resistance
 - mode description66
- Socket server function
 - check 229, 232
- Speaker Settings202, 212
- Specifications302
- Static constant current mode
 - description62
- Static/ Dynamic key32
- Step resolution.....188
- Step Resolution mode
 - description86
- Storage Environment.....9
- System Info199
- System Keys.....18
- Terminals.....31
- Trig out162
- Trig out mode description78
- Tutorials
 - Channel control.....110
 - Frame link.....108
 - General configuration
 - options112

Local load.....	99	Utility Menu.....	199
Program.....	107	Voltage levels constant	
Single load.....	101	voltage mode description..	67
Tutorials		Voltage sense terminal.....	31
Parallel load.....	103	Von voltage configuration...	179
Tutorials		Von voltage mode	
Basic Operation.....	98	description.....	84
Twisted pair description	46	Wire Connections.....	44
USB configuration.....	224	Wire gauge.....	44
USB path.....	240	Wire induction.....	45
USB remote interface		Wiring procedure.....	47
connection.....	278		
USB save/recall description .	95		

Programmable DC Electronic Load

PEL-2000B Series

PROGRAMMING MANUAL

GW INSTEK PART NO. Version 1.0



ISO-9001 CERTIFIED MANUFACTURER

GW INSTEK

This manual contains proprietary information which is protected by copyright. All rights are reserved. No part of this manual may be photocopied, reproduced or translated to another language without prior written consent of Good Will Corporation.

The information in this manual was correct at the time of printing. However, Good Will continues to improve products and reserves the right to change specifications, equipment, and maintenance procedures at any time without notice.

Table of Contents

INTERFACE OVERVIEW	3
Rear Panel Overview.....	4
PEL-2004B.....	4
PEL-2002B.....	4
Configuring the USB Interface.....	5
GPIB Interface Configuration	14
LAN Interface Configuration.....	16
COMMAND OVERVIEW	18
Command Syntax	19
List of Commands in Functional Order.....	22
COMMAND DETAILS	29
Common commands	31
Abort Subsystem	37
Channel Subsystem	38
CONFIGURE Subsystem.....	43
Utility Subsystem	60
Current Subsystem	70
FETCH Subsystem.....	85
LOAD Subsystem	89
Measure Subsystem	93
MODE Subsystem	97
OCP Test Automation Commands	99
Program Subsystem	108
Resistance Subsystem	118
RUN Subsystem	133
SHOW Subsystem	134
SPECIFICATION Subsystem	136
STATUS Subsystem	141
Voltage Subsystem	149

Power Subsystem	157
SYSTEM Subsystem.....	163
Memory Subsystem	166
SEQuence Subsystem	172
GLOBal Subsystem.....	182
Command Error Codes	185
STATUS REGISTERS	186
Status Register Overview.....	187


INTERFACE OVERVIEW

This manual describes how to use the PEL-2000B's remote command functionality and lists the command details. The Overview chapter describes how to configure the PEL-2000B USB/RS232 or RS485/LAN/GPIB remote control interface.


Rear Panel Overview.....	4
PEL-2004B	4
PEL-2002B	4
Configuring the USB Interface	5
RS232 or RS485 Interface Configuration	7
Set the UART settings	10
Multiple Unit Connection	12
GPIB Interface Configuration	14
LAN Interface Configuration.....	16

Rear Panel Overview

PEL-2004B




PEL-2002B





Configuring the USB Interface


USB connection	PC side connector	Type A, host
	PEL-2000B side connector	Type B, device
	Speed	1.1/2.0 (full speed)

Panel operation 1. Press the Shift Key then the Help key to access the Utility menu. 

2. Press F3 (Interface Menu). 



3. If the interface is not USB, use the selector knob to choose USB. 

4. Connect the USB cable to the USB-B slave port on the rear. 

5. When the PC asks for the USB driver, select gw_pel2k.inf

6. On the PC, activate a terminal application such as MTTY (Multi-Threaded TTY). To check the COM port No., see the Device Manager in the PC. For Windows XP, select Control panel → System → Hardware tab.

7. Run this query command via the terminal application.
*idn?
This command should return the manufacturer, model number, serial number, and firmware version in the following format.
GW, PEL-2002B/2004B, 00000001, V3.01



8. Configuring the command interface is completed. Refer to the other chapters for more details.

RS232 or RS485 Interface Configuration


RS232 or RS485 configuration	Connector	RJ45
	Baud rate	2400/4800/9600/19200/38400/57600/115200
	Data bits	7bits/8bits
	Stop bit	1bit/2bits
	Parity	None, Odd, Even
	Address	0 ~ 30 [This is available when Mode is RS485]

Panel operation

1. Press the Shift Key then the Help key to access the Utility menu.
2. Press the Shift Key then the Help key to access the Utility menu.



3. If the interface is not set to RS232, use the selector knob to change the interface to RS232.




4. Edit the Baud rate, Stop bit and parity.

Baud rate 2400, 4800, 9600, 19200, 38400,
57600,115200

Stop Bit 1,2

Parity None, Odd, Even

- Use the selector knob to change the interface to RS485



- Edit the Baud rate, Stop bit and parity.

Baud rate 2400, 4800, 9600, 19200, 38400,
57600,115200


Stop Bit 1,2

Parity None, Odd, Even

Data Bits 7bits, 8bits

UART Address 0 ~ 30

- Connect the RS-232C to RJ45 cable to the rear panel port: RJ45 female connector.




Terminal application	<p>Invoke a terminal application such as MTTY (Multi-Threaded TTY).</p> <ul style="list-style-type: none">• For RS-232C, set the COM port, baud rate, stop bit, data bit, and parity accordingly. <p>To check the COM port No. for RS-232C, see the Device Manager in the PC. For Win XP, Control panel → System → Hardware tab.</p> <p>8. Ensure the terminal application has the following settings;</p> <p>Baud rate - as per PEL-2000B settings</p> <p>Com Port - as per PC settings (Device Manager)</p> <p>Parity - None</p> <p>Data bits - 8</p> <p>Stop bits - None</p>
Functionality check	<p>Run this query command via the terminal.</p> <p>*idn?</p> <p>This should return the Manufacturer, Model number, Serial number, and Firmware version in the following format.</p> <p>GW, PEL-2002B/2004B, 00000001, V3.01</p>

Set the UART settings

Overview The PEL-2000B series uses the IN & OUT ports for UART communication coupled with RS232 (GW Instek Part number: GTL-259) or RS485 adapters (GW Instek part number: GTL-260).

The pin outs for the adapters are shown below.


RS232 cable with DB9 & RJ-45 shielded connectors from GTL-259 connection kit	DB-9 Connector		Remote IN Port		Remarks
	Pin No.	Name	Pin No.	Name	
	Housing	Shield	Housing	Shield	
	2	RX	7	TX	Twisted pair
	3	TX	8	RX	
	5	SG	1	SG	



Connection diagram




RS485 cable with DB9 & RJ-45 shielded connectors from GTL-260 connection kit	DB-9 Connector		Remote IN Port		Remarks
	Pin No.	Name	Pin No.	Name	
	Housing	Shield	Housing	Shield	
	9	TXD -	6	RXD -	Twisted pair
	8	TXD +	3	RXD +	
	1	SG	1	SG	
5	RXD -	5	TXD -	Twisted pair	
4	RXD +	4	TXD +		



Connection diagram



Diagram of Intermediate connector



Intermediate connector from GTL-259 or GTL-260 connection kit.	Intermediate connector					
	8 Pin (Male)			8 Pin (Female)		
	Pin No.	Name		Pin No.	Name	Remarks
	Housing	Shield	↔	Case	Shield	
	1	SG	↔	1	SG	
	6	TXD -	↔	6	TXD -	Internal paralleled by 120 ohm
	3	TXD +	↔	3	TXD +	
	5	RXD -	↔	5	RXD -	Internal paralleled by 120 ohm
	4	RXD +	↔	4	RXD +	

Diagram of End terminal connector



End terminal connector from GTL-259 or GTL-260 connection kit.	End terminal connector	
	8 Pin Connector	
	Pin No.	Remarks
3	Internal shorted	
7		
4	Internal shorted	
8		

Multiple Unit Connection

The PEL-2000B can have up to 16 units daisy-chained together using the 8 pin connectors (IN OUT ports) on the rear panel. The first unit in the chain is remotely connected to a PC using RS485. Each subsequent unit is daisy-chained to the next using a RS485 local bus. The OUT port of the first unit must be connected to intermediate connector and the OUT port of the last unit must be connected to end terminal connector.




Each unit is assigned a unique address and can then be individually controlled from the host PC.

Operation

1. Connect the first unit's IN port to a PC using RS485 serial cable. Use the serial cables supplied in the GTL-260 connection kit.


2. Plug in intermediate connector to the OUT port on the first unit then using the slave serial link cable (black plug) to connect intermediate connector to the IN port of the second unit.

Terminate the OUT port of the last unit with the end terminal connector included in the GTL-260 connection kit.



3. Power up all units.

4. Press the Shift Key then the Help key to access the Utility menu.



5. Press F3 and set the *Interface* setting to UART> *Mode* and set the Mode to RS485.




6. Set the addresses and mode of all units using UART menu. It must be a unique address identifier and mode select is RS485.

11/17/22		RS485		
16 : 50		LOAD		
Mode	RS485			
Baud rate	115200			
Data Bit	8 Bit			
Parity	NONE			
Stop bit	1			
Address	01			
System Info	Load	Interface	Time Set	Other


7. Multiple units can be operated using SCPI commands now. See the programming manual or see the function check below for usage details.

GPIB Interface Configuration


- Panel operation
1. Press the Shift Key then the Help key to access the Utility menu.



2. Press F3 (Interface Menu).




3. If the interface is not set to GPIB, use the selector knob to change the interface to GPIB.



4. Edit the GPIB address.



Range 1 ~ 30


5. Connect the GPIB cable to the rear panel port: 24-pin female connector





- GPIB constraints
- Maximum 15 devices altogether, 20m cable length, 2m between each device
 - Unique address assigned to each device
 - At least 2/3 of the devices turned On
 - No loop or parallel connection

LAN Interface Configuration

- Panel operation
1. Press the Shift Key then the Help key to access the Utility menu. 
 2. Press F3 (Interface Menu). 




3. If the interface is not set to Ethernet, use the selector knob to change the interface to Ethernet. 
4. Choose Ethernet. Confirm that connection status turn form Offline to Online



5. Check if indicator “Ethernet” turns in green and connection status becomes online status.

05/04/22 16 : 50		LOAD			Ethernet
Interface		Ethernet			
Connection status		Online			
MAC	24-22-00-D7-BA-CB				
DHCP	ON				
IP Address	172. 16. 5. 111				
Subnet Mask	255. 255. 128. 0				
System Info	Load	Interface	Time Set	Other	

6. Connect the LAN RJ45 connector to the RJ45 female socket on the rear panel.



C **COMMAND OVERVIEW**


The Command overview chapter lists all the PEL-2000B commands and command queries. The command syntax section shows you the basic rules you have to apply when using commands.

Command Syntax.....	19
List of Commands in Functional Order	22

Command Syntax

Compatible standard	<ul style="list-style-type: none"> • IEEE488.2, 1992 (fully compatible) • SCPI, 1994 (partially compatible) 												
Command types	<p>There are a number of different instrument commands and queries. A command sends instructions or data to the electronic load and a query receives data or status information from the electronic load.</p> <p>Command Types</p> <table border="1"> <tr> <td>Simple</td> <td>A single command with/without a parameter</td> </tr> <tr> <td>Example</td> <td>*OPC</td> </tr> <tr> <td>Compound</td> <td>Two or more commands separated by a colon (:) with/without a parameter</td> </tr> <tr> <td>Example</td> <td>UTILITY:SOUND 1</td> </tr> <tr> <td>Query</td> <td>A query is a simple or compound command followed by a question mark (?). A parameter (data) is returned.</td> </tr> <tr> <td>Example</td> <td>UTILITY:SOUND?</td> </tr> </table>	Simple	A single command with/without a parameter	Example	*OPC	Compound	Two or more commands separated by a colon (:) with/without a parameter	Example	UTILITY:SOUND 1	Query	A query is a simple or compound command followed by a question mark (?). A parameter (data) is returned.	Example	UTILITY:SOUND?
Simple	A single command with/without a parameter												
Example	*OPC												
Compound	Two or more commands separated by a colon (:) with/without a parameter												
Example	UTILITY:SOUND 1												
Query	A query is a simple or compound command followed by a question mark (?). A parameter (data) is returned.												
Example	UTILITY:SOUND?												

Command forms Commands and queries have two different forms, long and short. The command syntax is written with the short form of the command in capitals and the remainder (long form) in lower case.



The commands can be written in capitals or lower-case, just so long as the short or long forms

are complete. An incomplete command will not be recognized.

Below are examples of correctly written commands.

```
LONG  FETCh:VOLTage?  FETCH:VOTAGE?
      fetch:voltage?
```

```
SHORT FETC:VOLT?      fetc:volt?
```




Square Brackets Commands that contain squares brackets indicate that the contents are optional. The function of the command is the same with or without the square bracketed items, as shown below.

Example:

```
:LOAD[:STATe]
=          :LOAD:STATe
=          :LOAD
```

Command format :PROG**am**:CHA**in** <NR1>LF 1: command header
 1 2 3 4 2: single space
 3: parameter
 4: message terminator

Parameter	Type	Description	Example
	<Boolean>	Boolean logic	0, 1
	<NR1>	integers	0, 1, 2, 3
	<NR2>	decimal numbers	0.1, 3.14, 8.5
	<NR3>	floating point	4.5e-1, 8.25e+1
	<NRf>	any of NR1, 2, 3	1, 1.5, 4.5e-1
	<NRf+>	NRf type including MIN (minimum) and MAX (maximum) limits of the parameter.	1, 1.5, 4.5e-1 MAX, MIN

	<aard>	Arbitrary ascii characters.
	<block data>	IEEE-488.2 binary block data. The block data is comprised of five parts: $\#216 \underbrace{\langle 16_bytes_data \rangle}_{d} \underbrace{\langle NL \rangle}_{e}$  <ol style="list-style-type: none"> Initialization character (#) Digit length (in ASCII) of the number of bytes Number of bytes Binary data New line character
Message terminator	LF^END	line feed code (hexadecimal 0A) with END message
	LF	line feed code
	<dab>^END	last data byte with END message
 Note	In case of setting the parameter which is less than setting resolution, the setting value will round down to a smaller value which closed to the setting value.	
 Note	The receiving buffer size of this unit is 40k Bytes. Do not send the IEEE-488.2 binary block data to this unit at once data transformation. It may cause an unexpected error.	

List of Commands in Functional Order

Common Commands	*CLS	31
	*ESE	32
	*ESR?	32
	*IDN?	33
	*OPC	33
	*RCL	34
	*RDT?	34
	*RST	34
	*SAV	35
	*SRE	35
	*STB?	36
	*TST?	36
<hr/>		
Abort	:ABORt	37
<hr/>		
Channel	:CHANnel[:LOAD]	38
	:CHANnel:ACTive	39
	:CHANnel:SYNCon	39
	:CHANnel:SYNCon:ALL	40
	:CHANnel:ID?	40
	:CHANnel:DISPlay	40
	:CHANnel:MEMO	41
	:MEMO?	42
<hr/>		
Configure	:CONFigure:VOLTage:ON	43
	:CONFigure:VOLTage:RANGe	44
	:CONFigure:VOLTage:LATch	46
	:CONFigure:AUTO:LOAD	46
	:CONFigure:AUTO:MODE	47
	:CONFigure:SOUND	47
	:CONFigure:REMote	48
	:CONFigure:ALARm:MASTer	48

	:CONFigure:ALARm:SLAVE	49
	:CONFigure:SAVE	49
	:CONFigure:LOAD	49
	:CONFigure:PROTection:CURRent:STATe	51
	:CONFigure:PROTection:CURRent:LEVel	51
	:CONFigure:PROTection:VOLTag:e:STATe	52
	:CONFigure:PROTection:VOLTag:e:LEVel	53
	:CONFigure:PROTection:POWer:STATe	54
	:CONFigure:PROTection:POWer:LEVel	54
	:CONFigure:PROTection:UVP:CLear	55
	:CONFigure:PROTection:UVP:LEVel	56
	:CONFigure:RESPonse	56
	:CONFigure:RESEt	57
	:CONFigure:GROup:UNITs	57
	:CONFigure:GROup:MODE	58

Utility	:UTILity:AUTO:LOAD	60
	:UTILity:AUTO:MODE	61
	:UTILity:SOUND	61
	:UTILity:REMOte	62
	:UTILity:REMOte:MODE	62
	:UTILity:TIME	63
	:UTILity:LOAD	64
	:UTILity:IDENtify	64
	:UTILity:FRAME	65
	:UTILity:HIGH:RESolution	65

Current	:CURRent:STATic:RECall	70
	:CURRent:STATic:L1/L2	71
	:CURRent:STATic:RISE/FALL	72
	:CURRent:STATic:LOW:AVALue/BVALue	73
	:CURRent:STATic:LOW:RISE/FALL	74
	:CURRent:STATic:HIGH:AVALue/BVALue	74
	:CURRent:STATic:HIGH:RISE/FALL	75
	:CURRent:DYNamic:L1/L2	76

	:CURRent:DYNamic:RISE/FALL.....	77
	:CURRent:DYNamic:T1/T2.....	78
	:CURRent:DYNamic:LOW:L1/L2	79
	:CURRent:DYNamic:LOW:RISE/FALL	80
	:CURRent:DYNamic:LOW:T1/T2	81
	:CURRent:DYNamic:HIGH:L1/L2.....	81
	:CURRent:DYNamic:HIGH:RISE/FALL.....	82
	:CURRent:DYNamic:HIGH:T1/T2	83
<hr/>		
Fetch	:FETCh:VOLTage?	85
	:FETCh:CURRent?	85
	:FETCh:POWer?	86
	:FETCh:STATus?	86
	:FETCh:ALLVoltage?	86
	:FETCh:ALLCurrent?	87
	:FETCh:ALLPower?	87
<hr/>		
Load	:LOAD[:STATe].....	89
	:LOAD:SHORT[:STATe].....	89
	:LOAD:SHORT:KEY	90
	:LOAD:PROTection?	90
	:LOAD:PROTection:CLear.....	91
	:LOAD:TIME?	91
	:LOAD:DElay.....	92
	:LOAD:TYPE.....	92
<hr/>		
Measure	:MEASure:VOLTage?	93
	:MEASure:CURRent?	93
	:MEASure:POWer?	94
	:MEASure:INPut	94
	:MEASure:SCAN	94
	:MEASure:ALLVoltage?.....	95
	:MEASure:ALLCurrent?.....	95
	:MEASure:ALLPower?.....	96

Mode	:MODE	97
<hr/>		
OCP Test	:OCP:EDIT:CHANnel?	99
Automation	:OCP:CHANnel:RANGe.....	100
	:OCP:CHANnel:STARt.....	100
	:OCP:CHANnel:END	101
	:OCP:CHANnel:STEP:CURRent	102
	:OCP:CHANnel:LAST.....	102
	:OCP:CHANnel:STEP:TIME.....	103
	:OCP:CHANnel:DELay.....	103
	:OCP:CHANnel:TRIGger	104
	:OCP:CHANnel:ACTive.....	104
	:OCP:STATus?	105
	:OCP:SAVE	105
	:OCP:RESult?	106
	:OCP:RUN	106
	:OCP:KEEP	106
<hr/>		
Program	:PROGram:STATe	108
	:PROGram:FILE	109
	:PROGram:SEQuence.....	110
	:PROGram:MEMory	110
	:PROGram:SEQuence:SHORT:CHANnel	111
	:PROGram:SEQuence:SHORT:TIME.....	111
	:PROGram:SEQuence:MODE	112
	:PROGram:ACTive	113
	:PROGram:CHAI.....	114
	:PROGram:ONTime	114
	:PROGram:OFFTime	115
	:PROGram:RUN.....	115
	:PROGram:SAVE.....	116
	:PROGram:PFTIME	116
	:PROGram:CHAI:STARt.....	116

Resistance	:RESistance[:STATic]:L1/L2	118
	:RESistance[:STATic]:RISE/FALL	119
	:RESistance:STATic:RECall	120
	:RESistance:STATic:LOW:AVALue/BVALue	120
	:RESistance:STATic:LOW:RISE/FALL	121
	:RESistance:STATic:HIGH:AVALue/BVALue	122
	:RESistance:STATic:HIGH:RISE/FALL	123
	:RESistance:DYNamic:L1/L2	124
	:RESistance:DYNamic:RISE/FALL	125
	:RESistance:DYNamic:T1/T2	126
	:RESistance:DYNamic:LOW:L1/L2	127
	:RESistance:DYNamic:LOW:RISE/FALL	127
	:RESistance:DYNamic:LOW:T1/T2	128
	:RESistance:DYNamic:HIGH:L1/L2	129
	:RESistance:DYNamic:HIGH:RISE/FALL	130
	:RESistance:DYNamic:HIGH:T1/T2	131
<hr/>		
RUN	:RUN	133
<hr/>		
SHOW	:SHOW[:DISPlay] dual channel	134
	:SHOW[:DISPlay] single channel	135
<hr/>		
Specification	:SPECification:UNIT	136
	:SPECification[:PASS]?	137
	:SPECification[:PASS]:CHANnel/ ALLChannel/VOLTage/CURRent?	137
	:SPECification:VOLTage:H/L/C	138
	:SPECification:CURRent:H/L/C	138
	:SPECification:TEST:	139
	:SPECification:DElay	139
<hr/>		
Status	:STATus:CHANnel:CONDition?	141
	:STATus:CHANnel:ENABle	142
	:STATus:CHANnel:EVENT?	142

	:STATus:CHANnel:NTRansition/PTRansition	143
	:STATus:CSUMmary:ENABle	144
	:STATus:CSUMmary:EVENT?	145
	:STATus:QUESTionable:CONDition?	145
	:STATus:QUESTionable:ENABle	146
	:STATus:QUESTionable[:EVENT]?	146
	:STATus:QUESTionable:NTRansition/PTRansition	147
	:STATus:PREset	148
<hr/>		
Voltage	:VOLTage:L1/L2	149
	:VOLTage:RECall	150
	:VOLTage:AVALue/BVALue	150
	:VOLTage:LOW:CURRent	151
	:VOLTage:HIGH:CURRent	152
	:VOLTage:MODE	153
	:VOLTage:LOW:AVALue/BVALue	154
	:VOLTage:HIGH:AVALue/BVALue	154
	:VOLTage:IMEasure	155
<hr/>		
Power	:POWER:L1/L2	157
	:POWER:CURRent	158
	:POWER:RECall	159
	:POWER:LOW:AVALue/BVALue	159
	:POWER:LOW:CURRent	160
	:POWER:HIGH:AVALue/BVALue	161
	:POWER:HIGH:CURRent	161
<hr/>		
System	:SYSTEM:ERRor?	163
	:SYSTEM:VERSion?	163
	:SYSTEM:SETup	164
	:SYSTEM:KLOCK?	164
	:SYSTEM:KEYLock:MODE?	165

Memory	:MEMory:SAVE:PREset.....	166
	:MEMory:SAVE:PROGram	166
	:MEMory:SAVE:ALLPreset.....	167
	:MEMory:SAVE:SETup.....	167
	:MEMory:RECall:PREset	167
	:MEMory:RECall:PROGram.....	168
	:MEMory:RECall:ALLPreset	168
	:MEMory:RECall:SETup	168
	:MEMory:FILE:PREset	169
	:MEMory:FILE:PROGram	169
	:MEMory:FILE:SETup	170
	:MEMory:FILE:SEQuence.....	170

Sequence	:SEQuence:STATe.....	172
	:SEQuence:EDIT:POINt	173
	:SEQuence:END	173
	:SEQuence:END:LOAD	174
	:SEQuence:POINt:RESistance	174
	:SEQuence:POINt:CURRent.....	175
	:SEQuence:POINt:RISE/FALL.....	175
	:SEQuence:POINt:TIME.....	176
	:SEQuence:REPeat.....	177
	:SEQuence:VOLTage:RANGe.....	177
	:SEQuence:LOOP:START.....	178
	:SEQuence:CHANnel:TIME.....	179
	:SEQuence:RUN	179
	:SEQuence:SAVE	180
	:SEQuence:TRIGger:IN	180
	:SEQuence:TRIGger:OUT.....	180
	:SEQuence:TRIGger:IN:CHANnel.....	181

Global	:GLOBal:CONFIgure:VOLTage:RANGe	182
	:GLOBal:LOAD:SHORT.....	182
	:GLOBal:MODE	183
	:GLOBal:LOAD:[STATe].....	184

C COMMAND DETAILS

The Command details chapter shows the detailed syntax, equivalent panel operation, and example for each command. For the list of all commands, see page 22 for details. Before programming the PEL-2000B electronic load, please become familiar with the Status registers, detailed on page 186.

Common commands	31
Abort Subsystem	37
Channel Subsystem	38
CONFIGURE Subsystem	43
Utility Subsystem	60
Current Subsystem	70
FETCH Subsystem	85
LOAD Subsystem	89
Measure Subsystem	93
MODE Subsystem	97
OCP Test Automation Commands	99
Program Subsystem	106
Resistance Subsystem	118
RUN Subsystem	133
SHOW Subsystem	134
SPECIFICATION Subsystem	136
STATUS Subsystem	139
Voltage Subsystem	149
Power Subsystem	157
SYSTEM Subsystem	163
Memory Subsystem	166
SEQUENCE Subsystem	172

GLOBAL Subsystem.....	182
Command Error Codes	185

Common commands

*CLS	31
*ESE	32
*ESR?	32
*IDN?	33
*OPC	33
*RCL	34
*RDT?	34
*RST	34
*SAV	35
*SRE	35
*STB?	36
*TST?	36

*CLS

Status Command

Description	<p>Clears:</p> <ul style="list-style-type: none"> Channel Status Register Channel Summary Register Questionable Status Register Standard Events Register Operation Status Register Error Queue <p>When the *CLS command follows a program message terminator <nl>, the following is cleared:</p> <ul style="list-style-type: none"> Output Queue <p>See page 186 for details.</p>
Syntax	*CLS
Example	*CLS

Query Syntax	*ESR?			
Return Parameter	<NR1>	Bit(s) Set	<NR1>	Bit(s) Set
	1	OPC	32	CME
	8	DDE	64	~
	16	EXE	128	~
Example	*ESR? 48	The return value is the status reading of the standard Event Status Register.		

***IDN?** System Command

Description	Returns the load generator identification.			
Query Syntax	*IDN?			
Return Parameter	<aard>	Data	<aard>	Data
	GW	Manufacturer	00000001	Serial No.
	PEL-2004A	Model	V3.01	Firmware Version
Example	*IDN? GW, PEL-2002B/2004B, 00000001, V3.01	Returns the mainframe identification string.		

***OPC** Status Command

Description	This command sets the OPC (Operation Command Bit) bit (bit 0) of the Standard Event Status Register after the mainframe has completed all pending operations. See page 193 for details.			
Syntax	*OPC			
Example	*OPC	Sets the OPC bit.		
Query Syntax	*OPC?			
Return Parameter	<NR1>	Operation	<NR1>	Operation

	0	Pending	1	Complete
Query Example	*OPC?		All pending operations are completed.	
	1			

***RCL** Status Command

Description The Recall Instrument State command restores the instrument settings from a previously saved memory setting.

Syntax *RCL <NR1>

Parameter	<NR1>	Recall Memory Setting
	1~120	1~120

Example *RCL 1 Recalls Setting memory 1

***RDT?** System Command

Description Returns the load module type in each channel in order from 1~8. If no frame is present a 0 is returned.

Query Syntax *RDT?

Return Parameter	<aard>	Occupied Channel
	2020L	PEL-2020B left channel
	0	Empty channel

Query Example *RDT?
0,0,2020L,2020R,0,0,0,0 Channels 1-2 and 5-8 are empty; 3-4 is occupied by the PEL-2020B load module.

***RST** Status Command

Description Resets the mainframe by forcing the ABORT, *CLS, and LOAD:PROT:CLE command.

Syntax *RST

Example *RST

***SAV** All Channels

Description Saves the data memory into the specified save slot.

Syntax *SAV <NR1>

Parameter	<NR1>	Save slot
	1~120	1~120

Example *SAV 2 Saves data memory to save slot 2

***SRE** Status Command

Description The Service Request Enable Command determines which events in the Status Byte Register are allowed to set the MSS (Master summary bit) Any bit that is set to "1" will cause the MSS bit to be set. See page 195 for details.

Syntax *SRE <NR1>

Parameter	<NR1>	Bit(s) Set	<NR1>	Bit(s) Set
	4	CSUM	32	ESB
	8	QUES		

Example *SRE 12 Sets bits CSUM and QUES in the Service Request Enable register.

Query Syntax *SRE?

Return Parameter	<NR1>	Bit(s) Set	<NR1>	Bit(s) Set
	4	CSUM	32	ESB
	8	QUES		

Example	*SRE? 32	Returns settings of the Service Request Enable Register. Here ESB is returned.
---------	-------------	--

***STB?** Status Command

Description Reads the Status Query Byte Register. The *STB? command does not clear the register.
If the Master Summary Status bit (MSS) is set, it indicates that there is a reason for a service request.

Query Syntax *STB

Return Parameter	<NR1>	Bit(s) Set	<NRf>	Bit(s) Set
	2	ERR	32	ESB
	4	CSUM	64	MSS
	8	QUES		

Query Example	*STB? 36	Returns status of a byte query in the Status Byte Register. Here CSUM and ESB are returned.
---------------	-------------	---

***TST?** Status Command

Description Performs a system self-test and returns 0 if all tests passed. 1 is returned if a test failed.

Query Syntax *TST?

Return Parameter	<NR1>	Test result	<NR1>	Test result
	0	Pass	1	Fail

Example	*TST? >0
---------	-------------

Abort Subsystem

:ABORt All
Channel Command

Description Turns all electronic loads to OFF.

Syntax :ABORt

Example :ABORt

Channel Subsystem

:CHANnel[:LOAD]	38
:CHANnel:ACTive	39
:CHANnel:SYNCon.....	39
:CHANnel:SYNCon:ALL	40
:CHANnel:ID?	40
:CHANnel:DISPlay.....	40
:CHANnel:MEMO	41
:MEMO?.....	42

:CHANnel[:LOAD] Channel Specific Command

Description	Selects the channel that the channel specific commands use. This command will not change the channel in the display screen.	
Syntax	:CHANnel[:LOAD] <NR1>	
Parameter	<NR1>	Channel selected
	1~8	CH1 ~ CH8
	MAX	CH8
	MIN	CH1
Example	:CHAN 1	Sets channel 1 as the specific channel.
	:CHAN:LOAD 1	Sets channel 1 as the specific channel.
Query Syntax	:CHANnel? [LIST]	
Return Parameter	<NR1>	Current specific channel
	1~8	CH1 ~ CH8
	LIST	Lists available channels
Query Example	:CHAN? LIST	Channel 1 and 2 are available.
	1, 2	

:CHANnel:ACTive Channel Specific Command

Description	This command is for compatibility with other instruments only and has no action.	
Syntax	:CHANnel ACTive {ON 1 OFF 1}	
Parameter	ON/1	Enabled
	OFF/0	Disabled
Example	:CHAN:ACT ON	Enables the specific channel.

:CHANnel:SYNCon Channel Specific Command

Description	Turns independent mode on or off for the channel.	
Syntax	:CHANnel:SYNCon {ON 1 OFF 0}	
Parameter	ON/1	ON
	OFF/0	OFF
Example	:CHAN:SYNC ON	Enables the current channel to receive synchronized commands (synchronized commands is :RUN and Abort).
Query Syntax	:CHANnel:SYNCon?	
Return Parameter	<NR1>	Sync Status
	0	Independent mode is OFF
	1	Independent mode is ON
Query Example	:CHAN:SYNC?	Independent mode is set to OFF for the channel.
	0	

:CHANnel:SYNCon:ALL All Channels

Description	Turns independent mode on or off for all the channels.		
Syntax	:CHANnel:SYNCon:ALL{ON 1 OFF 0}		
Parameter	ON/1	ON for all channels	
	OFF/0	OFF for all channels	
Example	:CHAN:SYNCon:ALL ON	Enables all channel to receive synchronized commands (synchronized commands is :RUN and Abort).	

:CHANnel:ID? Channel Specific Command

Description	Queries the load module identity.			
Query Syntax	:CHANnel:ID?			
Return Parameter	<aard>	Data	<aard>	Data
	GW	Manufacturer	00000001	Serial No.
	PEL2020R	Channel load id	V3.01	Firmware Version.
Query Example	:CHAN:ID?	Returns the load module identification string.		
	GW, PEL2020R, 00000001, V3.01			

:CHANnel:DISPlay Channel Specific Command

Description	Sets or queries which channel is active on the mainframe display.	
Syntax	:CHANnel:DISPlay <NR1>	
Parameter	<NR1>	Channel displayed
	1~8	CH1 ~ CH8

	MAX	Last channel
	MIN	First channel
Example	:CHAN:DISP 1	Sets to the active channel on the display to ch1.
Query Syntax	:CHANnel:DISPlay? [MAX MIN]	
Return Parameter	<NR1> 1~8 MAX/MIN	Channel displayed CH1 ~ CH8 Returns the allowable maximum or minimum.
Query Example	:CHAN:DISP? 1	Channel 1 is currently active on the display.

:CHANnel:MEMO Channel Specific Command

Description	Creates or returns the “memo” that is displayed in the “System Information” screen in the Utility Menu. This memo only applies to this specific channel. The memo will replace the serial number information in the “System Information” screen.	
Syntax	:CHANnel:MEMO <string>	
Parameter/ Return parameter	<string>	String containing memo.
Example	:CHAN:MEMO “this is a memo”	Sets to the memo to “this is a memo”.
Query Syntax	:CHANnel:MEMO?	
Query Example	:CHAN:MEMO? this is a memo	Returns the memo message.

		Channel Specific Query
:MEMO?		
Description	Creates or returns the “memo” that is displayed in the “System Information” screen in the Utility Menu. This memo applies to the mainframe. The memo will replace the serial number information in the “System Information” screen.	
Syntax	:MEMO <string>	
Parameter/ Return parameter	<string>	String containing memo.
Example	:MEMO “this is a memo”	Set the memo to “this is a memo”
Query Syntax	:MEMO?	
Query Example	:MEMO? this is a memo	Returns the memo message.

CONFIGURE Subsystem

:CONFigure:VOLTage:ON	43
:CONFigure:VOLTage:RANGe	44
:CONFigure:VOLTage:LATch	46
:CONFigure:AUTO:LOAD	46
:CONFigure:AUTO:MODE	47
:CONFigure:SOUNd.....	47
:CONFigure:REMote.....	48
:CONFigure:ALARm:MASTer	48
:CONFigure:ALARm:SLAVE.....	49
:CONFigure:SAVE	49
:CONFigure:LOAD.....	49
:CONFigure:PROTection:CURRent:STATe	51
:CONFigure:PROTection:CURRent:LEVel.....	51
:CONFigure:PROTection:VOLTage:STATe	52
:CONFigure:PROTection:VOLTage:LEVel	53
:CONFigure:PROTection:POWEr:STATe	54
:CONFigure:PROTection:POWEr:LEVel.....	54
:CONFigure:PROTection:UVP:CLEar	55
:CONFigure:PROTection:UVP:LEVel	56
:CONFigure:RESPonse	56
:CONFigure:RESEt.....	57
:CONFigure:GROup:UNITs	57
:CONFigure:GROup:MODE.....	58

:CONFigure:VOLTage:ON	Channel Specific Command
-----------------------	--------------------------

Description	Sets Von (voltage on value). The allowable Von values are channel and load module specific.
-------------	---

Syntax	:CONFigure:VOLTage:ON <NRF>[MV V KV]
--------	--------------------------------------

Parameter	<NRF>[MV V KV]	Von
	3	3 volts

	30MV	30 millivolts
	30V	30 volts
Example	:CONF:VOLT:ON 30MV	Set Von to 30 millivolts.
Query Syntax	:CONF:VOLTage:ON?	
Return Parameter	<NR2> 1 unit = 1 volt	Von value (volts)
	1	1 volts
Query Example	:CONF:VOLT:ON? 0.03	Von is set as 30 millivolts (0.03 volts).



Note

The resolution is depended on the selected voltage range. For more details, please refer to PEL-2000B user manual.

For example, the 500V version will have another 125V voltage range.

Vrange	Resolution(V)
500	2
125	0.2
80	0.32
16	0.064

:CONF:VOLTage:RANGe Channel Specific Command

Description Sets Voltage range for CC mode.



Note

If the Von voltage set in the Voltage Range high exceeds the range of Low Range, it is automatically corrected to the maximum value of the Low Range when the Voltage Range is switched to low.

For commands on voltage range, please refer to the table below.

Voltage Range: High/Low commands

CV mode	High	: MODE CVH
	Low	: MODE CVL

CR mode	High	: MODE CRH
	Low	: MODE CRL
CC mode	High	: CONF:VOLT:RANG H
	Low	: CONF:VOLT:RANG L
CP mode	High	: CONF:VOLT:RANG H
	Low	: CONF:VOLT:RANG L

Syntax :CONFigure:VOLTage:RANGe <NRf>[V]|L|H

Parameter	<NRf>[V], L, H	Range
	16	Low range*
	80V	High range*
	L	Low range
	H	High range

*Load module dependent, PEL-2020B shown.

Example :CONF:VOLT:RANG L Sets the range to Low for the channel.

Query Syntax :CONFigure:VOLTage:RANGe?

Return Parameter	<NR2>	Range
	16	Low PEL-2020B, 2030B, 2040B
	125	Low PEL-2041B
	80	High PEL-2020B, 2030B, 2040B
	500	High PEL-2041B

Query Example :CONF:VOLT:RANG? Returns the voltage range. In this case high for the PEL-2041B.
500

:CONFigure:VOLTage:LATch Channel Specific Command

Description	Turn Von Latch on or off for the specific channel.	
Syntax	:CONFigure:VOLTage:LATch{OFF 0 ON 1}	
Parameter	{OFF 0 ON 1}	Von Latch
	OFF/0	Off
	ON/1	On
Example	:CONF:VOLT:LAT 1	Sets Von latch to ON.
Query Syntax	:CONFigure:VOLTage:LATch?	
Return Parameter	<NR1>	Von latch status
	0	Latched Off
	1	Latched On
Query Example	:CONF:VOLT:LAT?	Von latch is set to ON.
	1	

:CONFigure:AUTO:LOAD All channels

Description	Configures the load generator for Auto Load On or Off at start up.	
Syntax	:CONFigure:AUTO:LOAD {OFF 0 ON 1}	
Parameter	{OFF 0 ON 1}	Auto Load
	OFF/0	Off
	ON/1	On
Example	:CONF:AUTO:LOAD ON	Configures Auto Load to On
Query Syntax	:CONFigure:AUTO:LOAD?	
Return Parameter	<NR1>	Auto Load Status
	0	Off
	1	On

Query Example :CONF:AUTO:LOAD? Auto load is On.
1

:CONFigure:AUTO:MODE All channels

Description Configures the Auto Load mode as (run) Program or Load.

Syntax :CONFigure:AUTO:MODE PROGRAM/0, LOAD/1

Parameter	PROGRAM/0, LOAD/1	Auto Load Mode
	PROGRAM/0	PROGRAM
	LOAD/1	LOAD

Example :CONF:AUTO:MODE 1 Configures Auto Load to LOAD

Query Syntax :CONFigure:AUTO:MODE?

Return Parameter	<NR1>	Auto Load Type Status
	0	PROGRAM MODE
	1	LOAD MODE

Query Example :CONF:AUTO:MODE? Auto load mode is to LOAD mode.
1

:CONFigure:SOUND Channel Specific Command

Description Sets the keyboard operating and knob rotating make a sound.

Syntax :CONFigure:SOUND {OFF|0|ON|1}

Parameter	OFF/0	Off
	ON/1	On

Example :CONF:SOUND ON Configures the sound on.

Query Syntax :CONFigure:SOUND?

Return Parameter	<NR1>	SOUND Status
------------------	-------	--------------

	0	Off
	1	On

Query Example :CONF:SOUN?
0
Sound is off for all channel and mainframe.

:CONFIgure:REMOte All Channels

Description	Turns remote control on or off for all interfaces.	
Syntax	:CONFIgure:REMOTE {OFF 0 ON 1}	
Parameter	OFF/0	Off
	ON/1	On
Example	:CONF:REM 1	Turns Remote control on.

:CONFIgure:ALARm:MASTer All Channels

Description	Sets the alarm sound of mainframe.	
Syntax	:CONFIgure:ALARm:MASTer{OFF 0 ON 1}	
Parameter	OFF/0	Off
	ON/1	On
Example	:CONF: ALAR:MAST ON	Configures the alarm sound on for mainframe.
Query Syntax	:CONFIgure:ALARm:MASTer?	
Return Parameter	<NR1>	Alarm sound status of mainframe
	0	Off
	1	On
Query Example	:CONF: ALAR:MAST? 0	Alarm sound is off for the mainframe.

:CONFigure:ALARm:SLAVe All Channels

Description	Sets the alarm sound of slave module.	
Syntax	:CONFigure:ALARm:SLAVe{OFF 0 ON 1}	
Parameter	OFF/0	Off
	ON/1	On
Example	:CONF: ALAR:SLAV ON	Configures the alarm sound on for all slave modules.
Query Syntax	:CONFigure:ALARm:SLAVe?	
Return Parameter	<NR1>	Alarm sound status of all slave modules
	0	Off
	1	On
Query Example	:CONF: ALAR:SLAV? 0	Alarm sound is off for all of the slave modules.

:CONFigure:SAVE All Channels

Description	This command is for compatibility with other instruments only and has no action.	
Syntax	:CONFigure:SAVE	
Example	:CONF:SAVE	Saves the configuration data for all channels into internal memory.

:CONFigure:LOAD System Command

Description	Configures the load module selector knob as OLD or Updated.	
Syntax	:CONFigure:LOAD {OLD 0 UPDATED 1}	

Example	:CONF:LOAD UPDATED	Sets the load module selector knob as Updated.
Parameter	OLD/0 UPDATED/1	Old Updated
Example	:CONF:LOAD OLD	Configuration type set as OLD.
Query Syntax	:CONF:LOAD?	
Return Parameter	<NR1> 0 1	Configuration type Old Updated
Query Example	:CONF:LOAD? 0	Sets the load module selector configuration type as OLD.

:CONFigure:PROTection:CURRent:STATe Channel Specific Command

Description Sets the current protection for the specific channel on or off. The current protection can also be cleared.

Syntax :CONFigure:PROTection:CURRent:STATe {OFF|0|ON|1|CLEAR|2}

Parameter	CLEAR/2	Cleared
	OFF/0	Off
	ON/1	On

Example :CONF:PROT:CURR:STAT 1 Turns on current protection.

Query Syntax : CONFigure:PROTection:CURRent:STATe?

Return Parameter	<NR1>	Current Protection
	0	Off
	1	On
	2	Clear

Query Example :CONF:PROT:CURR:STAT? 1 Current protection is turned on.

:CONFigure:PROTection:CURRent:LEVel Channel Specific Command

Description Sets the current protection level for the current/specific channel.

Syntax :CONFigure:PROTection:CURRent:LEVel <NRf>[A]|MIN|MAX

Parameter	<NRf>	Current Protection Level
	.3	300mA
	0.3A	300mA
	300MA	300mA
	MIN	Sets to the minimum level

	MAX	Sets the current limit to the maximum level
Example	:CONF:PROT:CURR:LEV MAX	Sets the current limit to 20.40A (PEL2020B)
Query Syntax	:CONF:PROT:CURR:LEV? [MIN MAX]	
Return Parameter	<NRf> 1 unit = 1 amp 1 MAX/MIN	Current protection level 1 amp. Returns the allowable maximum and minimum.
Query Example	:CONF:PROT:CURR:LEV? 0.30	Current protection level is at 300mA.



Note

The range of current protection level depends on the current using operating current range of slave module.

The detail specifications of current protection range could be found “Over Current Protection” in the specification of user manual.

	:CONF:PROT:VOLT:STATe	Channel Specific Command
Description	Sets the voltage protection for the current/specific channel on or off. The voltage protection can also be cleared.	
Syntax	:CONF:PROT:VOLT:STATe {OFF 0 ON 1 CLEAR 2}	
Parameter	CLEAR/2 OFF/0 ON/1	Clear Off On
Example	:CONF:PROT:VOLT:STAT 1	Turns on voltage protection.
Query Syntax	:CONF:PROT:VOLT:STATe?	

Return Parameter	<NR1>	Voltage Protection state
	0	Off
	1	On
	2	Clear
Query Example	:CONF:PROT:VOLT:STAT? 0	Voltage protection is currently off.
:CONFigure:PROTection:VOLTage:LEVel		Channel Specific Command
Description	Sets the voltage protection level for the current/specific channel.	
Syntax	:CONFigure:PROTection:VOLTage:LEVel <NRf>[V] MIN MAX	
Parameter	<NRf>	Voltage Protection Level
	30	30 volts
	30V	30 volts
	MIN	Sets to the minimum level
	MAX	Sets the voltage limit to the maximum level
Example	:CONF:PROT:VOLT:LEV MAX	Sets the voltage limit to 81.6V (PEL2020B)
Query Syntax	:CONFigure:PROTection:VOLTage:LEVel? [MIN MAX]	
Return Parameter	<NRf> 1 unit = 1 volt	Voltage protection level
	1.00	1.00 volts.
	MAX/MIN	Returns the allowable maximum and minimum.
Query Example	:CONF:PROT:VOLT:LEV? 81.6000	Voltage protection level is at 81.6V.



Note

The range of voltage protection level depends on the current using operating voltage range of slave module.

The detail specifications of voltage protection range could be found “Over Voltage Protection” in the specification of user manual.

:CONFigure:PROTection:POWeR:STATe Channel Specific Command

Description Sets the power protection for the current/specific channel on or off. The power protection can also be cleared.

Syntax :CONFigure:PROTection:POWeR:STATe {OFF|0|ON|1|CLEAR|2}

Parameter	CLEAR/2	Cleared
	OFF/0	Off
	ON/1	On

Example :CONF:PROT:POW:STAT 1 Turns on power protection.

Query Syntax : CONFigure:PROTection:POWeR:STATe?

Return Parameter	<NR1>	Power Protection
	0	Off
	1	On
	2	Clear

Query Example :CONF:PROT:POW:STAT? 1 Power protection is currently on.

:CONFigure:PROTection:POWeR:LEVel Channel Specific Command

Description Sets the power protection level for the current/specific channel.

Syntax :CONFigure:PROTection:POWeR:LEVel <NRF>[W]|MIN|MAX

Parameter	<NRF> 200 200W MIN MAX	Power Protection Level 200Watts 200Watts Sets to the minimum level Sets the power limit to the maximum level
Example	:CONF:PROT:POW:LEV MAX	Sets the power limit to 102W (PEL2020B)
Query Syntax	:CONFigure:PROTectio:n:POWEr:LEVel? [MIN MAX]	
Return Parameter	<NRF> 1 unit = 1 watt MAX/MIN	Power protection level Returns the power protection level in Watts. Returns the allowable maximum and minimum.
Query Example	:CONF:PROT:POW:LEV? 75	Power protection level is at 75 watts.



Note


The range of power protection level depends on the current using operating power range of slave module.

The detail specifications of power protection range could be found “Over Power Protection” in the specification of user manual.

	:CONFigure:PROTectio:n:UVP:CLEar	All Channel Command
Description	Clears the under voltage protection status.	
Syntax	:CONFigure:PROTectio:n:UVP:CLEar	
Example	:CONF:PROT:UVP:CLE	Clears the under voltage protection.

:CONFigure:PROTection:UVP:LEVel Channel Specific Command

Description	Sets the under voltage protection level for the current/specific channel.	
Syntax	:CONFigure:PROTection:UVP:LEVel <NRf>[W]MIN MAX	
Parameter	<NRf>	UVP Level
	20	20 Volts
	20V	20 Volts
	MIN	Sets to the minimum level (OFF)
	MAX	Sets the voltage limit to the maximum level
Example	:CONF:PROT:UVP:LEV MIN	Sets the UVP limit to OFF
Query Syntax	:CONFigure:PROTection:UVP:LEVel? [MIN MAX]	
Return Parameter	<NRf>	Power protection level
	1 unit = 1 volt	Returns the UVP level as volts.
	MAX/MIN	Returns the allowable maximum and minimum.
Query Example	:CONF:PROT:UVP:LEV? 75	UVP level is at 75 volts.

 **Note** The range of under voltage protection level depends on the current using operating voltage range of slave module. And the MIN(0) will disable the under voltage protection.

The detail specifications of voltage protection range could be found in the specification of user manual.

:CONFigure:RESPonse Channel Specific Command

Description Sets or queries the response rate for the specific channel.

Syntax	:CONFigure:RESPonse {NORMAL 0 FAST 1}	
Parameter	NORMAL/0	Normal
	FAST/1	Fast
Example	:CONF:RESP 0	Response set to normal.
Query Syntax	: CONFigure:RESPonse?	
Return Parameter	<NR1>	Response
	0	Normal
	1	Fast
Query Example	:CONF:RESP? 1	Response is Fast.

:CONFigure:RESEt Channel Specific Command

Description	Recalls the original factory default settings.	
Syntax	:CONFigure:RESEt	
Example	:CONF:RESE	

:CONFigure:GROup:UNITs Channel Specific Command

Description	Sets or queries the number load modules that can be used in the group mode.	
Syntax	CONFigure:GROup:UNITs<NRf> MIN MAX	
Parameter	<NRf>	Number of units
	MIN	Sets to the minimum number
	MAX	Sets to the maximum number
Example	CONF:GRO:UNIT 2	Sets the parallel mode to 2 units.
Query Syntax	CONFigure:GROup:UNITs? [MIN MAX]	
Return Parameter	<NR1>	Returns the number of units
	MAX/MIN	Returns the allowable maximum and minimum.

Query Example : CONF:GRO:UNIT? 2 units are set for the parallel mode.
2



Note

The PEL-2040B and PEL-2041B are fully support group mode(Para/Sync)

The PEL-2030B does not support group function.

The dual channel of PEL-2020B does support group function partially. It can support to group 2 units under the Sync mode only. That means the PEL-2020A can be 2chx100W or 1chx200W.

:CONF:GRO:MODE Channel Specific Command

Description Sets or queries the parallel mode.

Syntax :CONF:GRO:MODE {SYNC|0|PARALLEL|1}

Parameter	SYNC, 0	Sync mode
	PARALLEL, 1	Parallel mode

Example :CONF:GRO:MODE 0 Sets the parallel mode to SYNC.

Query Syntax :CONF:GRO:MODE?

Return Parameter	0	Sync mode
	1	Parallel mode

Query Example :CONF:GRO:MODE? 0 The parallel mode is currently set to SYNC.



Note

The para setting allows the all the parallelized load modules to be operated as a single large load module.

Sync mode allows the settings of a single unit to be synchronized across all the other parallelized load modules.

The major difference is that the Para mode calculates the total amount of current on the screen of the Mainframe, and the Sync mode does not.

The PEL-2040B and PEL-2041B are fully support group mode (Para/Sync). The PEL-2030B does not support group function.

The dual channel of PEL-2020B does support group function partially. It can support to group 2 units under the Sync mode only. That means the PEL-2020A can be 2chx100W or 1chx200W.

Utility Subsystem

:UTILity:AUTO:LOAD	60
:UTILity:AUTO:MODE	61
:UTILity:SOUNd	61
:UTILity:REMOte	62
:UTILity:REMOte:MODE	62
:UTILity:TIME.....	63
:UTILity:LOAD	64
:UTILity:IDENtify	64
:UTILity:FRAMe	65
:UTILity:HIGH:RESolution	65
:UTILity:SYSTem:MODE	66
:UTILity:VOLTage:LATCh:CLEar.....	67
:UTILity:MEASure:PERiod	67
:UTILity:JOG:SHUTTLE:CONTRol	68
:UTILity:RVP:LOAD:OFF	69

:UTILity:AUTO:LOAD System Command

Description	Sets the mainframe to auto mode. Upon startup the mainframe will turn loads/programs on.	
Syntax	:UTILity:AUTO:LOAD {OFF 0 ON 1}	
Parameter	OFF/0	Turns auto loading off
	ON/1	Turns auto loading on
Example	:UTIL:AUTO:LOAD 1	Turns auto loading on
Query Syntax	:UTILity:AUTO:LOAD?	
Return Parameter	<NR1>	Auto load status
	0	Auto loading is off
	1	Auto loading is on

Query Example	:UTIL:AUTO:LOAD? 1	The main frame is currently configured to auto load.
---------------	-----------------------	--

:UTILity:AUTO:MODE System Command

Description	Sets the mainframe auto mode as load or program. Upon startup the mainframe can automatically turn on loads or automatically run the last program.
-------------	--

Syntax	:UTILity:AUTO:MODE {PROGRAM 0 LOAD 1}
--------	---------------------------------------

Parameter	PROGRAM/0	Sets the auto load mode to program
	LOAD/1	Sets the auto load mode to load.

Example	:UTIL:AUTO:MODE 1	Auto load mode is set to load.
---------	-------------------	--------------------------------

Query Syntax	:UTILity:AUTO:MODE?
--------------	---------------------

Return Parameter	<NR1>	Auto load mode
	0	Program
	1	Load

Query Example	:UTIL:AUTO:MODE? 0	Auto load mode is set to Program.
---------------	-----------------------	-----------------------------------

:UTILity:SOUND System Command

Description	Sets the keyboard operating and knob rotating make a sound.
-------------	---

Syntax	:UTILity:SOUND {OFF 0 ON 1}
--------	-----------------------------

Parameter	OFF/0	Off
	ON/1	On

Example	:UTIL:SOUND ON	Configures the sound on.
---------	----------------	--------------------------

Query Syntax	:UTILity:SOUND?
--------------	-----------------

Return Parameter	<NR1>	SOUND Status
------------------	-------	--------------

	0	Off
	1	On
Query Example	:UTIL:SOUN? 0	Sound is off for all channel and mainframe.

:UTILity:REMOte System Command



Description	Turns the remote control on or off.	
Syntax	:UTILity:REMOte {OFF 0 ON 1}	
Parameter	OFF/0	Turns Remote control off
	ON/1	Turns remote control on
Example	:UTIL:REM 1	Turns remote control on.
Query Syntax	:UTILity:REMOte?	
Return Parameter	<NR1>	Remote mode
	0	Off
	1	On
Query Example	:UTIL:REM? 1	Always under remote mode.

:UTILity:REMOte:MODE System Command

Description	Sets the remote mode to fast or normal. When in fast mode, the panel interface is deactivated with an interface time of no more than 10ms. Normal mode has an interface time of 30~130ms. In normal mode the panel interface continues to update the screen in real-time.	
Syntax	:UTILity:REMOte:MODE {NORMAL 0 FAST 1}	
Parameter	NORMAL/0	NORMAL
	FAST/1	FAST
Example	:UTIL:REM:MODE 1	Turns remote mode to fast.

Query Syntax	:UTILity:REMOte:MODE?	
Return Parameter	<NR1> NORMAL/0 FAST/1	Remote mode NORMAL FAST
Query Example	:UTIL:REM:MODE? 1	Remote mode is under fast mode.

:UTILity:TIME System Command

Description	Sets the date and time on the mainframe.	
Syntax	:UTILity:TIME [aard]	
Parameter	[aard] 	1 Year 2 Month/Day 3 Time (24 hours)
Example	:UTIL:TIME "201501031343" Sets the time to 1:00 pm, January 3 rd , 2015.	
Query Syntax	:UTIL:TIME?	
Return Parameter	[aard] 	1 Year 2 Month/Day 3 Time (24 hours)
Query Example	:UTIL:TIME? 2015/11/13/13:00	The date is November 13 th , 2015. The time is 1:00 pm.

:UTILity:LOAD System Command

Description	Sets the knob control style. The load module control knobs can be set to operate independently (OLD style) to the mainframe or with the mainframe (UPDATED).	
Syntax	:UTILity:LOAD {OLD 0 Updated 1}	
Parameter	OLD/0	Old
	UPDATED/1	Updated
Example	:UTIL:LOAD 1	Set the knob style to update.
Query Syntax	:UTILity:LOAD?	
Return Parameter	<NR1>	Knob style
	0	Old
	1	Updated
Query Example	:UTIL:LOAD? 1	The knob style is set to Updated.

:UTILity:IDENTify System Command

Description	The outer display screen of mainframe will be flashing for help identify which mainframe is under control. This command will have no function while the system is under remote fast mode. (:UTIL:REM:MODE 1)	
Syntax	:UTILity:IDENTify {OFF 0 ON 1}	
Parameter	OFF/0	Turns message off
	ON/1	Turns message on
Example	:UTIL:IDEN 1	Turns the message on.

:UTILity:FRAMe System Command

Description	Turns Frame Link on or off.	
Syntax	:UTILity:FRAMe {OFF 0 ON 1}	
Parameter	{OFF 0 ON 1}	Frame Link
	OFF/0	off
	ON/1	on
Example	:UTIL:FRAM 1	Turns Frame Link on.
Query Syntax	:UTILity:FRAMe?	
Return Parameter	<NR1>	Frame Link
	0	Off
	1	On
Query Example	:UTIL:FRAM? 0	Frame Link is on.

:UTILity:HIGh:RESolution System Command

Description	<p>ON: When there is difference between the measured value of voltage, current or power which displayed on the module panel and the setting value, the system will fine tune the load value so that the measured value close to the setting value. The system will perform and complete this action after loading is on in one second.</p> <p>OFF: The system won't perform any action when there is difference between the measured value of voltage, current or power which displayed on the module panel and the setting value.</p>	
Syntax	:UTILity:HIGh:RESolution{OFF 0 ON 1}	
Parameter	OFF/0	Set High Resolution to off
	ON/1	Set High Resolution to on

Example	:UTIL:HIGH:RES 0	Set High Resolution to off.
Query Syntax	:UTILity:HIGH:RESolution?	
Return Parameter	<NR1>	Remote mode
	0	Off
	1	On
Query Example	:UTIL:HIGH:RES? 0	High Resolution is set to off.

:UTILity:SYSTem:MODE System Command

Description	<p>1: When any command is received, the Master panel will automatically enter the Remote fast mode.</p> <p>0: The Master panel won't automatically enter the Remote fast mode.</p>	
Syntax	:UTILity:SYSTem:MODE {OFF 0 ON 1}	
Parameter	OFF/0	Set System Mode to 0
	ON/1	Set System Mode to 1
Example	:UTIL:SYST:MODE 0	Set System Mode to 0.
Query Syntax	:UTILity:SYSTem:MODE?	
Return Parameter	<NR1>	System mode
	0	Off
	1	On
Query Example	:UTIL:SYST:MODE? 0	System Mode is set to 0.

:UTILity:VOLTage:LATCh:CLEar System Command

Description	<p>Auto: Load starts when the terminal voltage of module is higher than Von value. The system stops loading when the terminal voltage of module is close to 0V for more than 25ms and system is under the state of detecting Von again.</p> <p>Manual: The load starts when the terminal voltage of module exceeds the Von setting value. Loading keep going even if the terminal voltage of module close to 0V.</p>	
Syntax	:UTILity:VOLTage:LATCh:CLEar{AUTO 0 MANUAL 1}	
Parameter	AUTO/0	Set Voltage Latch Clear to auto
	MANUAL/1	Set Voltage Latch Clear to manual
Example	:UTIL:VOLT:LATC:CLE 0 Set Voltage Latch Clear to auto.	
Query Syntax	:UTILity:VOLTage:LATCh:CLEar?	
Return Parameter	<NR1>	Remote mode
	0	AUTO
	1	MANUAL
Query Example	:UTIL:VOLT:LATC:CLE? 0 Voltage Latch Clear is set to auto.	

:UTILity:MEASure:PERiod System Command

Description	<p>You can select a measure sample rate through this setting, 200ms or 20ms are available for voltage and current sampling rate.</p>	
Syntax	:UTILity:MEASure:PERiod{NORMAL 0 FAST 1}	
Parameter	NORMAL/0	Set Measure Period to 200ms
	FAST/1	Set Measure Period to 20ms
Example	:UTIL:MEAS:PER 0 Set Measure Period to 200ms	

Query Syntax	:UTILity:MEASure:PERiod?	
Return Parameter	<NR1>	Remote mode
	0	NORMAL
	1	FAST
Query Example	:UTIL:MEAS:PER? Measure Period is set to 200ms. 0	

:UTILity:JOG:SHUTTLE:CONTRol System Command

Description	<p>ON: After this setting is enabled, the settings value will be adjusted by slave knob in Jog Shuttle mode when you adjust the setting value. The interval value is adjusted according to the knob speed.</p> <p>OFF: If this setting is disabled, the settings value will be adjusted by slave knob in the form of fixed compartment when you adjust the setting value.</p>	
Syntax	:UTILity:JOG:SHUTTLE:CONTRol{OFF 0 ON 1}	
Parameter	OFF/0	Set Jog Shuttle Control to OFF
	ON/1	Set Jog Shuttle Control to ON
Example	:UTIL:JOG:SHUTTLE:CONTRol 0 Set Jog Shuttle Control to OFF.	
Query Syntax	:UTILity:JOG:SHUTTLE:CONTRol?	
Return Parameter	<NR1>	Remote mode
	0	OFF
	1	ON
Query Example	:UTIL:JOG:SHUTTLE:CONTRol? Jog Shuttle Control is set to OFF. 0	

:UTILity:RVP:LOAD:OFF

System Command

Description	ON: When RVP is detected, Alarm will display on the screen and stop loading. OFF: When RVP is detected, Alarm will display on the screen but loading is kept on.	
Syntax	:UTILity:RVP:LOAD:OFF{OFF 0 ON 1}	
Parameter	OFF/0	Set RVP Load Off to OFF
	ON/1	Set RVP Load Off to ON
Example	:UTIL:RVP:LOAD:OFF 0 Set RVP Load Off to OFF.	
Query Syntax	:UTILity:RVP:LOAD:OFF?	
Return Parameter	<NR1>	Remote mode
	0	OFF
	1	ON
Query Example	:UTIL:RVP:LOAD:OFF? RVP Load Off is set to OFF. 0	

Current Subsystem

:CURRent:STATic:RECall	70
:CURRent:STATic:L1/L2	71
:CURRent:STATic:RISE/FALL	72
:CURRent:STATic:LOW:AVALue/BVALue	73
:CURRent:STATic:LOW:RISE/FALL.....	74
:CURRent:STATic:HIGH:AVALue/BVALue	74
:CURRent:STATic:HIGH:RISE/FALL	75
:CURRent:DYNamic:L1/L2	76
:CURRent:DYNamic:RISE/FALL.....	77
:CURRent:DYNamic:T1/T2.....	78
:CURRent:DYNamic:LOW:L1/L2	79
:CURRent:DYNamic:LOW:RISE/FALL	80
:CURRent:DYNamic:LOW:T1/T2	81
:CURRent:DYNamic:HIGH:L1/L2.....	81
:CURRent:DYNamic:HIGH:RISE/FALL.....	82
:CURRent:DYNamic:HIGH:T1/T2	83

:CURRent:STATic:RECall	Channel Specific Command
------------------------	--------------------------

Description	Sets or queries whether A Value or B Value is the currently active value in CC static mode.	
Syntax	:CURRent:STATic:RECall {A 0 B 1}	
Parameter	A/0	A
	B/1	B
Example	:CURR:STAT:REC 1 Makes B Value the active value.	
Query Syntax	:CURRent:STATic:RECall?	
Return Parameter	<NR1>	Value
	0	A
	1	B

Query Example :CURR:STAT:REC? A Value is active.
0

:CURRent:STATic:L1/L2 Channel Specific Command

Description Sets the A/B Value for constant current static mode, where L1 is A Value and L2 is B Value. The command is range dependent. If the current range is Low, then the command will only apply to the low range settings. When setting the A/B value, the device will be switched to CC mode by using this command.

Syntax :CURRent:STATic:L1|L2 <NRf+>[A]

Parameter	<NRf+>[A]	
	L1 1	Sets A Value to 1 Amp.
	L2 2	Sets B Value to 2 Amps.
	L1 1A	Sets A Value to 1 Amp.
	L1 MIN	Sets A Value to the minimum level for the specific channel.
	L1 MAX	Sets A Value to the maximum Level for the specific channel.

Example :CURR:STAT:L1 1 Sets A Value to 1 amp for the current range

Query Syntax :CURRent:STATic:L1?/L2? [MAX|MIN]

Return Parameter	<NR2> [MAX MIN]	Current
	1 unit = 1 amp	Returns the current of the A Value (L1) or B Value (L2).
	MAX/MIN	Returns the allowable maximum and minimum.

Query Example :CURR:STAT:L2? MAX Returns the maximum current allowed for the channel. (PEL-2020B)
10.2

Query Example :CURR:STAT:L2? 2 Returns the current setting (2 A) for B Value.

:CURRent:STATic:RISE/FALL Channel Specific Command

Description Sets the slew rate for constant current static mode. The command is range dependent. If the current range is Low, then the command will only apply to the low range settings. When setting the A/B value, the device will be switched to CC mode by using this command.

Syntax :CURRent:STATic:RISE/FALL <NRf+>[A/uS]

Parameter	<NRf+>[A/uS]	Slew Rate
	RISE/FALL 0.078A/uS	Sets the rising/ falling slew rate to 0.078A/uS
	RISE/FALL 1	Sets the rising/ falling slew rate to 1A/uS
	RISE/FALL MIN	Sets to the slowest rising/ falling slew rate.
	RISE/FALL MAX	Sets to the fastest rising/ falling slew rate.

Example :CURR:STAT:RISE .01 Sets the rising slew rate to 0.01A/uS.

Query Syntax : CURRent:STATic:RISE/FALL? [MIN|MAX]

Return Parameter	<NR2> [MAX MIN]	Slew rate
	1 Unit=1 amp/uS	Returns the slew rate.
	MAX/MIN	Returns the allowable maximum and minimum.

Query Example :CURR:STAT:RISE? MIN 0.078 The Minimum value for the rising slew rate is 0.078 A/uS for the specific channel.

Query Example :CURR:STAT:RISE? 0.16800 The rising slew rate is 0.168 A/uS for the specific channel.

:CURRent:STATic:LOW:AVALue/BVALue Channel Specific Command

Description Sets the low range A/B Value for constant current static mode.

Syntax :CURRent:STATic:LOW:AVALue/BVALue<NRf+>[A]

Parameter	NRf+[A]	
	AVALue 1	Sets A Value to 1 Amp. (Low range only)
	BVALue 2	Sets B Value to 2 Amps. (Low Range only)
	AVALue 1A	Sets A Value to 1 Amp. (Low range only)
	AVALue MIN	Sets A Value to the minimum level for the specific channel.
	AVALue MAX	Sets A Value to the maximum Level for the specific channel.

Example :CURR:STAT:LOW:AVAL 1 Sets low range CC static mode A Value to 1 amp.

Query Syntax :CURRent:STATic:LOW:AVALue/BVALue? [MAX|MIN]

Return Parameter	<NR2> [MAX MIN]	Current
	1 unit = 1 amp	Returns the current of the A or B Value.
	MAX/MIN	Returns the allowable maximum and minimum.

Query Example :CURR:STAT:LOW:BVAL? MAX 2 Returns the maximum current allowed for the channel. (PEL-2020B)

:CURRent:STATic:LOW:RISE/FALL Channel Specific Command

Description	Sets the low range rising/falling slew rates.	
Syntax	:CURRent:STATic:LOW:RISE/FALL<NRf+>[A/uS]	
Parameter	<NRf+>[A/uS]	Slew Rate
	RISE/FALL 0.078A/uS	Sets the rising/falling slew rate to 0.078A/uS
	RISE/FALL 1	Sets the rising/falling slew rate to 1A/uS
	RISE/FALL MIN	Sets to the slowest rising/falling slew rate.
	RISE/FALL MAX	Sets to the fastest rising/falling slew rate.
Example	:CURR:STAT:LOW:RISE .001	Sets the rising slew rate to 0.001A/uS.
Query Syntax	: CURRent:STATic:LOW:RISE/FALL? [MIN MAX]	
Return Parameter	<NR2> [MAX MIN]	Slew rate
	1 Unit=1 amp/uS	Returns the slew rate.
	MAX/MIN	Returns the allowable maximum and minimum.
Query Example	:CURR:STAT:LOW:RISE? MIN 0.078	For low range CC mode, the Minimum value for the rising slew rate is 0.078 A/uS for the specific channel.

:CURRent:STATic:HIGH:AVALue/BVALue Channel Specific Command

Description	Sets the high range A/B Value for constant current static mode.	
Syntax	:CURRent:STATic:HIGH:AVALue/BVALue<NRf+>[A]	
Parameter	NRf+[A]	

	AVALue 10	Sets A Value to 10 Amps. (high range only)
	BVALue 20	Sets B Value to 20 Amps. (high range only)
	AVALue MIN	Sets A Value to the minimum level for the specific channel.
	A Value MAX	Sets A Value to the maximum Level for the specific channel.

Example :CURRent:STATic:HIGH Sets high range CC static mode A Value to 10 amps.
:AVALue 10

Query Syntax :CURRent:STATic:HIGH:AVALue/BVALue?[MAX|MIN]

Return Parameter	<NR2> [MAX MIN]	Auto load mode
	MAX/MIN	Returns the allowable maximum and minimum.
	1 unit= 1 amp	Returns the current of the A or B Value.

Query Example :CURR:STAT:HIGH:BVALue? Returns the maximum current allowed for the channel in high range mode. (PEL-2020B)
MAX
20.4000

:CURRent:STATic:HIGH:RISE/FALL Channel Specific Command

Description Sets the high range rising/falling slew rate.

Syntax :CURRent:STATic:HIGH:RISE/FALL<NRf+>[A/uS]

Parameter	<NRf+>[A/uS]	Slew Rate
	RISE/FALL 0.8A/uS	Sets the rising/falling slew rate to 0.8A/uS
	RISE/FALL 1	Sets the rising/falling slew rate to 1A/uS
	RISE/FALL MIN	Sets to the slowest rising/falling slew rate.

	RISE/FALL MAX	Sets to the fastest rising/falling slew rate.
Example	:CURR:STAT:HIGH:RISE 1.1	Sets the rising slew rate to 1.1A/uS.
Query Syntax	:CURRent:STATic:HIGH:RISE/FALL? [MIN MAX]	
Return Parameter	<NR2> [MAX MIN] 1 Unit=1 amp/uS MAX/MIN	Slew rate Returns the slew rate. Returns the allowable maximum and minimum.
Query Example	:CURR:STAT:HIGH:RISE? MAX 0.8000	For high range CC mode, the maximum value for the rising slew rate is 0.8000 A/uS for the specific channel.

:CURRent:DYNamic:L1/L2 Channel Specific Command

Description	Sets the current levels (Level 1 & 2) for CC dynamic mode. The command is range dependent. If the current range is Low, then the settings will only apply to low range. When setting the A/B value, the device will be switched to CCD mode by using this command.	
Syntax	:CURRent:DYNamic:L1/L2<NRf+>[A]	
Parameter	NRf+[A]	Current
	L1 1	Sets L1 to 1 Amp.
	L2 2	Sets L2 to 2 Amps.
	L2 2A	Sets L2 to 2 Amps.
	L1/L2 MIN	Sets L1 or L2 to the minimum level for the specific channel.
	L1/L2 MAX	Sets L1 or L2 to the maximum Level for the specific channel.

Example	:CURR:DYN:L1 10	In CC dynamic mode, Set L1 (level 1) to 10 amps.
Query Syntax	:CURRent:DYNamic:L1/L2? [MIN MAX]	
Return Parameter	<NR2> [MAX MIN] MAX/MIN 1 unit= 1 amp	Current Returns the allowable maximum and minimum. Returns the current of L1/L2, or the maximum or minimum current allowed.
Query Example	:CURR:DYN:L2? 2.0400	Returns current for the specific channel.

Channel Specific Command

:CURRent:DYNamic:RISE/FALL

Description	Sets the rising/falling slew rate for CC dynamic mode for the specific channel and range. When setting the A/B value, the device will be switched to CCD mode by using this command.	
Syntax	:CURRent:DYNamic:RISE/FALL<NRf+>[A/uS]	
Parameter	<NRf+>[A/uS] RISE/FALL 0.8A/uS RISE/FALL 1 RISE/FALL MIN RISE/FALL MAX	Slew Rate Sets the rising/falling slew rate to 0.8A/uS Sets the rising/falling slew rate to 1A/uS Sets to the slowest rising/falling slew rate. Sets to the fastest rising/falling slew rate.
Example	:CURR:DYNA:RISE 1.1	Sets the rising slew rate to 1.1A/uS.
Query Syntax	:CURRent:DYNamic:RISE/FALL? [MIN MAX]	
Return Parameter	<NR2> [MAX MIN]	Slew rate

	1 Unit=1 amp/uS	Returns the slew rate.
	MAX/MIN	Returns the allowable maximum or minimum.
Query Example	:CURR:DYN:FALL? MIN 0.0003	Shows the minimum allowable value for the falling slew rate as 0.0003 A/uS for the specific channel and range.
:CURRENT:DYNAMIC:T1/T2		Channel Specific Command
Description	Sets the timers T1 or T2 for CC dynamic mode for the specific channel and range. When setting the A/B value, the device will be switched to CCD mode by using this command.	
Syntax	:CURRENT:DYNAMIC:T1/T2<NRf+>[S ms]	
Parameter	<NRf+>[S]	Time
	T1/T2 0.1S	Sets the T1/T2 time to 0.1 seconds.
	T1/T2 1	Sets T1/T2 to 1 second.
	T1/T2 MIN	Sets the T1/T2 to the minimum value.
	T1/T2 MAX	Sets the T1/T2 time to the maximum time
Example	:CURR:DYNA:T1 .1S	Sets the T1 time to 100 milliseconds for the specific channel.
Query Syntax	: CURRENT:DYNAMIC:T1/T2? [MIN MAX]	
Return Parameter	<NR2> [MAX MIN]	Time
	1 Unit=1 second	Returns T1/T2 time.
	MAX/MIN	Returns the allowable maximum and minimum.

Query Example	:CURR:DYN:L:T1? 2.5	Returns the T1 time of 2.5 seconds.
	:CURR:DYN:T1? MIN 0.000025	Returns the minimum T1 time allowable for the specific channel and range.

Channel Specific Command

:CURRent:DYNAmic:LOW:L1/L2

Description Sets the low range current levels (Level 1 & 2) for CC dynamic mode.

Syntax :CURRent:DYNAmic:LOW:L1/L2 <NRf+>[A]

Parameter	NRf+[A]	Current
	L1 1	Sets L1 to 1 Amp. (low range only)
	L2 2	Sets L2 to 2 Amps. (low Range only)
	L2 2A	Sets L2 to 2 Amps. (low Range only)
	L1/L2 MIN	Sets L1 or L2 to the minimum level for the specific channel.
	L1/L2 MAX	Sets L1 or L2 to the maximum Level for the specific channel.

Example :CURR:DYN:LOW:L1 10 In low range CC dynamic, Set L1 (level 1) to 10 amps.

Query Syntax :CURRent:DYNAmic:LOW:L1/L2? [MIN|MAX]

Return Parameter	<NR2> [MAX MIN]	Current
	1 unit= 1 amp	Returns the current of L1/L2, or the maximum or minimum current allowed.
	MAX/MIN	Returns the allowable maximum and minimum.

Query Example :CURR:DYN:LOW:L2? Returns current for the
2.0400 specific channel.

:CURRent:DYNamic:LOW:RISE/FALL Channel Specific
Command

Description Sets the low range rising/falling slew rate for CC
dynamic mode for the specific channel.

Syntax :CURRent:DYNamic:LOW:RISE/FALL<NRf+>[A/uS]

Parameter	<NRf+>[A/uS]	Slew Rate
	RISE/FALL 0.8A/uS	Sets the rising/ falling slew rate to 0.8A/uS
	RISE/FALL 1	Sets the rising/ falling slew rate to 1A/uS
	RISE/FALL MIN	Sets to the slowest rising/ falling slew rate.
	RISE/FALL MAX	Sets to the fastest rising/ falling slew rate.

Example :CURR:DYNA:LOW:RISE Sets the rising slew rate to
1.1 1.1A/uS.

Query Syntax : CURRent:DYNamic:LOW:RISE/FALL?[MIN|MAX]

Return Parameter	<NR2> [MAX MIN]	Slew rate
	1 Unit=1 amp/uS	Returns the slew rate.
	MAX/MIN	Returns the allowable maximum or minimum.

Query Example :CURR:DYN:LOW:FALL? For low range dynamic
MIN CC mode, the minimum
0.0003 allowable value for the
falling slew rate is 0.0003
A/uS for the specific
channel.

Parameter	NRf+[A]	
	L1 10	Sets L1 to 10 Amps. (High range only)
	L2 20	Sets L2 to 20 Amps. (High Range only)
	L1/L2 MIN	Sets L1 or L2 to the minimum level for the specific channel.
	L1/L2 MAX	Sets L1 or L2 to the maximum Level for the specific channel.

Example :CURR:DYN:HIGH:L1 10 In high range CC dynamic mode, Set L1 (level 1) to 10 amps.

Query Syntax :CURRent:DYNamic:HIGH:L1/L2? [MIN|MAX]

Return Parameter	<NR2> [MAX MIN]	Return value
	1 unit= 1 amp	Returns the current of Level 1/ 2 (L1/L2).
	MAX/MIN	Returns the allowable maximum and minimum.

Query Example :CURR:DYN:HIGH:L2? MAX
20.4000 Returns the maximum current allowed for the channel. (PEL-2020A)

:CURRent:DYNamic:HIGH:RISE/FALL Channel Specific Command

Description Sets the high range rising/falling slew rate for CC dynamic mode for the specific channel.

Syntax :CURRent:DYNamic:HIGH:RISE/FALL<NRf+>[A/uS]

Parameter	<NRf+>[A/uS]	Slew Rate
	RISE/FALL 0.8A/uS	Sets the rising/falling slew rate to 0.8A/uS
	RISE/FALL 1	Sets the rising/falling slew rate to 1A/uS

	RISE/FALL MIN	Sets to the slowest rising/falling slew rate.
	RISE/FALL MAX	Sets to the fastest rising/falling slew rate.
Example	:CURR:DYNA:HIGH:RISE 1.1	Sets the rising slew rate to 1.1A/uS.
Query Syntax	: CURRent:DYNamic:HIGH:RISE/FALL? [MIN MAX]	
Return Parameter	<NR2> [MAX MIN] 1 Unit = 1 amp/uS MAX/MIN	Slew rate Returns the slew rate. Returns the allowable maximum and minimum.
Query Example	:CURR:DYN:HIGH:FALL? MAX 0.8	For high range dynamic CC mode, the maximum value for the falling slew rate is 0.8 A/uS for the specific channel.

:CURRent:DYNamic:HIGH:T1/T2 Channel Specific Command

Description	Sets the timers T1 or T2 for CC dynamic mode for the specific channel in high range.	
Syntax	:CURRent:DYNamic:HIGH:T1/T2<NRf+>[S ms]	
Parameter	<NRf+>[S]	Time
	T1/T2 0.1S	Sets the T1/T2 time to 0.1 seconds.
	T1/T2 1	Sets T1/T2 to 1 second.
	T1/T2 MIN	Sets the T1/T2 to the minimum value.
	T1/T2 MAX	Sets the T1/T2 time to the maximum time
Example	:CURR:DYNA:HIGH:T1 10S	Sets the high range T1 time to 10 seconds for the specific channel.

Query Syntax	:CURRent:DYNamic:HIGH:T1/T2? [MIN MAX]	
Return Parameter	<NR2> [MAX MIN]	Time
	1 Unit=1 second	Returns T1/T2 time.
	MAX/MIN	Returns the allowable maximum and minimum.
Query Example	:CURR:DYN:HIGH:T1?	Returns the T1 time of 2.5 seconds.
	2.5	
	:CURR:DYN:HIGH:T1? MIN	Returns the minimum T1 time allowable for the specific channel.
	0.000025	

FETCH Subsystem

:FETCh:VOLTage?	85
:FETCh:CURRent?	85
:FETCh:POWer?	86
:FETCh:STATus?	86
:FETCh:ALLVoltage?	86
:FETCh:ALLCurrent?	87
:FETCh:ALLPower?	87

:FETCh:VOLTage? Channel Specific Status Command

Description	This query returns the real-time voltage of the load module input for the specific channel.	
Syntax	:FETCh:VOLTage? <NR2>	
Parameter	<NR2> 1 unit = 1 volt	Voltage
	8	8 volts
Query Example	:FETC:VOLT? 11.2	The specific channel has a voltage of 11.2 volts at the input.

:FETCh:CURRent? Channel Specific Status Command

Description	This query returns the real-time current of the load module input for the specific channel.	
Syntax	:FETCh:CURRent? <NR2>	
Parameter	<NR2> 1 unit= 1 amp	
	1	1 amp
Query Example	:FETC:CURR? 1.2	The specific channel has a current of 1.2 amps at the load module input.

:FETCh:POWer? Channel Specific Status Command

Description	This query returns the real-time power of the load module input for the specific channel.	
Syntax	:FETCh:CURRent? <NR2>	
Parameter	<NR2> 1 unit= 1 watt	
	1	1 amp
Query Example	:FETC:POW? 1.2	The specific channel is at 1.2 watts.

:FETCh:STATus? Status Command

Description	This query returns the status of the load module. The returned value is the bit weight of the Channel Status Register. See page 186 for details.			
Syntax	:FETCh:STATus? <NR1>			
Parameter	<NR1>	Condition	<NR1>	Condition
	1	OC	16	OT
	2	OV	32	G/N
	4	OP	64	UVP
	8	RV	128-65535	Not Used
Query Example	:FETC:STAT? 2	Over voltage (OV) protection has been triggered for the specific channel.		

:FETCh:ALLVoltage? All Channel Status Command

Description	This query returns the voltage values of all the load modules/channels in order from 1-8 (PEL-2004B)/1-4 (PEL2002B).
Syntax	:FETCh:ALLVoltage?

Parameter	<aard> CH1,CH2,CH3,CH4,CH5, CH6,CH7,CH8	Returns all the voltage values from all the channels, 1-8(PEL-2004B)/1-4(PEL-2002B).
Query Example	:FETC:ALLV? 2.5000, 3.0000, 0.0000, 0.0000, 0.0000, 0.0000, 5.500, 0.0000	Channel 1 and 2 have voltages of 2.5 and 3 volts respectively. Channels 3-6 and 8 have no voltage and channel 7 is 5.5 volts
:FETCh:ALLCurrent?		All Channel Status Command

Description	This query returns the current values of all the load modules/channels in order from 1-8 (PEL-2004B)/1-4 (PEL2002B).	
Syntax	:FETCh:ALLCurrent? <aard>	
Parameter	<aard> CH1,CH2,CH3,CH4,CH5, CH6,CH7,CH8	Returns all the current values from all the channels, 1-8 (PEL-2004B)/1-4 (PEL-2002B).
Query Example	:FETC:ALLC? 0.0000, 0.0000, 0.0000, 0.0000, 0.0000, 0.0000, 1.2000, 3.5600	Channels 1 to 6 have no current. Channels 7 & 8 have 1.2 and 3.56 amps, respectively.
:FETCh:ALLPower?		All Channel Status Command

Description	This query returns the power values of all the load modules/channels in order from 1-8 (PEL-2004B)/1-4 (PEL2002B).	
Syntax	:FETCh:ALLPower? <aard>	
Parameter	<aard>	

	<p>CH1,CH2,CH3,CH4,CH5, CH6,CH7,CH8</p>	<p>Returns all the power values from all the channels, 1-8(PEL-2004B)/1-4 (PEL-2002B).</p>
<p>Query Example</p>	<p>:FETC:ALLP? 0.0000, 0.0000, 10.200, 5.5000</p>	<p>Channels 1 to 2 have no power. Channels 3 & 4 have 10.2 and 5.5 watts, respectively.</p>

LOAD Subsystem

:LOAD[:STATe].....	89
:LOAD:SHORt[:STATe].....	89
:LOAD:SHORt:KEY.....	90
:LOAD:PROTection?.....	90
:LOAD:PROTection:CLEar.....	91
:LOAD:TIME?.....	91
:LOAD:DELAy.....	92
:LOAD:TYPE.....	92

Channel

:LOAD[:STATe] Specific Command

Description This command turns the electronic load on/off for the specific channel.

Syntax :LOAD[:STATe] {ON|1|OFF|0}

Parameter	ON/1	Load On
	OFF/0	Load Off

Example :LOAD ON Turns the specific channel load on.

Query Syntax :LOAD[:STATe]?

Return Parameter	<NR1>	Load module
	1	Load is On
	0	Load is Off

Query Example :LOAD?
1 Turns the specific channel load on.

Channel Specific Command

:LOAD:SHORt[:STATe] Command

Description This command shorts the electronic load on/off for the specific channel.

Syntax :LOAD:SHORt[:STATe]{ON|1|OFF|0}

Parameter	ON/1	Shorting is On
	OFF/0	Shorting is Off
Example	:LOAD:SHOR ON	Short circuits the load module channel.
Query Syntax	:LOAD:SHORT[:STATE]?	
Return Parameter	<NR1>	Short Load module
	1	Shorting is activated
	0	Shorting is deactivated
Query Example	:LOAD:SHOR?	Shorting is deactivated on the specific channel.
	0	

:LOAD:SHORT:KEY Channel Specific Command

Description	The SHORT key can be set to Toggle or Hold mode.	
Syntax	:LOAD:SHORT:KEY {TOGGLE 1 HOLD 0}	
Parameter	TOGGLE/1	Sets the SHORT key to toggle mode
	HOLD/0	Sets the SHORT key to hold mode
Example	:LOAD:SHOR:KEY 1	Set the SHORT key to toggle.
Query Syntax	:LOAD:SHORT:KEY?	
Return Parameter	<NR1>	Mode
	1	Toggle mode is active
	0	Hold mode is active
Query Example	:LOAD:SHOR:KEY?	Hold mode is active for the specific channel.
	0	

:LOAD:PROTection? Channel Specific Command

Description	Returns the protection levels for electronic load	
Query Syntax	:LOAD:PROTection?	

Query Example :LOAD:PROT? Clears the Channel Status Register.

Return Parameter	<NR1>	Condition	<NR1>	Condition
	1	OC	16	OT
	2	OV	32	G/N
	4	OP	64	UVP
	8	RV	128-65535	Not Used

Query Example :LOAD:PROT? Returns the status of the Channel Status Register. Here 0 is returned indicating no protection settings have been tripped.

:LOAD:PROTEction:CLEar Channel Specific Command

Description This command clears the Channel Status Register for the specific channel. See page 186 for details.

Syntax :LOAD:PROTEction:CLEar

Example :LOAD:PROT:CLE Clears the Channel Status Register.

:LOAD:TIME? Channel Specific Command

Description This command displays the total load on time. If the load is on, the load time when the command was issued is displayed.

Query Syntax :LOAD:TIME?

Return Parameter	<NR1>1unit = 1 second	Load on time
	2.2	2.2 seconds

Query Example :LOAD:TIME? Returns the load on time as 5.1 seconds.

		Channel Specific Command
:LOAD:DElay		
Description	Sets or queries the load delay time for the specific channel.	
Syntax	:LOAD:DElay<NRf>[S]	
Parameter	<NRf>[S]	Time
	0.1S	Sets the delay time to 0.1 seconds.
Example	:LOAD:DEL 0.1s Sets the delay time to 0.1s.	
Query Syntax	:LOAD:DEL?	
Return Parameter	<NR2>	Delay time in seconds.
Query Example	:LOAD:DEL? 0.10000	Returns the delay time for the current channel.

		All Channels
:LOAD:TYPE		
Description	Sets or queries which load type is the active type.	
Syntax	:LOAD:TYPE {LOAD 0 PROGRAM 1 SEQUENCE 2}	
Parameter	LOAD/0	Normal load
	PROGRAM/1	Program
	SEQUENCE/2	Sequence
Example	:LOAD:TYPE: 1 Program is active.	
Query Syntax	:LOAD:TYPE?	
Return Parameter	<NR1>	Type
	0	Normal load
	1	Program
	2	Sequence
Query Example	:LOAD:TYPE? 0	The normal load type is active

Measure Subsystem

:MEASure:VOLTage?	93
:MEASure:CURRent?	93
:MEASure:POWer?	94
:MEASure:INPut	94
:MEASure:SCAN	94
:MEASure:ALLVoltage?	95
:MEASure:ALLCurrent?	95
:MEASure:ALLPower?	96

:MEASure:VOLTage? Channel Specific Command

Description	This query returns the measured voltage of the specific channel.	
Query Syntax	:MEASure:VOLTage? <NR2>	
Return Parameter	<NR2> 1 unit = 1 volt 0.5000	Voltage at the load input 0.5000 volts
Query Example	:MEAS:VOLT? 8.5600	A voltage of 8.56 volts is measured at the specific channel load input.

:MEASure:CURRent? Channel Specific Command

Description	This query returns the measured current of the specific channel.	
Query Syntax	:MEASure:CURRent? <NR2>	
Return Parameter	<NR2> 1 unit = 1 amp 1.0000	Current at the load input 1.0000 amps
Query Example	:MEAS:CURR? 1.5	A current of 1.5 amps is measured at the specific channel load input.

:MEASure:POWer? Channel Specific Command

Description	This query returns the measured power of the specific channel.	
Query Syntax	:MEASure:POWer? <NR2>	
Return Parameter	<NR2> 1 unit = 1 watt 1.0000	Power at the load input 1.0000 watts
Query Example	:MEAS:POW? 1.5	1.5 watts is measured at the specific channel load input.

:MEASure:INPut Channel Specific Command

Description	This command is for compatibility with other instruments only and has no action.	
Syntax	:MEASure:INPut {LOAD 0 UUT 1}	
Parameter	LOAD/0 UUT/1	Disabled Enabled
Example	:MEAS:INP 0	Disable voltage sense.
Query Syntax	:MEASure:INPut? <NR1>	
Return Parameter	<NR1> 0 1	Voltage Sense Disabled Enabled
Query Example	:MEAS:INP? 1	Returns the voltage input status. Voltage sense is enabled.

:MEASure:SCAN Channel Specific Command

Description	This command allows the mainframe to scan all the load modules' voltage\current\power.	
Syntax	:MEASure:SCAN {OFF 0 ON 1}	

Parameter	OFF/0	Disabled
	ON/1	Enabled
Example	:MEAS:SCAN 0	Disable scanning.
Query Syntax	:MEASure:SCAN? <NR1>	
Return Parameter	<NR1>	Scan
	0	Disabled
	1	Enabled
Query Example	:MEAS:SCAN? 1	Returns the scanning status. Here scanning is enabled.

:MEASure:ALLVoltage? All Channel Command

Description This query measures the voltage values of all the load modules/channels in order from 1-8 (PEL-2004B)/1-4 (PEL2002B).

Query Syntax :MEASure:ALLVoltage? <aard>

Query Parameter <aard> 1 unit = 1 volt
CH1,CH2,CH3,CH4, CH5,CH6,CH7,CH8 Returns all the voltage values from all the channels, 1-8(PEL-2004B)/1-4(PEL-2002B).

Query Example :MEAS:ALLV?
2.5000, 3.0000, 0.0000, 0.0000, 0.0000, 0.0000, 5.500, 0.0000
Channel 1 and 2 have voltages of 2.5 and 3 volts respectively. Channels 3-6 and 8 have no voltage and channel 7 is 5.5 volts

:MEASure:ALLCurrent? All Channel Command

Description This query returns the current measured of all the load modules/channels in order from 1-8 (PEL-2004B)/1-4 (PEL2002B).

Query Syntax :MEASure:ALLCurrent? <aard>

Query Parameter	<aard> 1 unit = 1 amp CH1,CH2,CH3,CH4, CH5,CH6,CH7,CH8	Returns all the current values from all the channels, 1-8(PEL-2004A)/1-4(PEL-2002A).
-----------------	--	--

Query Example	:MEAS:ALLC? 0.0000, 0.0000, 0.0000, 0.0000, 0.0000, 0.0000, 1.2000, 3.5600	Channels 1 to 6 have no current. Channels 7 & 8 have 1.2 and 3.56 amps, respectively.
---------------	---	---

:MEASure:ALLPower?	All Channel Command
--------------------	---------------------

Description	This query returns the power measured of all the load modules/channels in order from 1-8 (PEL-2004B)/1-4 (PEL2002B).
-------------	--

Query Syntax	:MEASure:ALLPower? <aard>
--------------	---------------------------

Query Parameter	<aard> 1 unit = 1 watt CH1,CH2,CH3,CH4, CH5,CH6,CH7,CH8	Returns all the power values from all the channels, 1-8(PEL-2004B)/1-4(PEL-2002B).
-----------------	---	--

Query Example	:MEAS:ALLP? 0.0000, 0.0000, 0.0000, 0.0000, 0.0000, 0.0000, 1.5000, 3.2000	Channels 1 to 6 have no power. Channels 7 & 8 have 1.5 and 3.2 watts, respectively.
---------------	---	---

MODE Subsystem

		Channel Specific Command
:MODE		
Description	This command sets the operating mode of the specific channel. Some modes are load module dependent.	
Syntax	:MODE {CCL CCH CCDL CCDH CRL CRH CRDL CRDH CPL CPH CVL CVH}	
Parameter	CCL	CC static mode, low range
	CCH	CC static mode, high range
	CCDL	CC dynamic mode, low range
	CCDH	CC dynamic mode, high range
	CRL	CR static mode, low range
	CRH	CR static mode, high range
	CRDL	CR dynamic mode, low range
	CRDH	CR dynamic mode, high range
	CPL	CP static mode, low range
	CPH	CP static mode, high range
	CVL	CV static mode, low range
	CVH	CV static mode, High range
Example	:MODE CCL	Set the specific channel to low range constant current static mode.
Query Syntax	:MODE?	
Return Parameter	CCL	CC static mode, low range
	CCH	CC static mode, high range
	CCDL	CC dynamic mode, low range
	CCDH	CC dynamic mode, high range
	CRL	CR static mode, low range

	CRH	CR static mode, high range
	CRDL	CR dynamic mode, low range
	CRDH	CR dynamic mode, high range
	CPL	CP static mode, low range
	CPH	CP static mode, high range
	CVL	CV static mode, low range
	CVH	CV static mode, High range
Query Example	:MODE? CCH	The specific channel is currently set to CC static mode, high range.

OCP Test Automation Commands

:OCP:EDIT:CHANnel?	99
:OCP:CHANnel:RANGe	100
:OCP:CHANnel:STARt	100
:OCP:CHANnel:END	101
:OCP:CHANnel:STEP:CURRent	102
:OCP:CHANnel:LAST	102
:OCP:CHANnel:STEP:TIME	103
:OCP:CHANnel:DELay	103
:OCP:CHANnel:TRIGger	104
:OCP:CHANnel:ACTive	104
:OCP:STATus?	105
:OCP:SAVE	105
:OCP:RESult?	106
:OCP:RUN	106
:OCP:KEEP	106

:OCP:EDIT:CHANnel?	Channel Specific Command
--------------------	-----------------------------

Description	Sets or queries which channel is used to apply the OCP Test Automation parameters. Also see page 104 for setting the active channel.	
Syntax	:OCP:EDIT:CHANnel <NR1>	
Parameter	<NR1>	1-8
Example	:OCP:EDIT:CHAN 1	Sets channel 1 as the chosen channel.
Query Syntax	:OCP:EDIT:CHANnel?	
Return Parameter	<NR1>	1-8
Query Example	:OCP:EDIT:CHAN? 1	Channel 1 is the chosen channel.

		Channel Specific Command
:OCP:CHANnel:RANGe		
Description	Sets or queries the channel range. High (CC Mode High) or Low(CC Mode Low)	
Syntax	:OCP:CHANnel:RANGe{LOW 0 HIGH 1}	
Parameter	LOW/0	CC Mode Low range
	HIGH/1	CC Mode High range
Example	:OCP:CHAN:RANG 0 Sets the range to LOW.	
Query Syntax	:OCP:CHANnel:RANGe?	
Return Parameter	0	CC Mode Low range
	1	CC Mode High range
Query Example	:OCP:CHAN:RANG? The range is CC Mode Low. 0	

		Channel Specific Command
:OCP:CHANnel:STARt		
Description	Sets or queries the starting current value.	
Syntax	:OCP:CHANnel:STARt {<NRF>[A] MIN MAX}	
Parameter	<NRF>[A]	The current value in Amps.
	MAX	The maximum current value.
	MIN	The minimum current value.
Example	:OCP:CHAN:STAR MIN Set the start current to the minimum.	
Query Syntax	:OCP:CHANnel:STARt?[MIN MAX]	
Return Parameter	<NR2>	Returns the starting current in Amps.
Query Example	:OCP:CHAN:STAR? MIN Returns the minimum starting current. 1.5	

:OCP:CHANnel:END Channel Specific Command

Description	Sets the ending current value for the test. The value must be higher than the DUT OCP value.	
Syntax	:OCP:CHANnel:END{<NRF>[A] MIN MAX}	
Parameter	<NRF>[A]	The current value in Amps.
	MAX	The maximum current value.
	MIN	The minimum current value.
Example	:OCP:CHAN:END MIN	Set the ending current to the minimum.
Query Syntax	:OCP:CHANnel:END?	
Return Parameter	<NR2>	Returns the ending current in Amps.
Query Example	:OCP:CHAN:END?	Returns the ending current. 10.0

		Channel Specific Command
:OCP:CHANnel:STEP:CURRent		
Description	Sets the current step resolution for the OCP Test Automation.	
Syntax	:OCP:CHANnel:STEP:CURRent {<NRF>[A] MIN MAX}	
Parameter	<NRF>[A]	The current value in Amps.
	MAX	The maximum current value.
	MIN	The minimum current value.
Example	:OCP:CHAN:STEP :CURRent MIN Set the step resolution to the minimum value.	
Query Syntax	:OCP:CHANnel:STEP:CURRent?	
Return Parameter	<NR2>	Returns the current step resolution in Amps.
Query Example	:OCP:CHAN:STEP:CURR? 0.5 Returns the step resolution.	

		Channel Specific Command
:OCP:CHANnel:LAST		
Description	Queries or sets the current value for after the DUT OCP protection has been activated.	
Syntax	:OCP:CHANnel:LAST {<NRF>[A] MIN MAX}	
Parameter	<NRF>[A]	The current value in Amps.
	MAX	The maximum current value.
	MIN	The minimum current value.
Example	:OCP:CHAN:LAST MAX Set the current value to the maximum value.	
Query Syntax	:OCP:CHANnel:LAST?	
Return Parameter	<NR2>	Returns the current value in Amps.
Query Example	:OCP:CHAN:LAST? 3.0 Returns the current value.	

:OCP:CHANnel:STEP:TIME Channel Specific Command

Description	Queries or sets how long the step time is for the OCP Test Automation.	
Syntax	:OCP:CHANnel:STEP:TIME {<NRf>[S] MIN MAX}	
Parameter	<NRf>[S]	The step time in seconds (50mS~1600S).
	MAX	The maximum step time.
	MIN	The minimum step time.
Example	:OCP:CHAN:STEP:TIME MIN	Set the step time to the maximum value.
Query Syntax	:OCP:CHANnel:STEP:TIME?	
Return Parameter	<NR2>	Returns the step time in seconds.
Query Example	:OCP:CHAN:STEP:TIME? 10.0	Returns the step time.

:OCP:CHANnel:DElay Channel Specific Command

Description	Queries or sets the test delay time for the OCP Test Automation function.	
Syntax	:OCP:CHANnel:DElay {<NRf>[S] MIN MAX}	
Parameter	<NRf>[S]	The delay time in seconds (5mS~160S).
	MAX	The maximum delay time.
	MIN	The minimum delay time.
Example	:OCP:CHAN:DEL MAX	Set the delay time to the maximum value.
Query Syntax	:OCP:CHANnel:DElay?	
Return Parameter	<NR2>	Returns the delay time in seconds.
Query Example	:OCP:CHAN:DEL? 5.0	Returns the delay time.

:OCP:CHANnel:TRIGger Channel Specific Command

Description	Queries or sets the voltage trigger for when the power supply OCP has been triggered.		
Syntax	:OCP:CHANnel:TRIGger {<NRF>[V] MIN MAX}		
Parameter	<NRF>[V]	The trigger voltage level.	
	MAX	The maximum trigger voltage.	
	MIN	The minimum trigger voltage.	
Example	:OCP:CHAN:TRIG MAX	Set the trigger voltage level to the maximum value.	
Query Syntax	:OCP:CHANnel:TRIGger?		
Return Parameter	<NR2>	Returns the trigger voltage level in volts.	
Query Example	:OCP:CHAN:TRIG?	Returns the trigger level. 5.0	

:OCP:CHANnel:ACTive Channel Specific Command

Description	Queries or sets which bit(s) are the active channel for the OCP Test Automation function. More than one channel can be activated based on the bit weight of the parameter.			
Syntax	:OCP:CHANnel:ACTive{<NR1>0~255}			
Parameter	<NR1> (BIT WEIGHT)	Channel number	<NR1> (BIT WEIGHT)	Channel number
	1	1	16	5
	2	2	32	6
	4	3	64	7
	8	4	128	8
Example	:OCP:CHAN:ACT 3	Activates channel 1 and 2.		
Query Syntax	:OCP:CHANnel:ACTive?			

Return Parameter	<NR1> (BIT WEIGHT)	Channel number	<NR1> (BIT WEIGHT)	Channel number
	1	1	16	5
	2	2	32	6
	4	3	64	7
	8	4	128	8

Query Example :OCP:CHAN:ACT? 8 Returns channel 4 as the active channel.

:OCP:STATus?

Query

Description Queries the status of the OCP Test Automation function. Queries which bit(s) are the status of channel for the OCP Test Automation function. More than one channel can be query based on the bit weight of the parameter.

Query Syntax :OCP:STATus?{<NR1>0~255}

Return Parameter	<NR1> (BIT WEIGHT)	Channel number	<NR1> (BIT WEIGHT)	Channel number
	1	1	16	5
	2	2	32	6
	4	3	64	7
	8	4	128	8

Query Example :OCP:STAT? 1 The test has ended

:OCP:SAVE Channel Specific Command

Description Saves the current COP Test Automation parameters.

Syntax :OCP:SAVE

:OCP:RESult?

Query

Description	Returns the OCP Test Automation results.	
Query Syntax	:OCP:RESult?	
Query Example	:OCP:RES? Ch1 OCP Voltage, Ch1 OCP Current, Ch2 OCP Voltage, Ch2 OCP Current, Ch3 OCP Voltage, Ch3 OCP Current, Ch4 OCP Voltage, Ch4 OCP Current, Ch5 OCP Voltage, Ch5 OCP Current, Ch6 OCP Voltage, Ch6 OCP Current, Ch7 OCP Voltage, Ch7 OCP Current, Ch8 OCP Voltage, Ch8 OCP Current	This is an example of the results that are returned for the PEL- 2004B.

:OCP:RUN

Command

Description	Turns the OCP Test Automation function on or off.	
Syntax	:OCP:RUN { 0 OFF 1 ON }	
Parameter	0/OFF	Turn off.
	1/ON	Turn on.
Example	:OCP:RUN OFF	Turn the test off.

:OCP:KEEP

Command

Description	Sets or queries how long the keep time is for the OCP Test Automation.	
Syntax	:OCP:CHANnel:KEEP{<NRF>[S] MIN MAX}	
Parameter	<NRF>[S]	The keep time in seconds (0S~160S).
	MaX	The maximum keep time.

	MIN	The minimum keep time.
Example	OCP:KEEP :MAX 160	Set the step time to the maximum value.
Query Syntax	:OCP:KEEP?	
Return Parameter	<NR2>	Keep the step time in seconds.
Query Example	OCP:KEEP? 5.0	Keep the step time.

Program Subsystem

:PROGram:STATe	108
:PROGram:FILE	109
:PROGram:SEQuence	110
:PROGram:MEMory	110
:PROGram:SEQuence:SHORt:CHANnel	111
:PROGram:SEQuence:SHORt:TIME	111
:PROGram:SEQuence:MODE	112
:PROGram:ACTive	113
:PROGram:CHAin	114
:PROGram:ONTime	114
:PROGram:OFFTime	115
:PROGram:RUN	115
:PROGram:SAVE	116
:PROGram:PFTime	116
:PROGram:CHAin:STARt	116

:PROGram:STATe Program Number
Specific

Description	Sets or queries the state of the program function.	
Syntax	:PROGram:STATe {ON OFF PAUSE CONTINUE NEXT}	
Query Syntax	:PROGram:STATe? {ON,STOP ON,PAUSE ON, RUN OFF}	
Parameter	ON	Turn program on. The command “:RUN” can be used to active the program. And, the command “:ABORT” can be used to abort the program.
	OFF	Turn program off. The system will return back to normal operation.

	PAUSE	Program pause. This command is available for any mode on sequence mode of program.
	NEXT	Next step in the program. This command is available only for the current sequence mode of program set to manual and the execution time of current sequence is out.
	CONTINUE	Program continue. This command is available for any mode of the program sequence under "PAUSE" event.
Return Parameter	ON, STOP	Program is on, stopped
	ON, PAUSE	Program is paused
	ON, RUN	Program is running
	OFF	Program is off
Example	:PROG:STATe ON Turns "Program" on.	
Query example	:PROG:STATe? >OFF "Program" is off.	

:PROG:FILE		Program Number Specific
Description	Sets the program number.	
Syntax	:PROG:FILE <NR1>	
Parameter	<NR1>	Program number
	1~12	Number 1~12
Example	:PROG:FILE 5	Sets the program number to 5.
Query Syntax	:PROG:FILE?	
Return Parameter	<NR1>	Mainframe Scanning

1-12	Returns the current program number
------	------------------------------------

Query Example :PROG:FILE? 5 The set program number is 5.

:PROG:SEQ Program Number Specific

Description	Sets the Sequence number for the current program number.
-------------	--

Syntax	:PROG:SEQ <NR1>
--------	-----------------

Parameter	<NR1> Sequence number
	1~10 Number 1~10

Example	:PROG:SEQ 1 Sets the sequence number to 1 for the current program number.
---------	--

Query Syntax	:PROG:SEQ?
--------------	------------

Return Parameter	<NR1> Mainframe Scanning
	1-10 Returns the current sequence number

Query Example :PROG:SEQ? 1 The set sequence number is 1.

:PROG:MEM Program Number Specific

Description	Sets the memory number used for the current program/sequence.
-------------	---

Syntax	:PROG:MEM <NR1>
--------	-----------------

Parameter	<NR1> Memory number
	1~120 Number 1~120

Example	:PROG:MEM 1 Sets the memory number to 001.
---------	---

Query Syntax	:PROG:MEM?
--------------	------------

Return Parameter	<NR1> Mainframe Scanning
	1-120 Returns the current program number

Query Example :PROG:MEM? The memory number for the
1 current program/sequence is 001.

:PROG:SEQ:SHORT:CHANnel Program Number
Specific

Description Simulates short circuits for load channels for the
current sequence number.

Syntax :PROG:SEQ:SHORT:CHANnel<NR1>

Parameter	<NR1> (BIT WEIGHT)	Channel number	<NR1> (BIT WEIGHT)	Channel number
	1	1	16	5
	2	2	32	6
	4	3	64	7
	8	4	128	8

Example :PROG:SEQ:SHOR:CHAN Simulates a short circuit
12 for channels 3 and 4.

Query Syntax :PROG:SEQ:SHORT:CHANnel?<NR1>

Return Parameter	<NR1> (BIT WEIGHT)	Short Channel number	<NR1> (BIT WEIGHT)	Short Channel number
	1	1	16	5
	2	2	32	6
	4	3	64	7
	8	4	128	8

Query Example :PROG:SEQ:SHOR:CHAN? Returns channels 3 and
12 4 are set as shorted for
the program sequence.

:PROG:SEQ:SHORT:TIME Program Number
Specific

Description Sets the short time (seconds) for the current
program sequence.

Syntax	:PROG:SEQ:SHORT:TIME<NRf>[S]	
Parameter	<NRf>[S]	Short Time
	0.0	0 seconds = OFF
	0.1~60	0.1~60 seconds
	0.1~60S	0.1~60 seconds



Note

The short time value must equal to or small than on time setting value.

Example	:PROG:SEQ:SHOR:TIME 0.5	The short time for the program sequence is set to .5 seconds
---------	----------------------------	--

Query Syntax	:PROG:SEQ:SHORT:TIME? <NR2>	
--------------	-----------------------------	--

Return Parameter	<NR2> 1 unit = 1 second	Short Time
	0.0~60	Returns the short time for the program sequence.

Query Example	:PROG:SEQ:SHOR:TIME? 5	The short time for the program sequence is 5 seconds.
---------------	---------------------------	---

:PROG:SEQ:MODE Program Number Specific

Description	Sets the program sequence to Auto, Manual or Skip mode.	
Syntax	:PROG:SEQ:MODE{MANUAL AUTO SKIP}	
Parameter	MANUAL	Manual mode: program sequence is run manually
	AUTO	Auto mode: program sequence is run automatically
	SKIP	Skip mode: current program sequence is skipped.

Example :PROG:SEQ:MODE AUTO The current program sequence is set to Automatic mode.

Query Syntax :PROG:SEQ:MODE?

Return Parameter	MANUAL	Manual mode: program sequence is run manually under this mode. User may use the command “:PROG:STAT NET” to execute the next program sequence.
	AUTO	Auto mode
	SKIP	Skip mode

Query Example :PROG:SEQ:MODE? AUTO The current program sequence is set to AUTO.

:PROG:ACTIVE Program Number Specific

Description Activates or selects the active load modules.

Syntax :PROG:ACTIVE <NR1>

Parameter	<NR1> (BIT WEIGHT)	Active Channel	<NR1> (BIT WEIGHT)	Active Channel
	1	1	16	5
	2	2	32	6
	4	3	64	7
	8	4	128	8

Example :PROG:ACT 4 Activates channel three.

Query Syntax :PROG:ACTIVE? <NR1>

Return Parameter	<NR1> (BIT WEIGHT)	Active Channel	<NR1> (BIT WEIGHT)	Active Channel
	1	1	16	5
	2	2	32	6
	4	3	64	7

	8	4	128	8
Query Example	:PROG:ACT?		Channels 3 and 4 are active.	
	12			

:PROG:CHAI Program Number Specific

Description Chains the current program number to a specified program number.

Syntax :PROG:CHAI <NR1>

Parameter	<NR1>	Program
	1-12	1-12
	0	No chain/End chain

Example :PROG:CHA 6 Chains the current program number to program number 6

Query Syntax :PROG:CHAI? <NR1>

Return Parameter	<NR1>	Program
	1-12	1-12
	0	No chain/End chain

Query Example :PROG:CHA? Returns the program number the current program is chained to.
6

:PROG:ONTIME Program Number Specific

Description Sets the on-time for the program number. 0.1~60 seconds.

Syntax :PROG:ONTIME <NRf>[S]

Parameter	<NRf>[S]	Program On Time
	0.1-60	0.1~60 seconds
	0.1-60s	0.1~60 seconds

Example :PROG:ONT 10S Set the on-time for the current program number to 10 seconds.

Query Syntax	:PROG:ONTime? <NR2>	
Return Parameter	<NR2>	Program On Time
	0.1-60	0.1~60 seconds
Query Example	:PROG:ONT? 10	Returns the on-time for the current program number in seconds.

:PROG:OFFTime Program Number Specific

Description	Sets the off-time for the program number. 0.1~60 seconds.	
Syntax	:PROG:OFFTime <NRf>[S]	
Parameter	<NRf>[S]	Program Off Time
	0.0	0 seconds = OFF
	0.1~60	0.1~60 seconds
	0.1~60S	0.1~60 seconds
Example	:PROG:OFFT 10S	Set the off-time for the current program number to 10 seconds.
Query Syntax	:PROG:OFFTime? <NR2>	
Return Parameter	<NR2> unit = 1 second	Program Off Time
	0.0~60	0.0~60 seconds
Query Example	:PROG:OFFT? 10	Returns the off-time for the current program number in seconds.

:PROG:RUN All Channel Command

Description	Runs the current program number when set to on, and when set to off will allow all the program/sequence data to be programmed.	
Syntax	:PROG:RUN {OFF 0 ON 1}	
Parameter	OFF/0	OFF
	ON/1	ON

Example :PROG:RUN 1 Runs the program.

:PROG:SAVE All Channel Command

Description Saves the current program to memory.

Syntax :PROG:SAVE

Example :PROG:SAVE Saves the program to memory.

:PROG:PFTime Program Number Specific

Description Sets the P/F-Time (pass/fail time) for the current program sequence in seconds.

Syntax :PROG:PFTime <NRf>[S]

Parameter	<NRf>[S]	P/F Time
	0.0	0 seconds = OFF
	0.1~119.9	0.1~119.9 seconds
	0.1~119.9S	0.1~119.9 seconds

Example :PROG:PFT 0.5 Sets the P/F-Time to .5 seconds

Query Syntax :PROG:PFTime? <NR2>

Return Parameter	<NR2> 1 unit = 1 second	Short Time
	0.0~119.9	Returns the P/F-Time for the program sequence.

Query Example :PROG:PFTime? 5 The P/F-Time is 5 seconds.

:PROG:CHAI:START Program Number Specific

Description Sets or queries which program number is used as the "start" program in a program chain.

Syntax :PROG:CHAI:START<NR1>

Parameter <NR1> Program number

	1-12	1~12
Example	:PROG:CHA:STAR 1	Set program #1 to start the chain.
Query Syntax	:PROG:CHAI:STARt?<NR1>	
Return Parameter	<NR1>	Program number
	1-12	1~12
Query Example	:PROG:CHA:STAR? 5	Program #5 starts the chain.

Resistance Subsystem

:RESistance[:STATic]:L1/L2	118
:RESistance[:STATic]:RISE/FALL	119
:RESistance:STATic:RECall	120
:RESistance:STATic:LOW:AVALue/BVALue	120
:RESistance:STATic:LOW:RISE/FALL	121
:RESistance:STATic:HIGH:AVALue/BVALue	122
:RESistance:STATic:HIGH:RISE/FALL	123
:RESistance:DYNamic:L1/L2	124
:RESistance:DYNamic:RISE/FALL	125
:RESistance:DYNamic:T1/T2	126
:RESistance:DYNamic:LOW:L1/L2	127
:RESistance:DYNamic:LOW:RISE/FALL	127
:RESistance:DYNamic:LOW:T1/T2	128
:RESistance:DYNamic:HIGH:L1/L2	129
:RESistance:DYNamic:HIGH:RISE/FALL	130
:RESistance:DYNamic:HIGH:T1/T2	131

:RESistance[:STATic]:L1/L2	Channel Specific Command
----------------------------	--------------------------

Description	Sets A/B Value for constant resistance mode, where L1 is A Value and L2 is B Value. This command only applies to current mode (static). When setting the A/B value, the device will be switched to CR mode by using this command.	
Syntax	:RESistance[:STATic]:L1/L2<NRf+>[OHM]	
Parameter	NRf+[OHM]	Resistance
	L1 10	Sets A Value to 10 ohms
	L2 20	Sets B Value* to 20 ohms
		*Single Channel
	L1 MIN	Sets A Value to the minimum level for the specific channel.

	L1 MAX	Sets A Value to the maximum level for the specific channel.
Example	:RES:L1 10	Sets CR static mode A Value to 10 ohms, depending on the specific range
Query Syntax	:RESistance[:STATic]:L1/L2? [MAX MIN]	
Return Parameter	<NR2> [MAX MIN]	Resistance
	1 unit = 1 ohm	Returns the resistance of the A or B Value.
	MAX/MIN	Returns the allowable maximum and minimum.
Query Example	:RES:L1? MAX 300	Returns the maximum resistance allowed for the channel. (PEL-2020A)
:RESistance[:STATic]:RISE/FALL		Channel Specific Command
Description	Sets the rising/falling slew rate for CR mode. The command applies to the current mode (static/dynamic) and the current range (High/Low). When setting the A/B value, the device will be switched to CR mode by using this command.	
Syntax	:RESistance[:STATic]:RISE/FALL <NRf+>[A/uS]	
Parameter	<NRf+>[A/uS]	Slew rate
	RISE/FALL 0.8A/uS	Sets the rising/falling slew rate to 0.8A/uS
	RISE/FALL .8	Sets the rising/falling slew rate to 0.8A/uS
	RISE/FALL MIN	Sets to the slowest rising/falling slew rate.
	RISE/FALL MAX	Sets to the fastest rising/falling slew rate.

Example	:RES:RISE 0.1	Sets the rising slew rate to 0.1A/uS.
Query Syntax	:RESistance:RISE/FALL? [MIN MAX]	
Return Parameter	<NR2> [MAX MIN]	Slew rate
	1 Unit = 1 amp/uS	Returns the slew rate.
	MAX/MIN	Returns the allowable maximum and minimum.
Query Example	:RES:RISE? MAX 0.8000	Returns the maximum value for the rising slew rate (0.8 A/uS).

:RESistance:STATic:RECall Channel Specific Command

Description	Sets or queries whether A Value or B Value is the currently active value in CR static mode.	
Syntax	:RESistance:STATic:RECall {A 0 B 1}	
Parameter	A/0	A
	B/1	B
Example	:RES:STAT:REC 1	Makes B Value the active value.
Query Syntax	:RES:STATic:RECall?	
Return Parameter	<NR1>	Value
	0	A
	1	B

:RESistance:STATic:LOW:AVALue/BVALue Channel Specific Command

Description	Sets the low range A/B Value for constant resistance static mode.	
Syntax	:RESistance:STATic:LOW:AVALue/BVALue <NRf+>[OHM]	
Parameter	NRf+[OHM]	Resistance

	AVALue 10	Sets A Value to 10 ohms. (Low range only)
	BVALue 20	Sets B Value to 20 ohms. (Low range only)
	AVALue MIN	Sets A Value to the minimum level for the specific channel.
	AVALue MAX	Sets A Value to the maximum level for the specific channel.

Example :RES:STAT:LOW:BVAL 10 Sets low range CR static mode B Value to 10 ohms.

Query Syntax :RESistance:STATic:LOW:AVALue/BVALue?

Return Parameter	<NR2> [MAX MIN]	Resistance
	1 unit = 1 ohm	Returns the resistance of the A or B Value.

Query Example :RES:STAT:LOW:AVAL? Returns the maximum resistance allowed for the channel. (PEL-2020A)
MAX
300

:RESistance:STATic:LOW:RISE/FALL Channel Specific Command

Description Sets the low range rising/falling slew rate.

Syntax :RESistance:STATic:LOW:RISE/FALL<NRf+>[A/uS]

Parameter	<NRf+>[A/uS]	Slew rate
	RISE/FALL 0.8A/uS	Sets the rising/falling slew rate to 0.8A/uS
	RISE/FALL .8	Sets the rising/falling slew rate to 0.8A/uS
	RISE/FALL MIN	Sets to the slowest rising/falling slew rate.
	RISE/FALL MAX	Sets to the fastest rising/falling slew rate.

Example	:RES:STAT:LOW:RISE 0.1	Sets the rising slew rate to 0.1A/uS.
Query Syntax	:RESistance:STATic:LOW:RISE/FALL?[MIN MAX]	
Return Parameter	<NR2> [MAX MIN] 1 Unit =1 amp/uS MAX, MIN	Slew rate Returns the slew rate. Returns the allowable maximum and minimum.
Query Example	:RES:STAT:LOW:RISE? MAX 0.8000	For low range CR mode, the maximum value for the rising slew rate is 0.8 A/uS for the specific channel.

Channel Specific

:RESistance:STATic:HIGH:AVALue/BVALue Command

Description	Sets the high range A/B Value for constant resistance static mode.	
Syntax	:RESistance:STATic:HIGH:AVALue/BVALue <NRf+>[OHM]	
Parameter	NRf+[OHM] AVALue 10 BVALue 20OHM AVALue MIN AVALue MAX	Sets A Value to 10 ohms. (high range only) Sets B Value to 20 ohms. (high range only) Sets A Value to the minimum level for the specific channel. Sets A Value to the maximum level for the specific channel.
Example	:RES:STAT:HIGH:BVAL 10	Sets high range CR static mode B Value to 10 ohms.
Query Syntax	:RESistance:STATic:HIGH:AVALue/BVALue? [MAX MIN]	

Return Parameter	<NR2> [MAX MIN] 1 unit= 1 ohm	Resistance Returns the resistance of the A or B Value.
Query Example	:RES:STAT:HIGH:BVAL? MAX 15000.0	Returns the maximum resistance allowed for the channel for B Value. (PEL-2020B)
:RESistance:STATic:HIGH:RISE/FALL		Channel Specific Command
Description	Sets the high range rising/falling slew rate.	
Syntax	:RESistance:STATic:HIGH:RISE/FALL<NRf+>[A/uS]	
Parameter	<NRf+>[A/uS] RISE/FALL 0.8A/uS RISE/FALL 0.5 RISE/FALL MIN RISE/FALL MAX	Slew rate Sets the rising/falling slew rate to 0.8A/uS Sets the rising/falling slew rate to 0.5A/uS Sets to the slowest rising/falling slew rate. Sets to the fastest rising/falling slew rate.
Example	:RES:STAT:HIGH:RISE 1.1	Sets the rising slew rate to 1.1A/uS.
Query Syntax	:RESistance:STATic:HIGH:RISE/FALL?[MIN MAX]	
Return Parameter	<NR2> [MAX MIN] 1 Unit=1 amp/uS MAX/MIN	Slew rate Returns the slew rate. Returns the allowable maximum and minimum.
Query Example	:RES:STAT:HIGH:RISE? MIN 0.8000	For high range CR mode, the minimum value for the rising slew rate is 0.8 A/uS for the specific channel.

		Channel Specific Command
:RESistance:DYNamic:L1/L2		
Description	Sets the current levels (Level 1 & 2) for CR dynamic mode. When setting the A/B value, the device will be switched to CRD mode by using this command.	
Syntax	:RESistance:DYNamic:L1/L2 <NRf+>[OHM]	
Parameter	NRf+[OHM]	Resistance
	L1 1	Sets L1 to 1 ohms.
	L2 2	Sets L2 to 2 ohms.
	L2 2A	Sets L2 to 2 ohms.
	L1/L2 MIN	Sets L1 or L2 to the minimum level for the specific channel.
	L1/L2 MAX	Sets L1 or L2 to the maximum level for the specific channel.
Example	:RES:DYN:L1 10	In CR dynamic mode, Set L1 (level 1) to 10 ohms.
Query Syntax	:RESistance:DYNamic:L1/L2?[MIN MAX]	
Return Parameter	<NR2> [MAX MIN]	Resistance
	MAX/MIN	Returns the allowable maximum and minimum
	1 unit = 1 ohm	Returns the current of L1/L2, or the maximum or minimum current allowed.
Query Example	:RES:DYN:L2? 2.0400	Returns current for the specific channel.

		Channel Specific Command
:RESistance:DYNamic:RISE/FALL		
Description	Sets the rising/falling slew rate for CR dynamic mode for the specific channel and range. When setting the A/B value, the device will be switched to CRD mode by using this command.	
Syntax	:RESistance:DYNamic:RISE/FALL<NRf+>[A/uS]	
Parameter	<NRf+>[A/uS]	Slew Rate
	RISE/FALL 0.8A/uS	Sets the rising/falling slew rate to 0.8A/uS
	RISE/FALL 1	Sets the rising/falling slew rate to 1A/uS
	RISE/FALL MIN	Sets to the slowest rising/falling slew rate.
	RISE/FALL MAX	Sets to the fastest rising/falling slew rate.
Example	:RES:DYNA:RISE 1.1	Sets the rising slew rate to 1.1A/uS.
Query Syntax	:RESistance:DYNamic:RISE/FALL? [MIN MAX]	
Return Parameter	<NR2> [MAX MIN]	Slew rate
	1 Unit =1 amp/uS	Returns the slew rate.
	MAX/MIN	Returns the allowable maximum and minimum.
Query Example	:RES:DYN:FALL? MIN 0.0003	Shows the minimum allowable value for the falling slew rate as 0.0003 A/uS for the specific channel.

		Channel Specific Command
:RESistance:DYNamic:T1/T2		
Description	Sets the timers T1 or T2 for CR dynamic mode for the specific channel and range. When setting the A/B value, the device will be switched to CRD mode by using this command.	
Syntax	:RESistance:DYNamic:T1/T2<NRf+>[S][ms]	
Parameter	<NRf+>[S]	Time
	T1/T2 0.1S	Sets the T1/T2 time to 0.1 seconds.
	T1/T2 1	Sets the T1/T2 time to 1 second.
	T1/T2 MIN	Sets the T1/T2 time to the minimum value.
	T1/T2 MAX	Sets the T1/T2 time to the maximum value.
Example	:RES:DYN:T1 .1S	Sets the T1 time to 100 milliseconds for the specific channel.
Query Syntax	:RESistance:DYNamic:T1/T2?[MIN MAX]	
Return Parameter	<NR2> [MAX MIN]	Time
	1 unit = 1 second	Returns the T1/T2 time.
	MAX/MIN	Returns the allowable maximum and minimum.
Query Example	:RES:DYN:T1? 2.5	Returns the T1 time of 2.5 seconds.
	:RES:DYN:T1? MIN 0.000025	Returns the minimum T1 time allowable for the specific channel and range.

:RESistance:DYNamic:LOW:L1/L2 Channel Specific Command

Description	Sets the low range resistance levels (Level 1 & 2) for CR dynamic mode.	
Syntax	:RESistance:DYNamic:LOW:L1/L2 <NRf+>[OHM]	
Parameter	NRf+[OHM]	Ohms
	L1 10	Sets L1 to 10 ohms. (low range only)
	L2 20OHM	Sets L2 to 20 ohms. (low range only)
	L1/L2 MIN	Sets L1 or L2 to the minimum level for the specific channel.
	L1/L2 MAX	Sets L1 or L2 to the maximum level for the specific channel.
Example	:RES:DYN:LOW:L1 10	In low range CR dynamic mode, Set L1 (level 1) to 10 ohms.
Query Syntax	:RESistance:DYNamic:LOW:L1/L2?[MIN MAX]	
Return Parameter	<NR2> [MAX MIN]	Resistance
	1 unit = 1 ohm	Returns the resistance of L1/L2.
Query Example	:RES:DYN:LOW:L2? MAX 300	Returns the maximum resistance allowed for the channel. (PEL-2020A)

:RESistance:DYNamic:LOW:RISE/FALL Channel Specific Command

Description	Sets the low range rising/falling slew rate for CR dynamic mode for the specific channel.	
Syntax	:RESistance:DYNamic:LOW:RISE/FALL <NRf+>[A/uS]	
Parameter	<NRf+>[A/uS]	Slew Rate

	RISE/FALL 0.8A/uS	Sets the rising/falling slew rate to 0.8A/uS
	RISE/FALL .1	Sets the rising/falling slew rate to 0.1A/uS
	RISE/FALL MIN	Sets to the slowest rising/falling slew rate.
	RISE/FALL MAX	Sets to the fastest rising/falling slew rate.
Example	:RES:DYNA:LOW:RISE 0.1	Sets the rising slew rate to ~ 0.1A/uS.
Query Syntax	:RESistance:DYNamic:LOW:RISE/FALL? [MIN MAX]	
Return Parameter	<NR2> [MAX MIN]	Slew rate
	1 Unit =1 amp/uS	Returns the slew rate.
	MAX/MIN	Returns the allowable maximum and minimum.
Query Example	:RES:DYN:LOW:FALL? MIN 0.8000	For low range dynamic CR mode, the minimum value for the falling slew rate is 0.8 A/uS for the specific channel.

:RESistance:DYNamic:LOW:T1/T2 Channel Specific Command

Description	Sets the timers T1 or T2 for CR dynamic mode for the specific channel in low range.	
Syntax	:RESistance:DYNamic:LOW:T1/T2<NRf+>[S][ms]	
Parameter	<NRf+>[S]	Time T1/T2
	T1/T2 0.1S	Sets the T1/T2 time to 0.1 seconds.
	T1/T2 1	Sets the T1/T2 time to 1 second.
	T1/T2 MIN	Sets the T1/T2 time to the minimum value.

	T1/T2 MAX	Sets the T1/T2 time to the maximum value.
Example	:RES:DYNA:LOW:T1 10S	Sets the T1 time to 10 seconds for the specific channel.
Query Syntax	:RESistance:DYNamic:T1/T2? [MIN MAX]	
Return Parameter	<NR2> [MAX MIN] 1 Unit =1 second MAX/MIN	Time T1/T2 Returns T1/T2 time. Returns the allowable maximum and minimum.
Query Example	:RES:DYN:LOW:T1? 2.5 :CURR:DYN:LOW:T1? MIN 0.000025	Returns the T1 time of 2.5 seconds. Returns the minimum T1 time allowable for the specific channel.

:RESistance:DYNamic:HIGH:L1/L2 Channel Specific Command

Description	Sets the high range resistance levels (Level 1 & 2) for CR dynamic mode.	
Syntax	:RESistance:DYNamic:HIGH:L1/L2 <NRf+>[OHM]	
Parameter	NRf+[OHM]	Resistance
	L1 10	Sets L1 to 10 ohms. (high range only)
	L2 20OHM	Sets L2 to 20 ohms. (high range only)
	L1/L2 MIN	Sets L1 or L2 to the minimum level for the specific channel.
	L1/L2 MAX	Sets L1 or L2 to the maximum level for the specific channel.

Example :RES:DYN:HIGH:L1 10 In high range CR dynamic mode, Set L1 (level 1) to 10 ohms.

Query Syntax :RESistance:DYNamic:HIGH:L1/L2? [MIN|MAX]

Return Parameter <NR2> [MAX|MIN] Resistance
 1 unit = 1 ohm Returns the resistance of Level 1/ 2 (L1/L2).

Query Example :RES:DYN:HIGH:L2? MAX Returns the maximum resistance allowed for the channel. (PEL-2020B)
 15000.0

:RESistance:DYNamic:HIGH:RISE/FALL Channel Specific Command

Description Sets the high range rising/falling slew rate for CR dynamic mode for the specific channel.

Syntax :RESistance:DYNamic:HIGH:RISE/FALL <NRf+>[A/uS]

Parameter <NRf+>[A/uS] Slew Rate
 RISE/FALL 0.8A/uS Sets the rising/falling slew rate to 0.8A/uS
 RISE/FALL 1 Sets the rising/falling slew rate to 1A/uS
 RISE/FALL MIN Sets to the slowest rising/falling slew rate.
 RISE/FALL MAX Sets to the fastest rising/falling slew rate.

Example :RES:DYN:HIGH:RISE 1.1 Sets the rising slew rate to 1.1A/uS.

Query Syntax :RESistance:DYNamic:HIGH:FALL? [MIN|MAX]

Return Parameter <NR2> [MAX|MIN] Slew rate
 1 Unit =1 amp/uS Returns the slew rate.

	MAX/MIN	Returns the allowable maximum and minimum.
Query Example	:RES:DYN:HIGH:FALL? MAX 0.8000	For high range dynamic CR mode, the minimum value for the falling slew rate is 0.8 A/uS for the specific channel.
:RESistance:DYNamic:HIGH:T1/T2		Channel Specific Command
Description	Sets the timers T1 and T2 for high range dynamic CR mode.	
Syntax	:RESistance:DYNamic:HIGH:T1/T2 <NRf+>[S ms]	
Parameter	<NRf+>[S]	Timer T1/T2
	T1/T2 0.1S	Sets the T1/T2 time to 0.1 seconds.
	T1/T2 1	Sets the T1/T2 time to 1 second.
	T1/T2 MIN	Sets the T1/T2 time to the minimum value.
	T1/T2 MAX	Sets the T1/T2 time to the maximum value.
Example	:RES:DYNA:HIGH:T1 10S	Sets the high range T1 time to 10 seconds for the specific channel.
Query Syntax	:RESistance:DYNamic:HIGH:T1/T2? [MIN MAX]	
Return Parameter	<NR2> [MAX MIN]	T1/T2 time.
	1 Unit =1 second	Returns T1/T2 time.
	MAX/MIN	Returns the allowable maximum and minimum.

Query Example	:RES:DYN:HIG: T1?	Returns the T1 time of
	2.5	2.5 seconds.
	:RES:DYN:LOW: T1? MIN	Returns the minimum T1
	0.000025	time allowable for the specific channel.

RUN Subsystem

:RUN All Channel
Command

Description Turns on all the electronic loads.

Syntax :RUN

Example :RUN Turns on all electronic loads.

SHOW Subsystem

:SHOW[:DISPlay] dual channel 134
 :SHOW[:DISPlay] single channel 135

:SHOW[:DISPlay] dual channel Channel Specific Command
 (Dual channel module)

Description	Sets the display mode of the load module of the specific channel.	
Syntax	:SHOW:DISPlay {LVI LVW LIW RVI RVW RIW LRV LRI LRW LRS LIRV LVRI}	
Parameter	LVI	Left channel, voltage/current
	LVW	Left channel, voltage/power
	LIW	Left channel, current/power
	RVI	Right channel, voltage/current
	RVW	Right channel, voltage/power
	RIW	Right channel, current/power
	LRV	Left and right channel voltage
	LRI	Left and right channel current
	LRW	Left and right channel power
	LRS	Left and right channel load on time
	LIRV	Left channel current, right channel voltage
	LVRI	Left channel voltage, right channel current

Example :SHOW:DISP LVI Show the left channel voltage and current on the load module display.

:SHOW[:DISPlay] single channel Channel Specific Command
 (Single channel module)

Description Sets the display mode of the load module of the specific channel.

Syntax :SHOW:DISPlay {VI|VW|IW|S}

Parameter	VI	Voltage/current
	VW	Voltage/power
	IW	Current/power
	S	Load on time

Example :SHOW:DISP VI Shows voltage and current on the load module display.

SPECIFICATION Subsystem

:SPECification:UNIT	136
:SPECification[:PASS]?	137
:SPECification[:PASS]:CHANnel/ ALLChannel/VOLTage/CURRent?	137
:SPECification:VOLTage:H/L/C.....	138
:SPECification:CURRent:H/L/C.....	138
:SPECification:TEST:.....	139
:SPECification:DElay.....	139

:SPECification:UNIT		Channel Specific Command
Description	Sets the Go/NoGo (specification) units as percentages or values.	
Syntax	:SPECification:UNIT {PERCENT 0 VALUE 1}	
Parameter	PERCENT/0	Percentages
	VALUE/1	Values
Example	:SPEC:UNIT PERCENT	Sets the Go/NoGo limits as percentages
Query Syntax	:SPECification:UNIT? <NR1>	
Return Parameter	<NR1>	Go/NoGo Unit
	0	Percent
	1	Value
Query Example	:SPEC:UNIT? 0	The Go/NoGo (specification) units are set as percent.

:SPECification[:PASS]? Channel Specific Command

Description Displays if the Go/NoGo (specification) limit has passed/failed for the current channel used.

Query Syntax :SPECification[:PASS]?

Return Parameter	<NR1>	Go/NoGo Specification
	0	Fail
	1	Pass

Query Example	:SPEC:PASS?	Go/NoGo has failed
	0	

Query Example	:SPEC?	Go/NoGo has failed
	0	

**:SPECification[:PASS]:CHANnel/
ALLChannel/VOLTage/CURRent?** Channel Specific Command

Description Queries if the voltage, current, current channel or all channels have passed/failed the Go/NoGo (specification) limits.
 VOLTage→CC, CR mode,
 CURRent→CV, CP mode

Query Syntax :SPECification[:PASS]:CHANnel/ALLChannel/VOLTage/CURRent?

Return Parameter	<NR1>	Go/NoGo Specification
	0	Fail
	1	Pass

Query Example	:SPEC:PASS:VOLT?	The test has exceeded the Go/NoGo voltage limits.
	0	

Query Example	:SPEC:VOLT?	The test has exceeded the Go/NoGo voltage limits.
	0	

:SPECification:VOLTage:H/L/C Channel Specific Command

Description Sets the high (H), low (L) and center (C) Go/NoGo voltage limit specifications. Applicable to CC and CR mode only. The high (H) setting value must be greater than or equal to center (C) and the center (C) setting value will be greater than or equal to low (L).

Syntax :SPECification:VOLTage:{H|L|C}<NRf+>[V]

Parameter	<NRf+>[V] 1 unit = 1 volt	Go/NoGo voltage limit
1		1 volt
1V		1 volt

Example :SPEC:VOLT:H 2V Sets the Go/NoGo high voltage limit to 2 volts.

Query Syntax :SPECification:VOLTage:{H|L|C}?

Return Parameter	<NR2>	Go/NoGo voltage
	1 unit = 1 volt	Returns the limit voltage

Query Example :SPEC:VOLT:H? The voltage limit is 2 volts.
2.000

:SPECification:CURRent:H/L/C Channel Specific Command

Description Sets the high (H), low(L) and center (C) Go/NoGo current limit specifications. Applicable to CV and CP mode only. The high (H) setting value must be greater than or equal to center (C) and the center (C) setting value will be greater than or equal to low (L).

Syntax :SPECification:CURRent:{H|L|C}<NRf+>[A]

Parameter	<NRf+>[A] 1 unit = 1 amp	Go/NoGo current limit
1		1 amp
1A		1 amp

Example	:SPEC:CURR:H 1A	Sets the Go/NoGo high current limit to 1 amp.
---------	-----------------	---

Query Syntax	:SPECification:CURRENT:{H L C}?	
--------------	---------------------------------	--

Return Parameter	<NR2> 1 unit = 1 amp	Go/NoGo voltage Returns the limit current
------------------	-------------------------	--

Query Example	:SPEC:CURR:H? 5.120	The current limit is 5.12 amps.
---------------	------------------------	---------------------------------

Channel Specific Command

:SPECification:TEST:

Description	Turns the Go/NoGo specification (SPEC) limits on/off.	
-------------	---	--

Syntax	:SPECification:TEST {OFF 0 ON 1}	
--------	----------------------------------	--

Parameter	OFF/0 ON/1	OFF ON
-----------	---------------	-----------

Example	:SPEC:TEST OFF	Turn Go/NoGo SPEC off for the specific channel.
---------	----------------	---

Query Syntax	:SPECification:TEST?	
--------------	----------------------	--

Return Parameter	<NR1> 0 1	Go/NoGo SPEC status Off On
------------------	-----------------	----------------------------------

Query Example	:SPEC:TEST? 1	Go/NoGo SPEC limits is on.
---------------	------------------	----------------------------

Channel Specific Command

:SPECification:DElay

Description	It is "Delay Time" setting and query commands.	
-------------	--	--

Syntax	:SPECification:DElay <NR2>[S]	
--------	-------------------------------	--

Parameter	<NR2>[S] 5	Time Set Delay time to 5 seconds.
-----------	---------------	--------------------------------------

Example	:SPECification:DElay	Set Delay time to 0.5 seconds. 0.5
Query Syntax	:SPECification:DElay?	
Return Parameter	<NR2>[S] 1unit =1 second	Time Set Delay time to 1 second.
Query Example	:SPECification:DElay? 1	Returns the delay time in seconds.

STATUS Subsystem

:STATus:CHANnel:CONDition?	141
:STATus:CHANnel:ENABLE	142
:STATus:CHANnel:EVENT?	142
:STATus:CHANnel:NTRansition/PTRansition	143
:STATus:CSUMmary:ENABLE	144
:STATus:CSUMmary:EVENT?	145
:STATus:QUEStionable:CONDition?	145
:STATus:QUEStionable:ENABLE	146
:STATus:QUEStionable[:EVENT?]	146
:STATus:QUEStionable:NTRansition/PTRansition	147
:STATus:PREset	148

:STATus:CHANnel:CONDition?	Channel Specific Command
----------------------------	-----------------------------

Description	Returns the status of the Channel Status Condition Register. The returned value is the bit weight of the Channel Status Condition Register. See page 189 for details.
-------------	---

Query Syntax	:STATus:CHANnel:CONDition?<NR1>
--------------	---------------------------------

Return Parameter	<NR1>	Condition	<NR1>	Condition
	1	OC	16	OT
	2	OV	32	G/N
	4	OP	64	UVP
	8	RV	128~65535	Not Used

Query Example	:STAT:CHAN:COND? 3	Indicates OC and OV conditions are true.
---------------	-----------------------	--

:STATus:CHANnel:ENABLE Channel Specific Command

Description Sets which events are enabled in the Channel Status Enable register. The mask values are the bit weights of the Channel Status Enable Register. See page 189 for details.

Syntax :STATus:CHANnel:ENABLE <NR1>

Parameter	<NR1>	Event	<NR1>	Event
	1	OC	16	OT
	2	OV	32	G/N
	4	OP	64	UVP
	8	RV	128~65535	Not Used

Example :STAT:CHAN:ENAB 12 Events OP (Bit 3) and RV (Bit 4) are enabled in the Channel Status Enable register.

Query Syntax :STATus:CHANnel:ENABLE? <NR1>

Return Parameter	<NR1>	Event	<NR1>	Event
	1	OC	16	OT
	2	OV	32	G/N
	4	OP	64	UVP
	8	RV	128~65535	Not Used

Query Example :STAT:CHAN:ENAB? 4 The OP event is enabled.

:STATus:CHANnel:EVENT? Channel Specific Command

Description Returns the status of the Channel Status Event register for the specific channel. The Channel Status Event register is cleared upon reading.

Query Syntax :STATus:CHANnel:EVENT? <NR1>

Return Parameter	<NR1>	Event	<NR1>	Event
	1	OC	16	OT
	2	OV	32	G/N
	4	OP	64	UVP
	8	RV	128~65535	Not Used

Query Example :STAT:CHAN:EVEN?
1
An over current (OC) event occurred since the last time the Channel Status Event register was read.

:STATus:CHANnel:NTRansition/
PTRansition Channel Specific
Command

Description Determines whether a negative transition (NTR 1→0) or positive (PTR 0→1) transition in the Channel Status Condition register will set the corresponding event in the Channel Status Event register.
The mask values are the bit weights of the Channel Status PTR/NTR filters. See page 189 for details.

Syntax :STATus:CHANnel:NTRansition/PTRansition<NR1>

Parameter	<NR1>	Condition	<NR1>	Condition
	1	OC	16	OT
	2	OV	32	G/N
	4	OP	64	UVP
	8	RV	128~65535	Not Used

Example :STAT:CHAN:NTR 12 OP (Bit 3) and RV (Bit 4) are set as negative transitions.
:STAT:CHAN:PTR 1 OC (Bit 1) is set as a positive transition.

Query Syntax	:STATus:CHANnel:NTRansition/PTRansition?<NR1>			
Return Parameter	<NR1>	Event	<NR1>	Event
	1	OC	16	OT
	2	OV	32	G/N
	4	OP	64	UVP
	8	RV	128~65535	Not Used
Query Example	:STAT:CHAN:NTR? 4	OP is set as a negative transition.		

:STATus:CSUMmary:ENABLE Channel Specific Command

Description Determines which channels in the Channel Summary Register group can set the CSUM bit of the Status Byte Register. The mask values are the bit weights of each corresponding channel in the Channel Summary Enable Register. See page 191 for details.

Syntax :STATus:CSUMmary:ENABle <NR1>

Parameter	<NR1>	Event	<NR1>	Event
	1	CH1	16	CH5
	2	CH2	32	CH6
	4	CH3	64	CH7
	8	CH4	128	CH8

Example :STAT:CSUM: 3 Events from channel 1 and 2 are enabled

Query Syntax :STATus:CSUMmary:ENABle? <NR1>

Return Parameter	<NR1>	Event	<NR1>	Event
	1	CH1	16	CH5
	2	CH2	32	CH6
	4	CH3	64	CH7
	8	CH4	128	CH8

Query Example :STAT:CSUM:ENAB?
4
Only the events from channel 3 can set the CSUM bit in the Status Byte Register.

:STATus:CSUMmary:EVENT? Channel Specific Command

Description Returns the status of the Channel Summary Event register. The Channel Summary Event register is cleared upon reading.

Query Syntax :STATus:CSUMmary:EVENT? <NR1>

Return Parameter	<NR1>	Event	<NR1>	Event
	1	CH1	16	CH5
	2	CH2	32	CH6
	4	CH3	64	CH7
	8	CH4	128	CH8

Query Example :STAT:CSUM:EVENT?
4
An event from channel 3 occurred since the last time the Channel Summary Event register was read.

:STATus:QUEStionable:CONDition? Channel Specific Command

Description Returns the status of the Questionable Status Condition register for the specific channel. See page 191 for details.

Query Syntax :STATus:QUEStionable:CONDition? <NR1>

Return Parameter	<NR1>	Condition	<NR1>	Condition
	1	OC	16	OT
	2	OV	32	G/N
	4	OP	64	UVP
	8	RV	128~65535	Not used

Query Example :STAT:QUES:COND? 2 OV (overvoltage) error.

:STATus:QUESTionable:ENABLE Channel Specific Command

Description Sets which events are enabled in the Questionable Status Enable register. The mask values are the bit weights of the events. See page 191 for details.

Syntax :STATus:QUESTionable:ENABLE <NR1>

Parameter	<NR1>	Event	<NR1>	Event
	1	OC	16	OT
	2	OV	32	G/N
	4	OP	64	UVP
	8	RV	128~65535	Not used

Example :STAT:QUES:ENAB 12 Events OP (Bit 3) and RV (Bit 4) are enabled in the Questionable Status Enable register.

Query Syntax :STATus:QUESTionable:ENABLE? <NR1>

Return Parameter	<NR1>	Event	<NR1>	Event
	1	OC	16	OT
	2	OV	32	G/N
	4	OP	64	UVP
	8	RV	128~65535	Not used

Query Example :STAT:QUES:ENAB? 4 The OP event is enabled.

:STATus:QUESTionable[:EVENT]? Channel Specific Command

Description Returns the status of the Questionable Status Event register. The Questionable Status Event register is cleared upon reading.

Query Syntax	:STATus:QUEStionable[:EVENT]? <NR1>			
Return Parameter	<NR1>	Event	<NR1>	Event
	1	OC	16	OT
	2	OV	32	G/N
	4	OP	64	UVP
	8	RV	128~65535	Not used
Query Example	:STAT:QUES:EVEN? 1	An over current (OC) event occurred since the last time the Questionable Status Event register was read.		

**:STATus:QUEStionable:NTRansition/
PTRansition** Channel Specific
Command

Description Determines whether a negative transition (NTR 1→0) or positive (PTR 0→1) transition in the Questionable Status Condition register will set the corresponding event in the Questionable Status Event register.

The mask values are the bit weights of the Questionable Status PTR/NTR filters. See page 191 for details.

Syntax	:STATus:QUEStionable:NTRansition/PTRansition <NR1>			
Parameter	<NR1>	Condition	<NR1>	Condition
	1	OC	16	OT
	2	OV	32	G/N
	4	OP	64	UVP
	8	RV	128~65535	Not used
Example	:STAT:QUES:NTR 5	OC (Bit 1) and OP (Bit 3) are set as negative transitions.		

:STAT:CHAN:PTR 2 OV (Bit 2) is set as a positive transition.

Query Syntax :STATus:QUESTionable:NTRansition/PTRansition? <NR1>

Return Parameter	<NR1>	Event	<NR1>	Event
	1	OC	16	OT
	2	OV	32	G/N
	4	OP	64	UVP
	8	RV	128~65535	Not used

Query Example :STAT:QUES:NTR? 4 Returns which conditions (OP) have negative transitions.

:STATus:PREset Channel Specific Command

Description The status preset command resets the Enable registers and NTR/PTR registers from the Channel Status and Questionable Status Register groups.

Preset	Register	Preset
	Channel Status Enable	All bits set to 1
	Channel Status PTR	All bits set to 1
	Channel Status NTR	All bits set to 0
	Questionable Status Enable	All bits set to 0
	Questionable Status PTR	All bits set to 1
	Questionable Status NTR	All bits set to 0

Syntax :STATus:PREset

Example :STAT:PRE

Voltage Subsystem

:VOLTage:L1/L2.....	149
:VOLTage:RECall.....	150
:VOLTage:AVALue/BVALue.....	150
:VOLTage:LOW:CURRent.....	151
:VOLTage:HIGH:CURRent.....	152
:VOLTage:MODE.....	153
:VOLTage:LOW:AVALue/BVALue.....	154
:VOLTage:HIGH:AVALue/BVALue.....	154
:VOLTage:IMEasure.....	155

:VOLTage:L1/L2	Channel Specific Command
-----------------------	-----------------------------

Description	Sets the voltage of A Value or B Value in CV mode, where L1 is A Value and L2 is B Value. When setting the A/B value, the device will be switched to CV mode by using this command.	
Syntax	:VOLTage:L1/L2<NRf+>[V]	
Parameter	<NRf+>[V]	Voltage
	10	10 volts
	10V	10 volts
	MIN	Sets the voltage to the minimum value for the channel
	MAX	Sets the voltage to the maximum value for the channel
Example	:VOLT:L1 10V	Sets A Value to 10 volts for the specific channel
	:VOLT:L2 MAX	Sets B Value to the maximum allowed voltage for the specific channel.
Query Syntax	:VOLTage:L1/L2? [MAX MIN]	

Return Parameter	<NR2> 1 unit = 1 volt	Voltage
	10	Returns the voltage of the specific channel.
	MAX/MIN	Returns the allowable maximum and minimum.

Query Example	:VOLT:L1? 5	A Value is set to 5 volts.
	:VOLT:L1? MAX 81.6000	Returns the maximum settable voltage.

:VOLTage:RECall Channel Specific Command

Description	Sets or queries whether A Value or B Value is the currently active value in CV mode.	
Syntax	:VOLTage:RECall {A 0 B 1}	
Parameter	A/0	A
	B/1	B
Example	:VOLT:REC 1	Makes B Value the active value.
Query Syntax	:VOLTage:RECall?	
Return Parameter	<NR1>	Value
	0	A
	1	B

:VOLTage:AVALue/BVALue Channel Specific Command

Description	Sets the voltage of A Value or B Value in CV mode. When setting the A/B value, the device will be switched to CV mode by using this command.	
Syntax	:VOLTage:AVALue/BVALue<NRf+>[V]	
Parameter	<NRf+>[V]	Voltage
	10	10 volts

	10V	10 volts
	MIN	Sets the voltage to the minimum value for the channel
	MAX	Sets the voltage to the maximum value for the channel

Example :VOLT:AVAL 10V Sets A Value to 10 volts for the specific channel

 :VOLT:BVAL MAX Sets B Value to the maximum allowed voltage for the specific channel. (single channel only)

Query Syntax :VOLTage:AVALue/BVALue? [MAX|MIN]

Return Parameter	<NR2> 1 unit = 1 volt	Voltage
	10	Returns the voltage of the specific channel.
	MAX/MIN	Returns the allowable maximum and minimum.

Query Example :VOLT:AVAL? A Value is set to 5 volts.
5

 :VOLT:AVAL? MAX Returns the maximum settable voltage.
81.6000

:VOLTage:LOW:CURRent Channel Specific Command

Description Sets the current limit in CV mode. When setting the A/B value, the device will be switched to CV mode by using this command.

Syntax :VOLTage:LOW:CURRent<NRf+>[A]

Parameter	<NRf+>[A]	Current limit
	1	1 Amp
	1A	1 Amp
	MIN	Sets the current limit to the minimum value for the channel

	MAX	Sets the current limit to the maximum value for the channel
Example	:VOLT:LOW:CURRENt 1A	Sets the current limit to 1 Amp for the specific channel.
	:VOLT:LOW:CURRENt MAX	Sets the current limit to the maximum limit for the specific channel.
Query Syntax	:VOLTage:LOW:CURRENt? [MAX MIN]	
Return Parameter	<NR2> 1 unit = 1 amp	Current limit
	1	Returns the current limit of the specific channel.
	MAX/MIN	Returns the allowable maximum and minimum.
Query Example	:VOLT:LOW:CURRENt? 5	The current limit is 5 amps for the specific channel.
:VOLTage:HIGH:CURRENt		Channel Specific Command
Description	Sets the current limit in CV mode. When setting the A/B value, the device will be switched to CV mode by using this command.	
Syntax	:VOLTage:HIGH:CURRENt<NRf+>[A]	
Parameter	<NRf+>[A]	Current limit
	1	1 Amp
	1A	1 Amp
	MIN	Sets the current limit to the minimum value for the channel
	MAX	Sets the current limit to the maximum value for the channel
Example	:VOLT:HIGH:CURRENt 1A	Sets the current limit to 1 Amp for the specific channel.

:VOLT:HIGH:CURR Sets the current limit to the maximum limit for the specific channel.
MAX

Query Syntax	:VOLTage:HIGH:CURRENT? [MAX MIN]	
Return Parameter	<NR2> 1 unit = 1 amp	Current limit
	1	Returns the current limit of the specific channel.
	MAX/MIN	Returns the allowable maximum and minimum.

Query Example :VOLT:HIGH:CURR? 5
5 The current limit is 5 amps for the specific channel.

:VOLTage:MODE Channel Specific Command

Description	Set the constant voltage response time for the specific channel.	
Syntax	:VOLTage:MODE {SLOW 0 FAST 1}	
Parameter	SLOW/0	Slow response time for PEL-2000A
	FAST/1	Fast response time for PEL-2000A/B
	SLOW2	Slow1 response time for PEL-2000B
	SLOW3	Slow2 response time for PEL-2000B
	SLOW4	Slow3 response time for PEL-2000B
Example	:VOLT:MODE SLOW	Sets the response time to SLOW for the specific channel.
	:VOLT:MODE 1	Sets the response time to FAST for the specific channel.
Query Syntax	:VOLTage:MODE? <NR1>	
Return Parameter	<NR1>	Response Time
	0	Slow
	1	Fast

Query Example :VOLT:MODE? 0 The specific channel is set to SLOW response time.

:VOLTage:LOW:AVALue/BVALue Channel Specific Command

Description Sets the low voltage A/B value for constant voltage mode.

Syntax :VOLTage:LOW:AVALue/BVALue<NRf+>[V]

Parameter	<NRf+>[V]	
	AVALue 1	Sets A Value to 1 volt.
	BVALue 1V	Sets B Value to 1 volt.
	AVALue MIN	Sets A Value to the minimum level for the specific channel.
	AVALue MAX	Sets A Value to the maximum level for the specific channel.

Example :VOLTage:LOW:AVAL 1 Sets A Value to 1 volts for the specific channel

Query Syntax :VOLTage:LOW:AVALue/BVALue? [MAX|MIN]

Return Parameter	<NR2> [MAX/MIN]	Current
	1 unit = 1 volt	Returns the voltage of the A or B Value.
	MAX/MIN	Returns the allowable maximum and minimum.

Query Example :VOLTage:LOW:BVAL? MAX 5 Returns the maximum voltage allowed for the channel/range.

:VOLTage:HIGH:AVALue/BVALue Channel Specific Command

Description Sets the high voltage A/B value for constant voltage mode.

Syntax	:VOLTage:HIGH:AVALue/BVALue<NRf+>[V]	
Parameter	<NRf+>[V]	
	AVALue 1	Sets A Value to 1 volt.
	BVALue 1V	Sets B Value to 1 volt.
	AVALue MIN	Sets A Value to the minimum level for the specific channel.
	AVALue MAX	Sets A Value to the maximum level for the specific channel.
Example	:VOLTage:HIGH:AVAL 1	Sets A Value to 1 volts for the specific channel
Query Syntax	:VOLTage:HIGH:AVALue/BVALue?[MAX MIN]	
Return Parameter	<NR2> [MAX MIN]	Current
	1 unit = 1 volt	Returns the voltage of the A or B Value.
	MAX MIN	Returns the allowable maximum and minimum.
Query Example	:VOLTage:HIGH:BVAL? 2	Returns the maximum voltage allowed for the channel/range.

:VOLTage:IMEasure Channel Specific Command

Description	Sets the current measurement range of constant voltage mode for the specific channel.	
Syntax	:VOLTage:IMEasure{L 0 H 1}	
Parameter	L/0	Low range of current measurement.
	H/1	High range of current measurement.
Example	:VOLTage:IME L	Sets the current measurement range to Low for the specific channel.

:VOLTage:IME 1 Sets the current measurement range to High for the specific channel.

Query Syntax :VOLTage:IMEasure?<NR1>

Return Parameter	<NR1>	The current measurement range of constant voltage mode for the specific channel.
	0	Low
	1	High

Query Example :VOLT:IME? 0 The specific channel is set to low range for current measurement.

Power Subsystem

:POWer:L1/L2	157
:POWer:CURRent.....	158
:POWer:RECall	159
:POWer:LOW:AVALue/BVALue.....	159
:POWer:LOW:CURRent	160
:POWer:HIGH:AVALue/BVALue	161
:POWer:HIGH:CURRent.....	161

:POWer:L1/L2	Channel Specific Command
---------------------	---------------------------------

Description	Sets the A/B Value for constant power mode, where L1 is A Value and L2 is B Value. The command is range dependent. If the current range is Low, then the command will only apply to the low range settings. When setting the A/B value, the device will be switched to CP mode by using this command.
-------------	---

Syntax	:POWer:L1 L2 <NRf+>[W]
--------	------------------------

Parameter	<NRf+>[W]	
	L1 1	Sets A Value to 1 Watt.
	L2 2	Sets B Value to 2 Watts.
	L1 1W	Sets A Value to 1 Watt.
	L1 MIN	Sets A Value to the minimum level for the specific channel.
	L1 MAX	Sets A Value to the maximum Level for the specific channel.

Example	:POW:L1 1	Sets A Value to 1 watt
---------	-----------	------------------------

Query Syntax	:POW:L1?/L2? [MAX MIN]
--------------	------------------------

Return Parameter	<NR2> [MAX MIN]	Current
------------------	-----------------	---------

	1 unit = 1 watt	Returns the power of the A Value (L1) or B Value (L2).
	MAX/MIN	Returns the allowable maximum and minimum.
Query Example	:POW:L2? MAX 357.000	Returns the maximum power allowed for the channel. (PEL-2040B)

:POWer:CURRent Channel Specific Command

Description Sets the current limit for constant power mode. The command is range dependent. If the current range is Low, then the command will only apply to the low range settings. When setting the A/B value, the device will be switched to CP mode by using this command.

Syntax :POWer:CURRent<NRf+>[A]

Parameter	<NRf+>[A]	
	1	Sets the current limit to 1A.
	1A	Sets the current limit to 1A.
	MIN	Sets the current limit to the minimum level for the specific channel.
	MAX	Sets the current limit to the maximum level for the specific channel.

Example :POW:CURR 1 Sets the current limit to 1A.

Query Syntax :POW:CURRent? [MAX|MIN]

Return Parameter	<NR2> [MAX MIN]	Current
	1 unit = 1 amp	Returns the current limit.
	MAX/MIN	Returns the allowable maximum and minimum.

Query Example :POW:CURR?
7.0 Returns the current limit for the specific channel.

:POW:RECall Channel Specific Command

Description Sets or queries whether A Value or B Value is the currently active value in CP mode.

Syntax :POW:RECall {A|0|B|1}

Parameter	A/0, B/1	Value
	A/0	A
	B/1	B

Example :POW:REC 1 Makes B Value the active value.

Query Syntax :POW:RECall?

Return Parameter	<NR1>	Value
	0	A
	1	B

Query Example :POW:REC?
0 A Value is active.

:POW:LOW:AVALue/BVALue Channel Specific Command

Description Sets the low range A/B Value for constant power mode.

Syntax :POW:LOW:AVALue/BVALue<NRf+>[W]

Parameter	NRf+[W]	
	AVALue 1	Sets A Value to 1 watt.
	BVALue 1W	Sets B Value to 1 watt.
	AVALue MIN	Sets A Value to the minimum level for the specific channel.
	AVALue MAX	Sets A Value to the maximum Level for the specific channel.

Example :POWer:LOW:AVAL 1 Sets A Value to 1 watt for the low range.

Query Syntax :POWer:LOW:AVALue/BVALue? [MAX|MIN]

Return Parameter	<NR2> [MAX MIN]	Current
	1 unit = 1 watt	Returns the power of the A or B Value.
	MAX/MIN	Returns the allowable maximum and minimum.

Query Example :POWer:LOW:BVAL? MAX 2 Returns the maximum power allowed for the channel/range.

Channel Specific Command

:POWer:LOW:CURRent

Description Sets the current limit for constant power mode for the low range only.

Syntax :POWer:LOW:CURRent <NRf+>[A]

Parameter	<NRf+>[A]	
	1	Sets the current limit to 1A.
	1A	Sets the current limit to 1A.
	MIN	Sets the current limit to the minimum level for the specific channel.
	MAX	Sets the current limit to the maximum level for the specific channel.

Example :POW:CURR 1 Sets the current limit to 1A.

Query Syntax :POW:LOW:CURRent? [MAX|MIN]

Return Parameter	<NR2> [MAX MIN]	Current
	1 unit = 1 amp	Returns the current limit.
	MAX/MIN	Returns the allowable maximum and minimum.

Query Example :POW:LOW:CURR? Returns the current limit for the specific channel.
7.0

:POWer:HIGH:AVALue/BVALue Channel Specific Command

Description Sets the high range A/B Value for constant power mode.

Syntax :POWer:HIGH:AVALue/BVALue<NRf+>[W]

Parameter	NRf+[W]	
	AVALue 1	Sets A Value to 1 watt.
	BVALue 1W	Sets B Value to 1 watt.
	AVALue MIN	Sets A Value to the minimum level for the specific channel.
	AVALue MAX	Sets A Value to the maximum Level for the specific channel.

Example :POWer:HIGH:AVAL 1 Sets A Value to 1 watt for the high range.

Query Syntax :POWer:LOW:AVALue/BVALue? [MAX|MIN]

Return Parameter	<NR2> [MAX MIN]	Current
	1 unit = 1 watt	Returns the power of the A or B Value.
	MAX/MIN	Returns the allowable maximum and minimum.

Query Example :POWer:HIGH:BVAL? MAX Returns the maximum power allowed for the channel/range.
2

:POWer:HIGH:CURRent Channel Specific Command

Description Sets the current limit for constant power mode for the high range only.

Syntax :POWer:HIGH:CURRent<NRf+>[A]

Parameter	<NRf+>[A]	
	1	Sets the current limit to 1A.
	1A	Sets the current limit to 1A.
	MIN	Sets the current limit to the minimum level for the specific channel.
	MAX	Sets the current limit to the maximum level for the specific channel.
Example	:POW:HIGH:CURR 1	Sets the current limit to 1A.
Query Syntax	:POW:HIGH:CURRent? [MAX MIN]	
Return Parameter	<NR2> [MAX MIN]	Current
	1 unit = 1 amp	Returns the current limit.
	MAX/MIN	Returns the allowable maximum and minimum.
Query Example	:POW:HIGH:CURR? 7.0	Returns the current limit for the specific channel.

SYSTEM Subsystem

:SYSTem:ERRor?	163
:SYSTem:VERSion?	163
:SYSTem:SETup	164
:SYSTem:KLOCK?	164
:SYSTem:KEYLock:MODE?	165

:SYSTem:ERRor? System Command

Description The System Error command returns all the system errors. Please see the Error codes section for a full description. (page 164)

Query Syntax :SYSTem:ERRor?

Return Parameter	<character string>	Error
	-102, "Syntax error"	1 Error code number
		2 Error code description

Query Example :SYST:ERR?
-102, "Syntax error" Returns the next error in the Error Queue.

:SYSTem:VERSion? System Command

Description The system version command returns the SCPI version: year and SCPI version of that year.

Query Syntax :SYSTem:VERSion?

Return Parameter	<NRf>	
	2008.0	Year/ version

:SYSTem:SETup System Command

Description	Sets or returns the system setup for the current settings using block data. See the command syntax on page 19 for more details.	
Syntax	:SYSTem:SETup <block data>	
Parameter	<block data>	System setup data
Example	:SYST:SET <block data>	Loads the system setup using block data.
Query Syntax	:SYSTem:SETup?	
Return Parameter	<block data>	Returns the system setup as block data.
Query Example	:SYST:SET? #<digits><byte count><data><NL>	Returns the system settings as block data.

:SYSTem:KLOCK? System Command

Description	Enables or disables the front panel key lock.	
Syntax	:SYSTem:KLOCK{OFF ON 0 1}	
Query Syntax	:SYSTem:KLOCK?	
Parameter	0/OFF	Panel keys are unlocked.
	1/ON	Panel keys are locked.
Return Parameter	0	<Boolean> Panel keys are unlocked.
	1	<Boolean> Panel keys are locked.

:SYSTem:KEYLock:MODE?

System Command

Description	Set or queries the key lock mode.
Syntax	:SYSTem:KEYLock:MODE{0 1}
Query Syntax	:SYSTem:KEYLock:MODE?
Parameter/Return	0 Panel lock: allow load off.
Parameter	1 Panel lock: allow load on/off.

Memory Subsystem

:MEMory:SAVE:PREset	166
:MEMory:SAVE:PROGram	166
:MEMory:SAVE:ALLPreset	167
:MEMory:SAVE:SETup	167
:MEMory:RECall:PREset	167
:MEMory:RECall:PROGram	168
:MEMory:RECall:ALLPreset	168
:MEMory:RECall:SETup	168
:MEMory:FILE:PREset	169
:MEMory:FILE:PROGram	169
:MEMory:FILE:SETup	170
:MEMory:FILE:SEQuence	170

:MEMory:SAVE:PREset Channel Specific Command

Description	Saves preset data for the specific channel to internal memory slots P0~P9.	
Syntax	:MEMory:SAVE:PREset: <NR1>	
Parameter	<NR1>	Preset no.
	0~9	P0~P9
Example	:MEM:SAVE:PRE 0 Saves the preset settings to (P0).	

:MEMory:SAVE:PROGram Channel Specific Command

Description	Saves the specific channel into memory.	
Syntax	:MEMory:SAVE:PROGram<NR1>	
Parameter	<NR1>	Memory number
	001~120	M001~M120

Example	:MEM:SAVE:PROG 100	Saves the channel to Memory M100.
---------	-----------------------	--------------------------------------

:MEMory:SAVE:ALLPreset All Channels

Description	Saves preset data to internal memory for all channels.
-------------	--

Syntax	:MEMory:SAVE:ALLPreset: <NR1>
--------	-------------------------------

Parameter	<NR1> 0~9	Preset no. P0~P9
-----------	--------------	---------------------

Example	:MEM:SAVE:ALLP 0	Saves the preset settings to (P0) for all channels.
---------	------------------	--

:MEMory:SAVE:SETup All Channels

Description	Saves setup data for all channels to internal memory slots S1~S4.
-------------	---

Syntax	:MEMory:SAVE:SETup: <NR1>
--------	---------------------------

Parameter	<NR1> 1~4	Setup data S1~S4
-----------	--------------	---------------------

Example	:MEM:SAVE:SET 1	Saves the setup data to S1 (applicable to all channels).
---------	-----------------	---

:MEMory:RECall:PREset Channel Specific
Command

Description	Recalls preset data for the specific channel from internal memory slots P0~P9.
-------------	--

Syntax	:MEMory:RECall:PREset: <NR1>
--------	------------------------------

Parameter	<NR1> 0~9	Preset no. P0~P9
-----------	--------------	---------------------

Example :MEM:REC:PRE 0 Recalls the preset settings from (P0).

:MEMory:RECall:PROGram Channel Specific Command

Description Recalls memory data to the current channel.

Syntax :MEMory:RECall:PROGram <NR1>

Parameter	<NR1>	Memory number
	001~120	M001~M120

Example :MEM:REC:PROG 100 Recalls the memory M100 for the current channel.

:MEMory:RECall:ALLPreset All Channels

Description Recalls preset data from internal memory for all channels.

Syntax :MEMory:RECall:ALLPreset: <NR1>

Parameter	<NR1>	Preset no.
	0~9	P0~P9

Example :MEM:REC:ALLP 0 Recalls the preset settings from (P0) for all channels.

:MEMory:RECall:SETup All Channels

Description Recalls setup data for all channels from internal memory slots S1~S4.

Syntax :MEMory:RECall:SETup: <NR1>

Parameter	<NR1>	Setup data
	1~4	S1~S4

Example :MEM:REC:SET 1 Recalls the setup data from S1 (applicable to all channels).

Example	:MEM:REC:1	Recalls memory data S1 to the current channel.
---------	------------	--

:MEMory:FILE:PRESet System Command

Description	Sets or returns the preset settings using block data. See the command syntax on page 19 for more details on block data.
-------------	---

Syntax	:MEMory:FILE:PREset <block data>
--------	----------------------------------

Parameter	<block data>	Preset data
-----------	--------------	-------------

Example	:MEM:FILE:PRE <block data>	Loads the preset settings block data.
---------	----------------------------	---------------------------------------

Query Syntax	:MEMory:FILE:PREset?
--------------	----------------------

Return Parameter	<block data>	Returns the preset settings as block data.
------------------	--------------	--

Query Example	:MEM:FILE:PRE? #<digits><byte count><data><NL>	Returns the preset settings as block data.
---------------	--	--

:MEMory:FILE:PROGram System Command

Description	Sets or returns the program data using block data. See the command syntax on page 19 for more details on block data.
-------------	--

Syntax	:MEMory:FILE:PROGram <block data>
--------	-----------------------------------

Parameter	<block data>	Program data
-----------	--------------	--------------

Example	:MEM:FILE:PROG <block data>	Loads the program data using block data.
---------	-----------------------------	--

Query Syntax	:MEMory:FILE:PROGram?
--------------	-----------------------

Return Parameter	<block data>	Returns the program data as block data.
------------------	--------------	---

Query Example :MEM:FILE:PROG? Returns the program data as
 #<digits><byte block data.
 count><data><NL>

:MEMory:FILE:SETup System Command

Description	Sets or returns the setup data using block data. See the command syntax on page 19 for more details on block data.	
Syntax	:MEMory:FILE:SETup <block data>	
Parameter	<block data>	Setup data
Example	:MEM:FILE:SET <block data>	Loads the setup data using block data.
Query Syntax	:MEMory:FILE:SETup?	
Return Parameter	<block data>	Returns the setup data as block data.
Query Example	:MEM:FILE:SET? #<digits><byte count> <data><NL>	Returns the setup data as block data.

:MEMory:FILE:SEQuence System Command

Description	Sets or returns the sequence data using block data. See the command syntax on page 19 for more details on block data.	
Syntax	:MEMory:FILE:SEQuence <block data>	
Parameter	<block data>	Sequence data
Example	:MEM:FILE:SEQ <block data>	Loads the sequence data using block data.
Query Syntax	:MEMory:FILE:SEQuence?	
Return Parameter	<block data>	Returns the sequence data as block data.

Query Example :MEM:FILE:SEQuence? Returns the sequence data
 #<digits><byte count> as block data.
 <data><NL>

SEQuence Subsystem

:SEQuence:STATe.....	172
:SEQuence:EDIT:POINt	173
:SEQuence:END	173
:SEQuence:END:LOAD	174
:SEQuence:POINt:RESistance	174
:SEQuence:POINt:CURRent.....	175
:SEQuence:POINt:RISE/FALL.....	175
:SEQuence:POINt:TIME.....	176
:SEQuence:REPeat.....	177
:SEQuence:VOLTage:RANGe.....	177
:SEQuence:LOOP:STARt.....	178
:SEQuence:CHANnel:TIME.....	179
:SEQuence:RUN	179
:SEQuence:SAVE	180
:SEQuence:TRIGger:IN	180
:SEQuence:TRIGger:OUT.....	180
:SEQuence:TRIGger:IN:CHANnel.....	181

:SEQuence:STATe	Channel Specific Command
-----------------	--------------------------

Description	Turns on/off the Sequence Function mode.	
Syntax	:SEQuence:STATe {OFF 0 ON 1}	
Parameter	ON/1	Turn sequence mode on
	OFF/0	Turn sequence mode off
Example	:SEQuence:STATe 1	Turn sequence on
Query Syntax	:SEQuence:STATe?	
Return Parameter	ON,STOP	Sequence is on, stopped
	ON,RUN	Sequence is on, running
	OFF	Sequence is off

Query Example :SEquence:STATe? Sequence is on, stopped.
ON,STOP

:SEquence:EDIT:POINT Channel Specific Command

Description Sets the current point in the sequence. The SEquence:END command should first be used to set the number of points.

Syntax :SEquence:EDIT:POINT <NR1>

Parameter	<NR1>	Points
	1~last point	1~ last point.

Example :SEQ:EDIT:POIN 3 Sets the point to number 3.

Query Syntax :SEquence:EDIT:POINT?

Return Parameter	<NR1>	Points
	1~last point	Returns the current point.

Query Example :SEQ:EDIT:POIN? The current point is 3.
3

:SEquence:END Channel Specific Command

Description Sets the number of points in the sequence.

Syntax :SEquence:END <NR1>

Parameter	<NR1>	Points
	1~120	1~120

Example :SEQ:END 5 Sets the max number of points to 5.

Query Syntax :SEquence:END?

Return Parameter	<NR1>	Points
	1~120	1~120

Query Example :SEQ:END? There are 5 points in the sequence.
5

:SEquence:END:LOAD Channel Specific Command

Description	Sets or queries the value of On End Load.	
Syntax	:SEquence:END:LOAD <NRf+>[MAX MIN]	
Parameter	<NRf+>	current value(CC), resistance value(CR).
	0	On End Load = Off.
	MIN/MAX	Maximum or minimum value.
Example	:SEquence:END:LOAD 1.000	Sets the value of On End Load to 1.000
Query Syntax	:SEquence:END:LOAD?	
Return Parameter	0	On End Load is Off
	<NRf>	On End Load value
Query Example	:SEquence:END:LOAD? 1,000	On End Load value is 1.000.

:SEquence:POINt:RESistance Channel Specific Command

Description	Sets the resistance value for the current point. CR mode only.	
Syntax	:SEquence:POINt:RESistance <NRf>[OHM] MIN MAX	
Parameter	<NRf>[OHM], MIN, MAX	Resistance value
	100	100Ω
	100 OHM	100Ω
	MAX/MIN	Maximum or minimum value.
Example	:SEQ:POIN:RES 100	Sets the resistance to 100.
Query Syntax	:SEquence:POINt:RESistance? [MAX MIN]	
Return Parameter	<NR1>	Resistance Value

	1 unit = 1 ohm	Returns the resistance value.
	MAX/MIN	Returns the allowable maximum and minimum.
Query Example	:SEQ:POIN:RES? 100	The resistance value is 100 ohm.

:SEQ:POIN:CUR Channel Specific Command

Description	Sets the current value for the current point. CC mode only.	
Syntax	:SEQ:POIN:CUR <Nrf>[A] MIN MAX	
Parameter	<Nrf>[A], MIN, MAX	Current value
	10	10A
	100 A	100A
	MAX/MIN	Maximum or minimum value.
Example	:SEQ:POIN:CUR 1	Sets the current to 1.
Query Syntax	:SEQ:POIN::CUR? [MAX MIN]	
Return Parameter	<NR1>	Current Value
	1 unit = 1 A	Returns the current value.
	MAX/MIN	Returns the allowable maximum and minimum.
Query Example	:SEQ:POIN:CUR? 1	The current value is 1 amp.

:SEQ:POIN:RISE/FALL Channel Specific Command

Description	Sets the rising and falling slew rates for the current point.	
Syntax	:SEQ:POIN:RISE/FALL<Nrf>[A/us] MIN MAX	
Parameter	<Nrf>[A/us], MIN, MAX	Slew rate
	1.2	1.2A/us

	1.2 A/us MAX/MIN	1.2A/us Maximum or minimum value.
Example	:SEQ:POIN:RISE .3 A :SEQ:POIN:FALL .4 A	Sets the rising slew rate to 0.3 A/us Sets the falling slew rate to 0.4 A/us
Query Syntax	:SEQuence:POINt:RISE/FALL? [MAX MIN]	
Return Parameter	<NR1> 1 unit = 1 A/us MAX/MIN	Slew Rate Returns the slew rate. Returns the allowable maximum and minimum.
Query Example	:SEQ:POIN:RISE? 0.30000 :SEQ:POIN:FALL? 0.40000	Returns the rising slew rate (0.3 A/us). Returns the falling slew rate (0.4 A/us).

:SEQuence:POINt:TIME Channel Specific Command

Description	Sets the duration time of the current point in seconds (for CC mode and CR mode only).	
Syntax	:SEQuence:POINt:TIME<NRF>[S] MIN MAX	
Parameter	<NRF>	Duration Time
	0.000025~60000	0.000025~60000 seconds
	0.000025~60000S	0.000025~60000 seconds
	MIN	0.0001seconds
	MAX	60,000 seconds
Example	:SEQ:POIN:TIME 10	Sets the point duration time to 10 seconds.
Query Syntax	:SEQuence:POIN:TIME? [MAX MIN]	

Return Parameter	<NR2>	Point
	0.0001~60000	Returns the point duration time.
	MAX/MIN	Returns the allowable maximum and minimum.

Query Example :SEQ:POIN:TIM E? 0.00100
The point duration time is 0.001 seconds.

:SEQuence:REPeat Channel Specific Command

Description Sets the number of times the sequence can be repeated (looped).

Syntax :SEQuence:REPeat <NR1>

Parameter	<NR1>	Repeat setting
	1~9999	1~9999
	0	Infinite repeats

Example :SEQ:REP 10 Repeat 10 times
:SEQ:REP 0 Repeat infinitely

Query Syntax :SEQuence:REPeat?

Return Parameter	<NR1>	Repeat setting
	1~9999	1~9999
	0	Infinite

Query Example :SEQ:REP? 10 Repeats the sequence 10 times

:SEQuence:VOLTage:RANGe Channel Specific Command

Description Sets the sequence CC voltage range.

Syntax :SEQuence:VOLTage:RANGe {<NRf>[V]|L|H}

Parameter	<NRf>[V], L, H	Range
	16	Low range*

80V	High range*
L	Low range
H	High range

*Load module dependent, PEL-2020B shown.

Example :SEQ:VOLT:RANG L Sets the range to Low for the channel.

Query Syntax :SEQuence:VOLTage:RANGe?

Return Parameter	<NR2>	Range
	16	Low PEL-2020B, 2030B, 2040B
	125	Low PEL-2041B
	80	High PEL-2020B, 2030B, 2040B
	500	High PEL-2041B

Query Example :SEQ:VOLT:RANG? Returns the voltage range. In this case high for the PEL-2041B.
500

:SEQuence:LOOP:STARt Channel Specific Command

Description Determines from which point to start repeating (looping) the sequence from when using the SEQuence:REPeat command.

Syntax :SEQuence:LOOP:STARt <NR1>

Parameter	<NR1>	Start loop from
	1~last point	1st~ last point.

Example :SEQ:LOOP:STAR 2 Loop from point 2.

Query Syntax :SEQuence:LOOP:STARt?

Return Parameter	<NR1>	Point
	1~last point	Returns the point that the loop will start from.

Query Example :SEQ:LOOP:STAR? The loop starts at point 2.
2

:SEQuence:CHANnel:TIME Channel Specific Command

Description	Sets which channel duration time the specific channel will use.	
Syntax	:SEQuence:CHANnel:TIME <NR1>	
Parameter	<NR1>1~ max channels	Duration Time Settings
	0	OFF
	1	Use channel 1
	2	Use channel 2
Example	:SEQ:CHAN:TIME 3	Set the specific channel to use the channel duration time of channel 3.
Query Syntax	:SEQuence:CHANnel:TIME?	
Return Parameter	<NR1>	Point
	1~ max channels	Returns the channel duration time that the specific channel is using.
Query Example	:SEQ:CHAN:TIME? 2	The specific channel is using the channel duration setting of channel 2.

:SEQuence:RUN Channel Specific Command

Description	Turns the sequence On/Off.	
Syntax	:SEQuence:RUN {OFF 0 ON 1}	
Parameter	OFF/0	Off
	ON/1	On
Example	:SEQ:RUN ON	Run the sequence.


:SEquence:SAVE Channel Specific Command

Description	Saves the sequence for the specific channel.	
Syntax	:SEquence:SAVE	
Example	:SEQ:SAVE	Saves the sequence.

:SEquence:TRIGger:IN Channel Specific Command

Description	Turns the trigger input on/off for sequences. See the :SEquence:TRIGger:IN:CHANnel command to set which channels this command applies to.	
Syntax	:SEquence:TRIGger:IN {OFF 0 ON 1}	
Parameter	OFF/0	Off
	ON/1	On
Example	:SEQ:TRIG:IN 0	Trigger IN is on.
Query Syntax	:SEquence:TRIGger:IN?	
Return Parameter	<NR1>	Trigger IN
	0	Off
	1	On
Query Example	:SEQ:TRIG:IN? 1	Trigger IN is on.

:SEquence:TRIGger:OUT Channel Specific Command

Description	Turns the trigger output on for the selected channel for sequences.	
 Note	One channel must be set for trigger out.	
Syntax	:SEquence:TRIGger:OUT <NR1> MIN MAX	
Parameter	<NR1>	Channel number
	MAX	Sets TRIG OUT to the last channel

	MIN	Sets TRIG OUT to the first channel
Example	:SEQ:TRIG:OUT 1	Sets TRIG OUT to CH1.
Query Syntax	:SEQuence:TRIGger:OUT?	
Return Parameter	<NR1>	Channel number
	MAX/MIN	Last or first channel.
Query Example	:SEQ:TRIG:OUT? 1	CH1 is set to TRIG OUT.

:SEQuence:TRIGger:IN:CHANnel Channel Specific Command

Description Selects which channels are turned on/off with the :SEQuence:TRIGger:IN command. The bit weight of the <NR1> value determines which channels are used.

Syntax :SEQuence:TRIGger:IN:CHANnel<NR1>

Parameter	<NR1>	Channel	<NR1>	Channel
	1	CH1	32	CH 6
	2	CH2	64	CH 7
	4	CH3	128	CH 8
	8	CH 4	256~65535	Not used
	16	CH 5		

Example :SEQ:TRIG:IN:CHAN 9 Sets TRIG IN to CH1 and CH4.

Query Syntax :SEQuence:TRIGger:IN:CHANnel?

Return Parameter	<NR1>	Channel	<NR1>	Channel
	1	CH1	32	CH 6
	2	CH2	64	CH 7
	4	CH3	128	CH 8
	8	CH 4	256~65535	Not used
	16	CH 5		

Query Example :SEQ:TRIG:IN:CHAN? 24 Sets TRIG IN to CH4 and CH5.

GLOBAL Subsystem

:GLOBal:CONFigure:VOLTage:RANGe	182
:GLOBal:LOAD:SHORT.....	182
:GLOBal:MODE	183
:GLOBal:LOAD:[STATe].....	184

:GLOBal:CONFigure:VOLTage:RANGe Global Command

Description	Sets the CC Voltage range high or low. This command applies to all channels.	
Syntax	:GLOBal:CONFigure:VOLTage:RANGe{L H}	
Parameter	L	Low range
	H	High range
Example	:GLOB:CONF:VOLT:RANG L Sets the range to low.	

:GLOBal:LOAD:SHORT Global Command

Description	Shorts all the input terminals.	
Syntax	:GLOBal:LOAD:SHORT{OFF 0 ON 1}	
Parameter	{OFF 0 ON 1}	SHORT
	OFF/0	Off
	ON/1	On
Example	:GLOB:LOAD:SHOR 1 Short on.	



Note

This command is valid only when the “LOAD ON”. Otherwise, it will get “-200, Execution error”. All channels must be LOAD ON to be set to 1.

:GLOBal:MODE

Global Command

Description	Sets the mode for all the load modules in the mainframe.	
Syntax	:GLOBal:MODE {CCL CCH CCDL CCDH CRL CRH CRDL CRDH CVL CVH CPL CPH}	
Parameter	CCL	CC static mode, low range
	CCH	CC static mode, high range
	CCDL	CC dynamic mode, low range
	CCDH	CC dynamic mode, high range
	CRL	CR static mode, low range
	CRH	CR static mode, high range
	CRDL	CR dynamic mode, low range
	CRDH	CR dynamic mode, high range
	CVL	CV static mode, low range
	CVH	CV static mode, high range
	CPL	CP static mode, low range
	CPH	CP static mode, high range
Example	:GLOBal:MODE CCL	Set the specific channel to low range constant current static mode.

:GLOBal:LOAD:[STATe] Global Command

Description This command turns the electronic load on/off for all channels.

Syntax :GLOBal:LOAD:[STATe]{OFF|0|ON|1}

Parameter	OFF/0	Turns the electronic load OFF for all channels.
	ON/1	Turns the electronic load ON for all channels.

Example :GLOB:LOAD 0 Turns the electronic load OFF for all channels.

Command Error Codes

Description	
	The PEL-2000B series has a number of specific error codes. Use the SYSTem:ERRor command to recall the error codes.
-102	Syntax error. An unrecognized command or data type was encountered.
-109	Missing parameter The command header requires more parameters than was received.
-122	Data out of range The data is outside the allowed range.
-128	Numeric data not allowed The command does not accept numerical data/parameters
-200	Execution error Generic execution error.
-144	Character Data too long The character data contains more than twelve characters
-151	Invalid String The string data received is invalid
-148	Character data not allowed The command does not accept character data
-138	Suffix not allowed A command does not accept suffixes/the suffix type.
-222	Data out of range


S STATUS REGISTERS

To program the PEL-2000B series effectively, the Status Register structure needs to be understood. This chapter explains in detail the structure of the status registers.

Status Register Overview.....	187
Channel Status	189
Channel Summary.....	191
Questionable Status.....	191
Output Queue	193
Standard Event Status.....	193
Status Byte Register	194
Service Request Register.....	195

Status Register Overview

Description	<p>The status registers are used to determine the status of the electronic load. The status registers maintain the status of the protection conditions, load conditions and channel conditions of the load modules.</p> <p>The PEL-2000B series have a number of register groups:</p> <ul style="list-style-type: none">Channel Status Registers (one for each channel)Channel Summary RegistersQuestionable Status RegistersStandard Event Status RegistersStatus Byte RegisterService Request Generation Register <p>The structure of the status registers is shown on the next page.</p>
-------------	--



Channel Status

Description Each channel has a dedicated Channel Status Register group. These registers show if any errors or faults have occurred to a specific channel.

The Channel Status Register group consists of: the Condition, EVENT and ENABLE registers as well as PTR/NTR (positive and negative transition) filters.

Channel Status Registers								
Bit Position	7-15	6	5	4	3	2	1	0
Condition	0	UVP	G/N	OT	RV	OP	OV	OC
PTR/NTR	0	UVP	G/N	OT	RV	OP	OV	OC
EVENT	0	UVP	G/N	OT	RV	OP	OV	OC
ENABLE	0	UVP	G/N	OT	RV	OP	OV	OC
Bit weight		64	32	16	8	4	2	1

Protection Bits

OC If an over current condition occurs the OC bit (bit 0) is set.

The OC bit can be cleared only with the :LOAD:PROTECTION:CLEAR command if the over current condition is invalid.

OV If an over voltage condition occurs, the OV bit (bit 1) will be set.

The OV bit can be cleared only with the :LOAD:PROTECTION:CLEAR command if the over voltage condition is invalid.

OP If an over power condition occurs, the OP bit (bit 2) is set.

The OP bit can be cleared only with the :LOAD:PROTECTION:CLEAR command if the over power condition is invalid.

RV	If a reverse voltage condition occurs the RV bit (bit 3) is set. The RV bit is automatically cleared after the reverse voltage is removed.
OT	When the internal temperature exceeds 85°C the OT bit will be set. The OT bit is automatically cleared after the temperature goes below 85°C.
G/N	The Go/NoGo bit is set when Go/NoGo limits have been exceeded, when Go/NoGo SPEC has been enabled.
UVP	If the under voltage condition occurs the UVP bit is set.

Condition Register The condition register indicates the status of the electronic load. The condition register can only be changed by a change in the condition of the electronic load. Reading the condition register does not change the state of the condition register.

PTR/NTR Register The PTR/NTR (Positive/Negative transition) register determines the type of transition conditions that will trigger an event. Only the Channel Status Register and Questionable Status Register can be transition programmed.

Positive Transition	0→1
Negative Transition	1→0

Event Register The Event Register indicates if an event has been triggered according to the transition settings from the PTR/NTR Register.

Enable Register The Enable register determines which status event(s) are enabled. Any status events (OC, OV, OP, RV, OT, G/N, UVP) that are enabled will set the corresponding channel bit in the Channel Summary Event Register.

Channel Summary

Description The Channel Summary Registers consolidate the channel status of all 4/8 channels, depending on the electronic load.

Channel Summary Registers								
Bit Position	7	6	5	4	3	2	1	0
EVENT	CH8	CH7	CH6	CH5	CH4	CH3	CH2	CH1
ENABLE	CH8	CH7	CH6	CH5	CH4	CH3	CH2	CH1
Bit weight	128	64	32	16	8	4	2	1

Event Register If an event has been enabled and set in the Channel Status Registers, then the corresponding channel bit will be set in the Channel Summary Event Register. If the Event Register is read, it will be cleared to 0.

Enable Register The Enable Register is used to determine which channel events will be used to set the CSUM bit of the Status Byte Register.

Questionable Status


Description The Questionable Status Registers will show if any faults or errors have occurred. The Questionable Status Registers have the same events as the Channel Status Registers.

Questionable Status Register								
Bit Position	7-15	6	5	4	3	2	1	0
Condition	0	UVP	G/N	OT	RV	OP	OV	OC
PTR/NTR	0	UVP	G/N	OT	RV	OP	OV	OC
EVENT	0	UVP	G/N	OT	RV	OP	OV	OC
ENABLE	0	UVP	G/N	OT	RV	OP	OV	OC
Bit weight		64	32	16	8	4	2	1

Bit Summary	OC	Over Current
	OV	Over voltage
	OP	Over Power
	RV	Reverse Voltage
	OT	Over Temperature
	G/N	Go/NoGo
	UVP	Under Voltage Protection
Condition Register	The Questionable Status Condition Register indicates the status of the electronic load. If a bit is set in the Condition register (OC, OV, OP, RV) indicates that the event is true. Reading the condition register does not change the state of the condition register.	
PTR/NTR Register	The PTR/NTR (Positive/Negative transition) register determines the type of transition conditions will set the corresponding bit in the Event Registers. Only the Channel Status Register and Questionable Status Register can be transition programmed.	
	Positive Transition	0→1
	Negative Transition	1→0
Event Register	The PTR/NTR Register will dictate the type of transition conditions will set the corresponding bits in the Event Register. If the Event Register is read, it will be cleared to 0.	
Enable Register	The Enable Register is used to determine which channel events will be used to set the QUES bit of the Status Byte Register.	

Output Queue

Description The Output queue stores output messages in a FIFO buffer until read. If the Output Queue has data, the MAV bit in the Status Byte Register is set.



Standard Event Status

Description The Standard Event Status Registers indicate any programming errors that occur. The Standard Event Status Register group comprises of the Event and Enable registers.

Standard Event Status Registers								
Bit Position	7	6	5	4	3	2	1	0
EVENT	0	0	CME	EXE	DDE	QUE	0	OPC
ENABLE	0	0	CME	EXE	DDE	QUE	0	OPC
Bit weight	128	64	32	16	8	4	2	1

Error Bits

OPC The operation complete bit is set when all selected pending operations are complete. This bit is set in response to the *OPC command.

QUE The query error bit is set when there is an error reading the output queue. This can be caused by trying to read the output queue when there is no data in it.

DDE The Device Dependent Error indicates a memory error/lost memory or failure of the self-test.

EXE The Execution bit indicates an execution error due to one of the following

- Illegal command parameter
- Parameter out of range
- Invalid parameter

Command didn't execute due to an overriding operation condition.

CME The Command Error bit is set when a syntax error has occurred. The CME bit can also be set when a <GET> command is received within a program message. (Group Execute Trigger) as defined in IEEE 488.1.

Event Register The Event Register will be set to 0 when read.

Enable Register The Enable Register determines which events will set the ESB Bit (bit 5) in the Status Byte Register.

Status Byte Register

Description The Status Byte register consolidates the status events of all the status registers. The Status Byte register can be read with the *STB? query or a serial poll and can be cleared with the *CLS command.

Status Byte Register								
Bit Position	7	6	5	4	3	2	1	0
Condition	0	MSS	ESB	MAV	QUES	CSUM	ERR	0
Bit weight	128	64	32	16	8	4	2	1

Status Bits **CSUM** The CSUM bit is set when an Enabled event has occurred on a channel. The Channel Condition, Channel Event and Channel Summary Event Registers all determine if the CSUM bit is set.

QUES The Questionable bit is set when a questionable event has occurred.

ESB	The Event Status bit is set if an enabled event in the Standard Event Status Event Register has occurred.
ERR	The ERR bit is set when there is a message in the error queue.
MSS & RQS	The Master Summary Status is used with the *STB? query. When the *STB? query is read the MSS bit is not cleared. The Request Service bit is cleared when it is polled during a serial poll.

Service Request Register

Description The Service Request Generation Register determines which events in the Status Byte Register will generate Service Requests. It is essentially the Status Byte Enable Register. The bit events are the same as the Status Byte Register, minus the MSS/RQS bit.

Service Request Generation Register(Status Byte Enable)								
Bit Position	7	6	5	4	3	2	1	0
Condition	0	0	ESB	MAV	QUES	CSUM	ERR	0
Bit weight	128	64	32	16	8	4	2	1