



INSTRUCTIONS – Non-Contact Voltage Tester with Laser distance meter

ENGLISH

TESTER (FIG. 1)

1. NCV On/Off Button
2. Laser Distance Meter On/Off Button
3. Change Units / Reference Point Button
4. LCD Display
5. NCV Indicator
6. Laser Distance Meter
7. NCV Antenna
8. Pocket Clip
9. O-ring Seal
10. 2x AAA Batteries (Included)
11. Battery Cap

NOTE: There are no user-serviceable parts inside tester.

LCD (FIG. 2)

- A. Measurement
- B. Laser Active
- C. Ref. Point #1
- D. Ref. Point #2
- E. NCV On
- F. Battery Status
- G. Units (ft, in, m)
- H. Silent Mode

ESPAÑOL

PROBADOR (FIG. 1)

1. Botón de enc. y ap. de NCV
2. Botón de enc. y ap. de medidor de dist. láser
3. Botón de cambio de unidades / punto de referencia
4. Pantalla LCD
5. Indicador de NCV
6. Medidor de distancia láser
7. Antena de NCV
8. Clip de bolsillo
9. Junta tórica
10. 2 baterías AAA (incluidas)
11. Tapa del compartimento de baterías

NOTA: El probador no contiene en su interior piezas que el usuario pueda reparar.

LCD (FIG. 2)

- A. Medición
- B. Láser activo
- C. Punto de ref. n.º 1
- D. Punto de ref. n.º 2
- E. NCV encendido
- F. Estado de la batería
- G. Unidades (ft, in, m)
- H. Modo silencioso

FRANÇAIS

TESTEUR (FIG. 1)

1. Bouton marche/arrêt NCV (TTSC)
2. Bouton marche/arrêt du télémètre laser
3. Bouton de changement des unités/du point de référence
4. Écran ACL
5. Voyant de TTSC
6. Télémètre laser
7. Antenne du TTSC
8. Agrafe pour poche
9. Joint torique
10. 2 piles AAA (comprises)
11. Couvercle du compartiment à piles

REMARQUE : Ce testeur ne contient aucune pièce réparable par l'utilisateur.

Écran ACL (FIG. 2)

- A. Mesure
- B. Laser activé
- C. Point de réf. n.º 1
- D. Point de réf. n.º 2
- E. TTSC activé
- F. Charge des piles
- G. Unités (pi, po, m)
- H. Mode muet

- Detects AC voltage from 12V to 1000V with visual & audible indicators
 - Measures distance from 2 in. to 65.6 ft. (51 mm to 20 m)
-
- Detecta voltaje CA de 12 V a 1000 V mediante indicadores visuales y audibles
 - Mide la distancia de 2" a 65,6' (51 mm a 20 m)
-
- Détecte la présence d'une tension allant de 12 V à 1000 V c.a. et la signale au moyen d'indicateurs visuels et sonores.
 - Mesure la distance de 51 mm à 20 m (2 po à 65,6 pi)

Durability / Durabilidad / Durabilité

Ingress Protection

Protección contra el ingreso
Protection contre les infiltrations



IP40

Drop Protection

Protección ante caídas
Protection contre les chutes



6.6 ft.
(2 m)

Safety Rating

Clasificación de seguridad
Cote de sécurité



CAT IV
1000V



Symbols on tester / Símbolos del probador / Symboles sur le testeur



Warning – Risk of electric shock / Advertencia: riesgo de choque eléctrico / Avertissement – Risque d'électrocution



Risk of danger. **Important information:** It is important that users of this tester read, understand, and follow all warnings, cautions, safety information, and instructions in this manual before operating or servicing this tester. Failure to follow instructions could result in death or serious injury.

Riesgo de peligro. **Información importante:** Es importante que el usuario de este probador lea, comprenda y respete todas las advertencias, precauciones, instrucciones e información de seguridad incluidas en este manual, antes de poner en funcionamiento el probador o de realizarle servicios de mantenimiento. No seguir estas instrucciones puede dar lugar a lesiones graves o mortales.

Risque de danger. **Information importante :** Il est important que les utilisateurs de ce testeur lisent, comprennent et suivent tous les avertissements, mises en garde, information de sécurité et instructions, donnés dans le présent guide avant de faire fonctionner ou de réparer ce testeur. Le non-respect pourrait entraîner des blessures graves, voire la mort.



Double insulated / Doble aislamiento / Double isolation



Read instructions / Lea las instrucciones / Lire les instructions



This product has been independently tested by Intertek and meets applicable published standards. Este producto ha sido probado de manera independiente por Intertek y cumple con las normas publicadas vigentes.

Ce produit a été testé de manière indépendante par Intertek et répond aux exigences des normes applicables.



For measurements performed at the source of low-voltage installation and outside lines. Para mediciones realizadas en la fuente de la instalación de bajo voltaje y líneas externas. Pour des mesures prises à la source d'une installation à faible tension et des lignes extérieures.

GENERAL SPECIFICATIONS

The Klein Tools NCVT-6 is a full-range non-contact voltage tester with an integrated laser distance meter. It can detect voltage from 12V to 1000V AC and can measure distance from 2 in. to 65.6 ft. (51 mm to 20 m). Under normal operating conditions, at distances from 51 mm (2 in) – 10 m (32.8 ft) the NCVT-6 has an accuracy of +/- 1.6 mm (1/16 in). At distances >10m (32.8 ft) – 20m (65.6 ft) the NCVT-6 has an accuracy of +/- 3.2 mm (1/8 in). The laser distance meter functions independently from the NCVT.

- **Distance Measurement Range:** 2 in. to 65.6 ft. (51 mm to 20 m)
- **Voltage Detection Range:** 12V to 1000V AC
- **Frequency Range:** 50 to 500 Hz
- **Laser:** Class II, 630 to 670nm, Max. Power <1mW
- **Batteries:** 2x AAA 1.5V Alkaline
- **Operating and Storage Altitude:** Up to 6562 ft. (2000 m)
- **Operating and Storage Temp:** 32° to 122°F (0° to 50°C)
- **Relative Humidity:** <85% non-condensing
- **Dimensions:** 6.45" x 1.32" x 1.21" (164 x 34 x 31 mm)
- **Weight:** 3.4 oz. (96 g) including batteries
- **Pollution degree:** 2
- **Safety Rating:** CAT IV 1000V AC
- **Drop Protection:** 6.6 ft. (2 m)
- **Ingress Protection:** IP40 Dust resistant
- **Standards:** Conforms to UL STD. 61010-1, 61010-2-030
Certified to CSA STD. C22.2 No. 61010-1, 61010-2-030
- **Complies with:** 21 CFR 1040.10 and 1040.11 except for deviations pursuant to laser notice No. 50, dated June 24, 2007.

Specifications subject to change.

FUNCTION BUTTONS (FIG. 1)

NON-CONTACT VOLTAGE TESTING (NCV) ON/OFF BUTTON ①

To turn on the NCVT-6 and activate the Non-Contact Voltage Testing (NCV) function, press and release the NCV Power Button ①. The tester will emit a single audible beep and the NCV Indicator ⑤ will illuminate with a solid blue light. A proximity sensor indicating voltage strength using a dash scale will be shown on the LCD Display ④. Press and hold the NCV Power Button ① for two seconds to power off the NCVT-6.

NOTE: When the Laser Distance Meter (LDM) function is active, a short press of the NCV Power Button ① will deactivate the LDM function and enter the NCV function.

LASER DISTANCE METER (LDM) ON/OFF BUTTON ②

To activate the LDM function, press the LDM Button ②.

- A short press of the LDM Button ② will cause the NCVT-6 to emit an audible beep and take a distance measurement. The value of the distance measurement will be shown on the Display ④.
- A long press and hold of the LDM Button ② will activate continuous measurement mode for the LDM function. As each new distance measurement is taken, the NCVT-6 will emit an audible beep and will update the display ④ with the new measurement value.

⚠ WARNING: LASER RADIATION. DO NOT do any of the following, as severe and permanent eye damage could result:

- **DO NOT** direct laser beam into eyes.
- **DO NOT** stare into the beam.
- **DO NOT** view directly with optical instruments.

FUNCTION BUTTONS (FIG. 1)

CHANGE UNITS / REFERENCE POINT BUTTON ③

- A short press of the Change Units / Reference Point Button ③ will switch the measurement reference point between Reference Point 1 (NCV Antenna ⑥) and Reference point 2 (Battery Cap ⑩).
- A long press of the Change Units/Ref. Point Button ③ will change the units of measurement for the LDM function between meters, inches with decimals, inches with fractions, feet with decimals, and feet with fractions.

⚠ WARNINGS

To ensure safe operation and service of the tester, follow these instructions. Failure to observe these warnings can result in severe injury or death.

- **LASER RADIATION.** Class II laser. **DO NOT** direct laser beam into eyes, **DO NOT** stare into the beam, or **DO NOT** view directly with optical instruments as this can cause severe and permanent eye damage.
- Risk of electric shock and burn. Contact with live circuits could result in death or serious injury.
- Use caution with voltages above 25V AC as a shock hazard may exist.
- A blinking red or a steadily illuminated red NCV Indicator ⑤ with audible beeps indicates the presence of voltage. A steadily illuminated blue NCV Indicator ⑤ indicates that no voltage is detected, however voltage could still be present.
- Before and after each use, verify operation by testing a known working circuit that is within the rating of this unit.
- Never assume neutral or ground wires are de-energized. Neutrals in multi-wire branch circuits may be energized when disconnected and must be retested before handling.
- The tester **WILL NOT** detect voltage if:
 - The wire is shielded.
 - The operator is not grounded or is otherwise isolated from an effective earth ground.
 - The voltage is DC.
- The tester **MAY NOT** detect voltage if:
 - The user is not holding the tester.
 - The user is insulated from the tester with a glove or other materials.
 - The wire is partially buried or in a grounded metal conduit.
 - The tester is at a distance from the voltage source.
 - The field created by the voltage source is being blocked, dampened, or otherwise interfered with.
 - The frequency of the voltage is not a perfect sine wave between 50 and 500Hz.
 - The tester is outside of operating conditions (listed in Specifications section).
- Operation may be affected by differences in socket design and insulation thickness and type.
- In bright light conditions, the LED visual indicators will be less visible.
- When the NCV function is activated, the NCV Indicator ⑤ will be illuminated either red or blue. **DO NOT USE THE NCV FUNCTION UNLESS THE NCV INDICATOR ⑤ IS ILLUMINATED.**
- Do not use if tester appears damaged or is not operating properly. If in doubt, replace the tester.
- Do not apply more than the rated voltage as marked on the tester (1000V).
- Detection within the range of 12V to 1000V is specified under "nominal" conditions as detailed in the GENERAL SPECIFICATIONS section. The tester may detect at a different threshold at different conditions, or may not detect at all unless:
 - The tip of the tester is within 0.25" (6 mm) of an AC voltage source radiating unimpeded.
 - The user is holding the body of the tester with his or her bare hand.
 - The user is standing on or connected to earth ground.
 - The air humidity is nominal (50% relative humidity – non-condensing).
 - The tester is held still.
- Always wear approved eye protection.
- Comply with local and national safety requirements.
- If this product is used in a manner not specified by the manufacturer, protection provided by the product may be affected.

⚠ CAUTION

- **DO NOT** attempt to repair this tester. It contains no serviceable parts.
- **DO NOT** expose tester to extremes in temperature or high humidity.

OPERATING INSTRUCTIONS

CHECKING FOR THE PRESENCE OF AC VOLTAGE

1. Prior to use, test on a known live circuit to verify tester functionality.
2. Place NCV Antenna ⑦ near an AC voltage source. If voltage is present, the unit will emit audible beeps and the NCV Indicator ⑤ will illuminate.

SILENT MODE

With the NCVT-6 powered off, press and hold the On/Off Button for five seconds (the NCV On/Off ① for NCV mode, or the LDM On/Off Button ② for LDM mode) to power-on in Silent mode. While Silent mode is active, the silent mode icon ⑧ will be displayed. All visual indicators and display readings will continue to function as normal, but no audible indicators will be given. Silent mode will remain active until the NCVT-6 is powered-off.

AUTO-POWER OFF (APO)

While the NCV function is active, the display ④ will powersdown following 15 seconds of no voltage detection (the NCV indicator ⑤ will remain illuminated). After 4 minutes of further inactivity, the NCVT-6 will automatically power-off.

While the LDM function is active, the NCVT-6 will automatically power-off following 15 seconds of inactivity.

MAINTENANCE

BATTERY REPLACEMENT

When the Battery Status Indicator ⑨ shows only one bar remaining, the LDM functionality will be disabled, and the NCV functionality has less than 8 hours remaining. At this point, the batteries should be replaced:

1. Unscrew Battery Cap ⑩ and remove/recycle spent batteries ⑩.
2. Install two new AAA batteries ⑩. Note proper polarity.
3. Screw battery cap until fully seated to ensure a tight seal, being careful not to damage the O-ring ⑨. **NOTE: Damage to the O-ring can affect the IP40 dust resistant rating, but will not affect functionality.**

CLEANING

Be sure tester is turned off and wipe with a clean, dry lint-free cloth. **Do not use abrasive cleaners or solvents.**

STORAGE

Remove the batteries when not in use for a prolonged period of time. Do not expose to high temperatures or humidity. After a period of storage in extreme conditions exceeding the limits mentioned in the General Specifications section, allow the tester to return to normal operating conditions before using.

DISPOSAL / RECYCLE



Do not place equipment and its accessories in the trash.



Items must be properly disposed of in accordance with local

regulations.60069