



CCTV Camera Tester for IP Digital / HD Coax / Analog Systems

Test Equipment Depot - 800.517.8431 - 5 Commonwealth Ave, MA 01801 - TestEquipmentDepot.com

Depend On Us



CCTV Camera Tester for IP Digital / HD Coax / Analog Systems SecuriTEST IP is an installation and troubleshooting tester for digital/IP, HD coax and analog CCTV camera systems. With a single tester that can power, configure and document, SecuriTEST IP increases productivity from start to finish.

Supply power to cameras via PoE/PoE+ (Power over Ethernet) or standard 12V DC power using its internal Li-Ion battery, eliminating the need for external power adapters and injectors.

The QuickIP[™] feature allows installers who are new to IP camera systems to quickly and easily connect to cameras without being network experts.

Create professional test reports including video screen shots to verify the job has been completed successfully and reduce unpaid call backs.

Camera Configuration, Installation and Troubleshooting



Physically Connect Camera

Connect to any IP or analog camera using RJ-45, BNC connections or Wi-Fi via network.





Power Camera

Whether you are installing or troubleshooting cameras, SecuriTEST IP supports all your power requirements for IP and analog cameras.

No need for separate power injectors – SecuriTEST IP includes the following power outputs:





Power the camera using 12V DC from the tester - 2.5mm to 3.5mm barrel connector.

Power the camera by passing PoE+ from the network and through the tester - RJ-45 port.

Camera Identification and Login

QuickIP[™] automates the process of connecting to IP cameras, allowing novice technicians to configure IP cameras as easily as analog cameras. For instances where dynamic IP addresses are required by the camera, SecuriTEST IP has a built-in DHCP server making setup easy and eliminating the need for additional network hardware.

A suite of networking troubleshooting tools are available to pinpoint and solve network connectivity issues.

- Display Network Configuration
- Ping / TraceRoute
- Hub blink for Port Identification
- IP network Scan check for IP address conflicts

IP Camera Setup

SecuriTEST IP offers a comprehensive range of ONVIF and non-ONVIF camera setup tools to ensure the camera is installed correctly



- 1. Configure camera update camera information and network settings.
- 2. Aim and focus use the high-resolution touchscreen or the hard keys when wearing gloves.
- **3. Program presets for PTZ cameras** Program PTZ camera presets for users to automatically look at predefined areas.

-ONVIF VIVIF PoE 48V ON/3.3W Main Stream 1920x1080 h264 Cugged inadmin Logout Device List() VIVISVORT Station dry Jangaba

4. Take snapshot – save video snapshots including preset locations for your installation reports.

0

5. Record video clip – record video clips to demonstrate complete coverage for PTZ cameras.

Analog and HD Camera Setup

Easily setup analog cameras.



Video adjustment


SD TVI	1920	x1080P 25FPS		<u> </u>	亨 1:36 AM
	Protocols:		Pelco D		<u> </u>
NYPE DE	Port:	`⊲[RS485		Phot
	Baud Rate:		2400		Snaps
Contraction of the	Address:	4			1. 👓
	Tilt speed:		40		Reco
an len	Tilt speed:	\triangleleft	40		Playb
	Set Position:				Ģ
	Call Position:	\triangleleft	8		PTZ
	ОК		Canc	el	

Add Refresh

ONVIF setting


men

PTZ protocol settings



PTZ RTSP

Test pattern generator to adjust screens



Professional Reports*

Easily transfer reports from the jobsite – Using the built-in Wi-Fi and the web browser, test reports can be sent directly from the tester using email, your preferred file sharing service or be exported on microSD card.

Convert unpaid call backs to billable service calls – Generate professional PDF reports that provide proof of installation to the client.

No more spreadsheets – Today security engineers waste time manually filling in excel documents to create reports. SecuriTEST IP is the first camera tester to capture camera image(s), network configuration and automate documentation.

Reduce troubleshooting time – Reports capture as-built configuration that will help to reduce troubleshooting on future call backs.

18GB of combined storage -

10GB of internal memory and 8GB available on the SD memory card included.

* Only applicable when using the ONVIF protocol

Example Report

Job/Project name : Ticket/Ref /Job No. : Building No. : Street : City : State : ZIP : Country :	Lake Ridge QR127A LRP472 River Run St Tega Cay SC 29777 USA	Operator J. Smith Company: City Wide Street: 1300 N. In City: San Jose, ZIP: 92100 Country: USA Tel: 888-555-1 Email: contactust	ndustrial Blvd CA 1295	
	SecuriTEST IP 2017072000010810 1.3-1.3 V1.1.0	Test Time/Date : Time zone : Firmware Version : System SW version :	2017-10-09 12:32:37 EST 1.7.1.1.4 IN-K2-X7V1.0.0-1.0.0- 7114G	
Device Info Camera name : Camera time : Camera Firmware Ver :	IPCAM06 2017-10-9 13:0:36 V5.3.9 build 151223	Camera Model : Camera Maker : ONVIF version :	DS-2DE2202-DE3/W HIKVISION 2.40	
Network Status Info Ethernet port speed : PoE : Camera IP Mode : Gateway : DNS :	100Mb/s dynamic 192.168.1.1 8.8.8.8	Duplexity : Camera IP address : Camera subnet mask : Camera MAC add :	255.255.255.0	
Image Info Resolution : Frame Rate (fps) : photo :	1920x1080 25	Encoding format : Bit Rate Max (kbps) :	H264 3072	
2011-01-02-11-25-08.p	-	2011-01-02-12-16-07; p 09-12-2017 fac 22:57	-	

2011-01-04-20-30-12.png

2011-01-04-20-24-37.png

Data Cable Test (UTP) - Wiremap

Eliminate guess work troubleshooting cabling faults – SecuriTEST IP is used in combination with the "Cable Tracer/Remote Tool" to pinpoint cabling faults such as cross overs, miswires, shorts and opens. The length of the cabling is also provided.

Determine water ingress in data cabling – Many cables are run outside or in underground conduit and exposed to moisture. Moisture ingress through the cable jacket, which is impossible to see, leads to a number of performance problems.

ៅ RJ45 Cable TDR	test			📒 🐖 📋 13:29 🔀
Test once				(2)
Continuous test Advanced test	Line pair	Status	Length(m)	Attenuation (dB/100m)
	1 2	Open	10.5	-6.9
	3 6	Open	10.5	-7.8
	4 5	Open	10.5	-8.8
Test port connection	8 8	Open	10.5	-7.3
Display cable diagrams	Go	od quality cable	Poor quality	cable Possible contaminated cable

Cable Tracing - Search for Cabling

SecuriTEST IP includes the ability to identify and trace cables using the digital tone generator and the "Cable Tracer/Remote Tool". Choose from four tones and use the "Cable Tracer/Remote Tool" with variable sensitivity settings to trace either large cable bundles from a distance or pinpoint a single cable within a bundle.

Accurate setup of 4k

cameras – Digital zoom displays full detail of high resolution video on the 7" touchscreen. Fast access to key features -

Short cut menu to instantly launch your most used tools.

One hand operation - Pan/ Tilt/Zoom (PTZ) the camera using either the touchscreen or the hard keys.

÷ ÷ • • 2 SecuriTEST[®] IP SecuriTEST IP 🖀 📬 📋 2018-01-12 12:00:44 20 PoE POWER DIRECT CAMERA NETWORK CAMERA ANALOG & HD CAMERA 8 HELP CABLE TEST MY APPS Esc JOBS Long battery life - Up to 10 Ease of use - High resolution 7" hours continuous usage with a capacitive touchscreen with 1920 x lithium-ion battery. 1200 resolution display.

PoE+ troubleshooting

Flashlight - Bright LED flashlight with 5/10/30/60 minute auto-off options. - Display the PoE+ consumption of the attached camera in realtime using the power monitor tool. Displays voltage by pair and total wattage drawn.

Analog/AHD/CVI/ TVI video input -

Connect to all common analog and HD-over-coax cameras for maximum versatility.

HEMI

RS 485

Setup security

monitors – Use the analog Video Out port on the tester with the test pattern generator function to setup security monitors.

12V DC power supply

DC12V

- Power any camera using the built-in 12V/2A DC power supply.

Power up camera with PoE+ - RJ-45

network port provides PoE+ (up to 24 watts) to the camera using the internal battery when network power is unavailable.

Troubleshooting

HDMI - Use the HDMI In port, connect to any HDMI source to isolate Network Video Recorder (NVR) vs monitor problems.

HDMI In – Eliminates the need for a separate monitor.

RS485 interface -

Control and program Pan/ Tilt/Zoom (PTZ) cameras and monitor incoming PTZ control signals to assist in troubleshooting analog cameras.

Camera audio testing using audio in port -

Test microphone equipped cameras using the tester's internal speaker.

Camera audio testing using audio out port - Listen

to the camera audio through the tester using external headphones/ earbuds. Useful in noisy environments.

Data cable testing

- RJ-45 port to perform wiremap testing of unshielded twisted pair (UTP) data cabling. Automatically identify cross over cables and common wiremap faults using the Tracer/Remote.

USB charging - High

power 2A USB port to quickly charge devices such as mobile phones and tablets. (Please note this port does not support data transfer).

microSD slot - Transfer test reports, screen captures and video clips, or update software using microSD card.

HDMI output - Display tester screen on a larger monitor using HDMI for greater clarity.

0 7

CCTV Camera Tester for IP Digital / HD Coax / Analog Systems



Ordering Information

Part No.	Kit Contents
R171000	SecuriTEST IP - Digital/Analog/HD Coax CCTV Tester. 1 x SecuriTEST IP Camera Tester, 1 x carry case with strap, 2 x neck straps, 1 x PSU EU/UK/US/AU adapters, 1 x cable tracer/ remote, 1 x 9.84 ft Cat. 5e UTP patch cable, 1 x 9.84 ft coax cable with two end BNC (m) connectors, 1 x 9.84 ft DC12V 3.5(f) to 2.5(f) power cable, 2 x RS485 female green plugs, 1 x 1.64 ft RS485 cable with female green plug and two clips, 1 x 1.64 ft audio male jack with other end two clips, 1 x quick reference guide, 1 x 8GB microSD card and reader with USB adapter

Optional Accessories

Part No.	Description
R171050	1 x Replacement Cable Tracer/Remote
R171051	1 x Replacement accessory set for SecuriTEST IP. 1 x coax cable with two end BNC (m) connectors, 1 x DC12V 3.5(f) to 2.5(f) power cable, 2 x RS485 female green plug
R171052	1 x Replacement Battery

Basic Specifications

Internal	Max. Cable	Battery	Dimension	Weight	Operation	Operation
Memory	Length	Life*	(inches)		Temp	Humidity
10GB	328 ft	10 hours	6.3 (L) x 9.9 (W) x 1.9 (D)	2.2 lbs	-14°F to +122°F	30% to 90%

*Battery life is dependent on the load being drawn.



All Rights Reserved. TREND NETWORKS, SecuriTEST, and the QuickIP logos are trademarks or registered trademarks of TREND NETWORKS.

Job/Project name :	Lake Ridge	Operator : J. Smith	
Ticket/Ref /Job No. :	OR127A	Company : City Wide	COTV
Building No. :	LBP472		ndustrial Blvd
Street :	River Run St	City : San Jose	
City :	Tega Cav	ZIP: 92100	, OA
State :	SC	Country : USA	
ZIP :	29777	Tel : 888-555-	1295
Country :	USA		@trend-networks.com
Tester Info			
Tester Name :	SecuriTEST IP	Test Time/Date :	2017-10-09 12:32:37
Serial No :	2017072000010810	Time zone :	EST
	1.3-1.3	Firmware Version :	1.7.1.1.4
Main SW version :	V1.1.0	System SW version :	IN-K2-X7V1.0.0-1.0.0- 7114G
Device Info			
Camera name :	IPCAM06	Camera Model :	DS-2DE2202-DE3/W
Camera time :	2017-10-9 13:0:36	Camera Maker :	HIKVISION
Camera Firmware Ver	: V5.3.9 build 151223	ONVIF version :	2.40
Network Status Info			
Ethernet port speed :	100Mb/s	Duplexity :	Full
PoE :		Camera IP address :	
	dynamic	Camera subnet mask	
Gateway :	192.168.1.1	Camera MAC add :	bc:ad:28:c8:6d:0e
DNS :	8.8.8.8		
Image Info Besolution :	1920x1080	Encoding format :	1004
	1920X 1080	Bit Rate Max (kbps) :	
	25	bit hate max (kbps) .	3072
photo :			

2011-01-04-20-30-12.png

2011-01-04-20-24-37.png

Specification subject to change without notice. E&OE © TREND NETWORKS 2020 Publication no.: 171819, Rev. 4 P-5549