

## **ELECTRIC MEASUREMENTS**

Test Equipment Dep	oot - 800.517.8431	- 99 Washington S	Street M	elrose, MA 021	76 - TestEquipme	ntDepot.com
		_				
		_				
		<u> </u>				
						<del></del>
			_			
			_			

## **AR-225**

## **PHASE SEQUENCE INDICATOR**

## **AR-225 3 INSTRUMENTS IN ONE**

Indication of open phase, phase sequence and motor rotation.

CROCODILE CLAMP OF BIG SIZE

Permit connecting easily to terminals of conmutation boards.

HIGH RELIABILITY

Identify trifasic frequency and check the open phase.

SPECIFICATIONS	PHASE SEQUENCE METER		
Input voltage	100 V AC to 600 V AC max.		
Frequency range	from 45 to 70 Hz		
Technology	(not mechanical)		
Battery	9V type 006P		
Valid for insta. with category of overvoltage IEC-1010			

