


Tools for PoE Powered Devices

ALIGN / FOCUS AN IP CAMERA ON THE JOBSITE CONFIGURE A ROUTER AT THE ROUTER LOCATION CONFIGURE AN ACCESS POINT AT ITS LOCATION

MONITOR POE VOLTS, WATTS
AND LINK ACTIVITY



CONNECT POE POWER SOURCE HERE (POE SWITCH OR INJECTOR)

MODEL IPAS10-N

