

ATRIX REVO RED bagless HEPA CANISTER

VACUUM CLEANER

OWNER'S MANUAL

Model: AHC-RR

120V 60Hz 12A, 1400W ETL US CANADA



Test Equipment Depot - 800.517.8431 - 99 Washington Street Melrose, MA 02176 TestEquipmentDepot.com

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING APPLIANCE

WARNING:

TO REDUCE THE RISK OF FIRE, ELECTRICAL SHOCK OR INJURY:

1. Do not leave appliance when plugged in. Unplug from outlet when not in use and before servicing.

2. Electrical shock may occur if used outdoors or on wet surfaces.

3. Do not allow vacuum to be used as a toy. Pay close attention when vacuum is used by or near children.

4. Use only as described in this manual. Use only manufacturer's recommended instructions.

5. Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to Atrix International to be evaluated (refer to warranty policy).

6. Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges of corners. Do not run appliance over cord. Keep cord away from heated surfaces.

7. Do not unplug by pulling on cord. To unplug, grasp plug, not the cord.

8. Do not handle plug or appliance with wet hands.

9. Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.

10. Keep hair, loose clothing, fingers and all body parts away from openings and moving parts.

11. Do not pick up anything that is burning or smoking such as cigarettes, matches or hot ashes.

12. Do not use without filter in place.

13. Turn off all controls before unplugging.

14. Use extra care when cleaning on stairs.

15. Do not use to pick up any liquids, including flammable or combustible liquids such as gasoline or use in areas where they may be present.

16. Connect to a properly grounded outlet only.

17. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.


Children should be supervised to ensure that they do not play with the vacuum.

SAVE THESE INSTRUCTIONS!

Know Your Revo Red

- 1. Floor Tool
- 2. Telescopic Wand
- 3. Parking Fixture
- 4. Storage Clip
- 5. Air Slide
- 6. Vacuum Hose
- 7. Carrying Handle

- 8. Vacuum Hose Connection
- 9. ON/OFF Button
- 10. Release Button
- 11. Cord Rewind Button
- 12. Motor Power Adjustment Slide
- 13. Crevice Nozzle
- 14. Upholstery Nozzle
- 15. Turbo Brush





15

Assembling the Revo Red

- Fit the hose on the vacuum cleaner by inserting the rotating hose connection into the vacuum cleaner until you hear a click. To remove the hose, press the button at the side of the hose connection and then pull it out.
- Fit the telescopic tube into the other end of the hose.
- Adjust the length of the telescopic tube by pushing the locking mechanism down and pulling in the bottom section of the tube to a suitable length. When parking, shorten the tube as far as possible.
- Fit the floor brush into the telescope tube.

Floor Nozzle

The floor nozzle has two settings. When cleaning hard surfaces (wood, tile etc.), the brush bristles should be extended. When cleaning carpets and mats, the brush bristles should be retracted into the nozzle. Press the brush change button to switch between the two settings.


Crevice Nozzle

For radiators, corners, base boards, etc.


Upholstery Nozzle

For furniture, curtains, drapes, etc.













Using the Revo Red

Before using the vacuum, pull out a sufficient length of cord and then plug the cleaner into the wall outlet.

The yellow mark on the cord is the maximum length and must not be exceeded.

Push On/Off Button


To rewind the cord, push cord rewind button

Emptying the Revo Red Dust Bin

Empty the dust bin regularly, at the latest when the quantity of dirt in the dust container has reached the "MAX" mark or the suction power has dropped.

- Switch off the vacuum cleaner and disconnect the plug from the outlet. To do this, always pull on the plug and not on the cord.
- Release the dust container by pressing down the release button (1).
- Lift the dust container forwards out of the cylinder vacuum cleaner (2).
- When emptying the dust container, hold it low over the garbage can.
- Press the open button. The base opens and the dust drops (3).
- Carefully knock the remaining dust loose.
- Close the base.
- Place the dust bin back onto the vacuum cleaner.
- Check whether the dust container is securely seated.







Cleaning the Revo Red HEPA and Foam Filters


- Turn off and unplug cleaner.
- Remove the dust bin.
- Open the dust bin cover and remove filters.
- For a quick clean, tap on side of garbage can.
- For a deep clean, rinse with water and dry.
- Insert the dry filters back into the dust bin cover.
- To deep clean dust bin and chamber, twist and unlock from assembly.
- Rinse with water and dry.
- Reassemble and attach to vacuum.
- Check whether the dust bin is securely seated.

LOCK C

IMPORTANT! Never use the vacuum cleaner without filters.

Cleaning the Revo Red Intake and Exhaust Filters

The intake/exhaust air foam filters will rarely require cleaning. You can use the same wet or dry method as described above. Turn off. Unplug. Remove. Clean. Dry. Install.



Cleaning the Revo Red

- Unplug the vacuum cleaner.
- Wipe with a slightly damp cloth.
- Do NOT use any form of strong, solvent or abrasive cleaners.
- Let dry before next use.

•

Disposal Information



Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority for recycling advice.

Test Equipment Depot - 800.517.8431 - 99 Washington Street Melrose, MA 02176 TestEquipmentDepot.com