

EasyLog CC

Quick Start Guide



Test Equipment Depot - 800.517.8431
99 Washington Street, Melrose, MA 02176
TestEquipmentDepot.com

1

Your new logger comes ready to go.

Simply press and hold the  button until the green LED lights up to start logging.



2

Now place your logger in the location you want to monitor.



3

When you are ready to view the recorded data on your logger, the first thing you need to do is download the EasyLog CC software.

EasyLog CC Windows Control Software

EasyLog CC is the software platform for Lascar's EasyLog CC range of Cold Chain data loggers. It is compatible with Windows XP, 7, 8 & 10.



Click here to download the EasyLog CC Software



EasyLog

Double click on the downloaded **EasyLog CC Installer.exe** file, and follow the on screen prompts.

- 4** To save your data, remove the logger from the plastic sleeve and connect it to a USB port.


Open the EasyLog CC software and click on **Save Data**.




This will automatically open up your readings in the EasyLogGraph software, where you can view your data or export it in various formats.






- 5** To start your logger for the next session, click on **Prime Logger**.




Your data logger is now primed and ready to go. Place your logger in location ready for the next session. To start it logging again, press and hold the  button until the green LED lights up.

Once logging, pressing the  button will light up an LED to give a quick indication of the status. It will also add a marker to the data to show that you have checked it.

No alarms will be triggered in the first 30 minutes to allow the logger to settle at the monitored temperature.


	Green single flash The data logger is currently logging No alarm has been triggered	No action required
	Red single flash The data logger is currently logging An alarm has been triggered!	Check alarm condition in PC software
	Green double flash The data logger's memory is full No alarm was triggered	Plug your logger in to a PC, download your readings and start a new session
	Red double flash The data logger's memory is full An alarm was triggered!	Plug your logger in to a PC, download your readings, check alarm condition and start a new session
	No LEDs flash The data logger is stopped or the battery is flat	Check the logger's status using the PC software

The EasyLog CC Range



EL-CC-1-001
Chilled Goods

High Alarm 8°C
Low Alarm 2°C



EL-CC-1-002
Frozen Goods

High Alarm -16°C
Low Alarm -20°C



EL-CC-1-003
Ripening Goods

High Alarm 14°C
Low Alarm 12°C

Test Equipment Depot - 800.517.8431
99 Washington Street, Melrose, MA 02176
TestEquipmentDepot.com

