



BAT-200

Battery Tester

User Manual



BAT-200

Battery Tester

Users Manual

English

September 2009, Rev.1
©2009 Amprobe Test Tools.
All rights reserved. Printed in China

Limited Warranty and Limitation of Liability

Your Amprobe product will be free from defects in material and workmanship for 1 year from the date of purchase. This warranty does not cover disposable batteries or damage from accident, neglect, misuse, alteration, contamination, or abnormal conditions of operation or handling. Amprobe's warranty obligation is limited, at Amprobe's option, to refund of the purchase price, free of charge repair, or replacement of a defective product . To obtain service during the warranty period, return the product with proof of purchase to an authorized Amprobe Test Tools Service Center or to an Amprobe dealer or distributor. This warranty is your only remedy . All other warranties - whether express, implied or statutory - including implied warranties of fitness for a particular purpose or merchantability, are hereby excluded. Neither Amprobe nor its parent company or affiliates shall be liable for any special, indirect, incidental or consequential damages or losses, arising from any cause or theory. Since some states or countries do not allow the exclusion or limitation of an implied warranty or of incidental or consequential damages, this limitation of liability may not apply to you.

Repair

All test tools returned for warranty or non-warranty repair or for calibration should be accompanied by the following: your name, company's name, address, telephone number, and proof of purchase. Additionally, please include a brief description of the problem or the service requested and include the test leads with the meter. Non-warranty repair or replacement charges should be remitted in the form of a check, a money order, credit card with expiration date, or a purchase order made payable to Amprobe® Test Tools.


In-Warranty Repairs and Replacement – All Countries

Please read the warranty statement and check your battery before requesting repair. During the warranty period any defective test tool can be returned to your Amprobe® Test Tools distributor for an exchange for the same or like product.

Non-Warranty Repairs and Replacement – US and Canada

Non-warranty repairs in the United States and Canada should be sent to a Amprobe® Test Tools Service Center. Call Amprobe® Test Tools or inquire at your point of purchase for current repair and replacement rates.

BAT-200 Battery Tester






- ① Battery Condition Meter
- ② 1.5v Battery Terminal Contactor Caliper
- ③ 9v Battery Terminal Contactors

CONTENTS

SYMBOLS.....	2
UNPACKING AND INSPECTION	2
INTRODUCTION	2
FEATURES	3
OPERATION.....	3

SYMBOLS

	Caution! Refer to the explanation in this Manual
	Conforms to relevant Australian standards
CE	Complies with European Directives
	Do not dispose of this clamp meter as unsorted municipal waste. Contact a qualified recycler for disposal.

⚠ WARNING and PRECAUTIONS

- *Do not operate this instrument in the presence of gasoline, natural gas, propane, or in other combustible atmospheres.*
- *The battery tester is activated by the battery being checked. Keep test time as short as possible, to avoid unnecessary battery drain.*

UNPACKING AND INSPECTION

Your shipping carton should include:

- 1 BAT-200 Battery Tester
- 1 Users manual

If any of the items are damaged or missing, return the complete package to the place of purchase for an exchange.

INTRODUCTION

Check the batteries! Battery failure is often the common cause for the sensor or instrument failure. Simple to use! Portable universal battery tester for the standard and rechargeable types batteries.

FEATURES

- Measuring for Multiple battery types
- Available for 1.5V and 9V battery
- Easy-to-read color-coded display with "**Good**", "**Low**" and "**Replace/Recharge**" indicators
- Works with standard and rechargeable batteries

OPERATION

Reading The Meter

For 1.5V and 9V batteries, read off upper scale.



Connect the 1.5V Battery




Connect the 9V Battery


For 1.5V button cells, read off "BUTTON BATT" scale.4.



Connect the 1.5V button cells



 Red = Replace

 Yellow = Low Power

 Green = Good

If needle does not move, check that battery is touching both contacts before assuming that it is completely dead.

The Battery Tester may be used to test the following sizes:

1.5V	AAA, SH16, MN2400, R03 AA, HP7, MN1500, UM3 C, HP11, MN1400, SO11, LR14, UM2 D, HP2, MN1399, SP2, R20, UM1
9V	PP3, MN1604, 6F22, 006P