

HAKKO FX-791

N₂ STATION

Instruction Manual


Thank you for purchasing HAKKO FX-791 N₂ Station.
Please read this manual before operating the HAKKO FX-791.
Keep this manual readily accessible for reference.

Specifications

Name	HAKKO FX-791
Outer dimensions	70(W) × 121(H) × 134(D) mm
Weight	600g
Pressure gauge for discharged gas	0.2 MPa (2.0 kgf/cm ²)
Gas flow	0.25ℓ/min - 2.5ℓ/min

*The specifications and design are subject to change without notice.

Part Names



OPERATION

1. Connect N₂ gas to the IN connector on the rear.

Limit the input gas pressure at 0.2MPa (2.0kgf/cm²) to 0.9MPa (9.0kgf/cm²) to maximum.
If this limit is exceeded, parts for the main unit may be broken.

2. Set the flow rate of the discharged gas.

Connect the soldering iron tube into the OUT connector.


Open the gas discharge valve marked FLOW.

The gas will start being discharged.

Using the gas flow control knob, select the appropriate gas flow rate in accordance with the application of soldering job.

(Turn the knob clockwise to reduce the gas flow and counterclockwise to increase the gas flow.)

Connection example



CAUTION

Be sure to use the air filter. Otherwise, dust in the piping may be stuck in the main unit and cause a problem.



Copyright © 2005 HAKKO Corporation. All Rights Reserved.

2005.1
MA01358JZ050106



99 Washington Street
Melrose, MA 02176
Phone 781-665-1400
Toll Free 1-800-517-8431

Visit us at www.TestEquipmentDepot.com