



- Batteries can be tested in service
- Dynamic discharge technology full power at all voltages
- Safety in all details, e.g. detection of blocked airflow
- Real time monitoring during test
- Easy report function and calibration
- Easily expandable for larger battery banks using TXL extra load units
- Battery cell monitor control integrated in the system
- Can be used with Lead-Acid, Ni-Cd and other battery types

DESCRIPTION

The TORKEL[™] 900 series is used to perform load/discharge testing which is the only way to determine battery systems actual capacity. Together with the optional cell voltage logger, BVM, connected directly to the TORKEL 900, it becomes a complete, stand-alone, discharge test system.

TORKEL comes in three models, 910, 930 and 950, see table below.

The high discharge capacity of TORKEL gives the opportunity to shorten the test time. Discharging can take place at up to 220 A, and if higher current is needed, two or more TORKEL units or extra load units, TXL, can be linked together. Tests can be conducted at constant current, constant power, constant resistance or in accordance with a pre-selected load profile.

Testing can also be carried out without disconnecting the battery from the equipment it serves. Via a DC clamp-on probe, TORKEL measures the total battery current while regulating it at a constant level. Battery systems can be plus or minus grounded or free floating.


The test results can be presented and edited on a PC using the included PC software "TORKEL Viewer.

MODEL OVERVIEW

| TORKEL | 910 | 930 | 950 |
|---------------------------|-------|-------|-------|
| Current (max) | 110 A | 220 A | 220 A |
| Voltage (max) | 300 V | 300 V | 500 V |
| BVM functionality | No | Yes | Yes |
| Charging measurement | No | Yes | Yes |
| Full report functionality | No | Yes | Yes |

APPLICATION EXAMPLE

The TORKEL is connected to battery, the current and the voltage alarm levels are set. After starting the discharge, TORKEL keeps the current constant at the preset level. When the voltage drops to a level slightly above the final voltage, TORKEL issues an alarm. If the voltage drops so low that there is a risk for deep discharging the battery, TORKEL shuts down the test. If the power supply is interrupted the test will continue when power is restored. All values are stored in TORKEL and can easily be transferred via an USB-stick or ethernet cable to a PC for evaluation and print out.



Separate sensing cables (dashed lines) should be used to get accurate voltage measurements to offset the voltage drop caused by long current cables and/or high current.



FEATURES AND BENEFITS

1. TXL STOP

Output used for stop discharging from an external device (e.g. TXL). Galvanically isolated.

2. SERVICE

Connector for service purposes only.

3. ALARM

Output equipped with a relay contact for triggering an external alarm device.

4. DC OUT

9 V output for external current clamp.

5. IEXT≤1V

Input used to measure current in an external path by means of a clamp-on probe or a current shunt.

6. Display

Touch screen 7"

7. BVM1, BVM2

USB connections for BVM units.

- 8. USB connection For USB memory stick.
- 9. Ethernet connection For reports connected to PC
- **10. EMERGENCY STOP** Push to stop. Reset by turning it cloch-wise
- 11. Control knob For entering settings etc. Press to confirm a setting.
- 12. Buzzer For alarms.
- 13. ON/OFF switch





14.

Protective ground (earth) conductor terminal

15. MAINS Connector for mains supply.

16. +

Connection terminal (+) for the battery (or other DC source). **17. VOLTAGE SENSE**

Input for sensing voltage at the battery terminals. Impedance to the battery current terminals is >1 M Ω .

18. -

Connection terminal (-) for the battery (or other DC source).



Specifications are valid at nominal input voltage and an ambient temperature of +25°C, (77°F). Specifications are subject to change without notice.

Environment

| Environment | |
|----------------------|---|
| Application field | The instrument is intended for use in high-voltage substations and industrial environments. |
| Temperature | |
| Operating | 0°C to +50°C (32°F to +122°F) |
| | Power derating at temperatures over +35°C |
| | (+95°F) |
| Storage & | -40°C to +70°C (-40°F to +158°F) |
| transport | |
| Humidity | 5% – 95% RH, non-condensing |
| Shock/Vibration/Fa | II |
| Instrument only | ETSI EN 300 019-2-7 class 7M2 |
| Instrument in | ISTA 2A |
| transport case | |
| Altitude | |
| Operating | 3000 m (10000 ft) |
| Storage | 10000 m (33000 ft) |
| Encapsulation | IP20 |
| class | |
| CE-marking | |
| LVD | 2014/35/EU |
| EMC | 2014/30/EU |
| RoHS | 2011/65/EU |
| General | |
| Mains voltage | 100 – 240 V AC, 50/60 Hz |
| Power | 200 W (max) |
| consumption | |
| Power | 40 ms (max) |
| interruption | |
| Protection | Thermal cut-outs, Automatic overload pro- |
| | tection, Emergency stop button |
| Dimensions | 519x315x375 mm, (20.5" x12.4" x14.7") |
| Weight | 19.5 kg (43.0 lbs) instrument |
| | 31.9 kg (70.3 lbs) incl. standard transport case |
| | 39,2 kg (86,4 lbs) incl. large transport case and cables |
| Diamlay | |
| Display Available | 7" LCD, Capacitive touch screen |
| languages | Czech, English, French, German, Romanian, Russian, Spanish, Swedish |
| Number of test | 30 (max) |
| files | 50 (IIIax) |
| Test time | 240 h (max) |
| Measurement se | ection |
| Current measure | ement |

Current measurement

 Display range
 0.0 to 2999.0 A

 Basic inaccuracy
 ±(0.5% of reading +0.1 A)

 Resolution
 0.1 A

0 to 1000 mV DC

0.30 mV/A to 100.00 mV/A

Internal current measurement

Range

 TORKEL 910
 0 to 110 A

 TORKEL 930/950
 0 to 220 A

Input for clamp-on probe

Range mV/A-ratio


Input impedance >1 MΩ

Voltage measurement

| Voltage | 0 to 500 V DC |
|------------|-----------------------------------|
| Inaccuracy | \pm (0.5% of reading +0.1 V DC) |

| Inaccuracy | $\pm 0.1\%$ of reading ± 1 digit |
|-----------------|--|
| Load section | |
| Battery voltage | 7.5 V3) to 300 V1) / 500 V2) |
| Power | 15 kW (max) |
| Load patterns | Constant current, constant power, constant resistance, current or power profile |
| 220 | TORKEL 930/950 TORKEL 930/950 |
| 200 | ambient temperature. <35°C (95°F) |
| 180 | <50°C (122°F) |
| 160 | |

0.1 V



Constant I

Resolution

Sample rate

Time measurement

| Constant I | |
|---------------------|---|
| Range | |
| TORKEL 910 | 0 to 110.0 A |
| TORKEL 930/950 | 0 to 220.0 A |
| Inaccuracy | ±(0.5% +0.2 A) |
| Resolution | 0.1 A |
| Ripple | max 0.5 A peak |
| Constant R | |
| Range | 300 mΩ to 3 kΩ |
| Inaccuracy | ±1% typical |
| Resolution | 100 mΩ |
| Constant P | |
| Range | 0 to 15 kW |
| Inaccuracy | ±1% typical |
| Resolution | 10 W |
| Inputs | |
| + | 7.5 to 300 V ^{.1)} 7.5 to 500 V ^{.2)} |
| - | 0 V |
| $I EXT \le 1 V$ | 1 V DC, 300 V DC to ground |
| VOLTAGE SENSE | Impedance to the current terminals is >1 $M\Omega$ |
| Outputs | |
| ALARM | |
| Relay contact | 28 V DC, 8 A, 240 V AC, 8 A |
| | Devices higher than Cat II must not be at- |
| TV4 (TOD | tached |
| TXL STOP | |
| Relay contact | 250VDC, 0.28A, 28VDC, 8A, 250VAC, 8A |
| 9 V DC | 9 V DC, ±7% max 100 mA |
| Communication | • |
| BVM1 BVM2 | USB connection for BVM units |
| •~ | USB connection for USB memory |
| 문 | For reports connected to PC |
| 1) TORKEL 910 and 9 | |
| 3) On sw from R02G. | Min voltage is 2V |
| | |



10 Hz, Values are saved when change is >10 mV



SPECIFICATIONS TXL830/850/865/870/890

Specifications are valid at nominal input voltage and an ambient temperature of $+25^{\circ}$ C, (77°F). Specifications are subject to change without notice.

Environment

Application field

The instrument is intended for use in highvoltage substations and industrial environments.

Temperature

Operating Storage & transport Humidity

-40°C to +70°C (-40°F to +158°F) 5% – 95% RH, non-condensing

0°C to +40°C (32°F to +104°F)

CE-marking

LVD EMC RoHS

General

Mains voltage Power consumption Protection 2014/30/EU 2011/65/EU 100 – 240 V AC, 50/60 Hz

2014/35/EU

75 W (max)

Thermal cut-outs, automatic overload protection

Dimensions

Instrument Transport case Weight 210x353x600 mm (8.3" x 13.9" x 23.6") 710 x 310 x 520 (28" x 12.2" x 20.5") Instrument 13 kg (29 lbs) 21,4 kg (47 lbs) with transport case

Load section

| | Voltage (DC) max. | Current max. | Power max. |
|--------|-------------------|--------------|------------|
| TXL830 | 28 V | 300 A | 8.3 kW |
| TXL850 | 56 V | 300 A | 16.4 kW |
| TXL865 | 260 V (98 A max) | 117 A | 25.5 kW |
| TXL870 | 280 V (56 A max) | 112 A | 15.8 kW |
| TXL890 | 480 V (32 A max) | 62 A | 15.4 kW |

Internal resistance, 3-position selector

| | Position 1 | Position 2 | Position 3 |
|--------|------------|------------|------------|
| TXL830 | 0.275Ω | 0.138 Ω | 0.092 Ω |
| TXL850 | 0.55Ω | 0.275 Ω | 0.184 Ω |
| TXL865 | 2.65 Ω | 5.05 Ω | 0.12 Ω |
| TXL870 | 4.95Ω | 2.48 Ω | 1.24 Ω |
| TXL890 | 14.10Ω | 7.05 Ω | 3.52 Ω |

Maximal currents, 3-position selector¹⁾ Position 1

| | Current | Voltage | Cells | Cell voltage |
|-----------|---------|---------|-------|--------------|
| TXL830 | 100 A | 27.6 V | 12 | 2.3 V |
| 28 V max | 78.5 A | 21.6 V | 12 | 1.8 V |
| TXL850 | 100 A | 55.2 V | 24 | 2.3 V |
| 56 V max | 78.5 A | 43.2 V | 24 | 1.8 V |
| TXL865 | 93.7 A | 248.4 V | 108 | 2.3 V |
| 260 V max | 73.4 A | 194.4 V | 108 | 1.8 V |
| TXL870 | 50.1 A | 248.4 V | 108 | 2.3 V |
| 280 V max | 39.2 A | 194.4 V | 108 | 1.8 V |
| TXL890 | 32.3 A | 469.2 V | 204 | 2.3 V |
| 480 V max | 26.0 A | 367.2 V | 204 | 1.8 V |

Position 2

| | Current | Voltage | Cells | Cell voltage |
|----------------------------|---------|---------|-------|--------------|
| TXL830 | 200 A | 27.6 V | 12 | 2.3 V |
| 28 V max | 156 A | 21.6 V | 12 | 1.8 V |
| TXL850 | 200 A | 55.2 V | 24 | 2.3 V |
| 56 V max | 156 A | 43.2 V | 24 | 1.8 V |
| TXL865 260 V max | 49.2 A | 248.4 V | 108 | 2.3 V |
| | 38.5 A | 194.4 V | 108 | 1.8 V |
| TXL870 | 50.1 A | 124.2 V | 54 | 2.3 V |
| 280 V max | 39.2 A | 97.2 V | 54 | 1.8 V |
| TXL890 | 35.2 A | 248.4 V | 108 | 2.3 V |
| 480 V max | 27.8 A | 194.4 V | 108 | 1.8 V |

Position 3

| | Current | Voltage | Cells | Cell voltage |
|---|---------|---------|-------|--------------|
| TXL830 | 300 A | 27.6 V | 12 | 2.3 V |
| 28 V max | 235 A | 21.6 V | 12 | 1.8 V |
| TXL850 | 300 A | 55.2 V | 24 | 2.3 V |
| 56 V max | 235 A | 43.2 V | 24 | 1.8 V |
| TXL865 14 V max | 115 A | 13.8 V | 6 | 2.3 V |
| | 90 A | 10.8 V | 6 | 1.8 V |
| TXL870 | 100 A | 124.2 V | 54 | 2.3 V |
| 140 V max | 74.8 A | 97.2 V | 54 | 1.8 V |
| TXL890 | 70.5 A | 248.4 V | 108 | 2.3 V |
| 250 V max | 55.2 A | 194.4 V | 108 | 1.8 V |
| 1) The data examples apply to lead batteries. | | | | |



OPTIONAL ACCESSORIES

Extra loads



Five extra loads available: TXL830, TXL850, TXL865, TXL870 and TXL890

BVM - Battery Voltage Monitoring



Enables automatic battery cell voltage logging during capacity tests Up to 2x120 units can be used (Daisychain) For complete information see the BVM data sheet

(CJ0062XX)

Clamp-on-probe



Cable set Torkel 930/950



Extension cables





Sensing leads



Software

PowerDB is a PC software for BVM and TORKEL 800 / 900-series. For BVM and TORKEL 800 series it works for controlling, data management and report handling. For TORKEL 900-series only for data management and reporting.



INCLUDED ACCESSORIES – TORKEL 910

Cable set



Ground Cable




INCLUDED ACCESSORIES – TORKEL 930/950

Cable set



TORKEL Viewer



TORKEL Viewer is a free software, download at www.megger.com (search "TORKEL900" and submenu "Software"). Open the file and follow the instructions.

Please note that TORKEL Viewer can only be used with TORKEL930 and TORKEL950.

For TORKEL910, TORKEL Viewer cannot be used. A payable license fee for FW upgrade is needed. (E.g. material number CS-90010, "Upgrade Torkel 910 to 930")

ORDERING INFORMATION

| | | DENING | |
|--|------------|------------|--|
| ltem | | Cat. No. | |
| TORKEL 910 | | | |
| Incl. transport case Standard ¹⁾ and acc | cessories: | | |
| Mains cable | | 7 | |
| Cable set, 2 x 3 m, 25 mm ² | GA-00550 | 1 | |
| Soft case for cables | 2012-180 | CS-19190 | |
| Incl. transport case Large ²⁾ and access | ories: | | |
| Mains cable | | 7 | |
| Cable set, 2 x 3 m, 25 mm ² | GA-00550 | - | |
| TORKEL 930 | | └ CS-19191 | |
| Incl. transport case Standard ¹⁾ and acc | essories. | | |
| Mains cable | | 1 | |
| Cable set, 2 x 3 m, 70 mm ² | GA-09550 | - | |
| Soft case for cables | 2012-180 | - | |
| TORKEL Viewer | CS-8010X | 1 | |
| USB memory stick | HF-10020 | CS-19390 | |
| Incl. transport case Large ²⁾ and access | ories: | | |
| Mains cable | | 1 | |
| Cable set, 2 x 3 m, 70 mm ² | GA-09550 | 1 | |
| TORKEL Viewer | CS-8010X | - | |
| USB memory stick | HF-10020 | | |
| TORKEL 950 | 1 | 」CS-19391 | |
| Incl. transport case Standard ¹⁾ and acc | essories. | | |
| Mains cable | | 7 | |
| Cable set, 2 x 3 m, 70 mm ² | GA-09550 | - | |
| Soft case for cables | 2012-180 | - | |
| TORKEL Viewer | CS-8010X | - | |
| USB memory stick | HF-10020 | CS-19590 | |
| Incl. transport case Large ²⁾ and access | orios: | 1 C3-19390 | |
| Mains cable | | | |
| Cable set, 2 x 3 m, 70 mm ² | GA-09550 | | |
| TORKEL Viewer | CS-8010X | | |
| USB memory stick | HF-10020 | 66 40504 | |
| Included in all models above: | 111 10020 | CS-19591 | |
| Ground cable, 5 m (16 ft) 2.5 mm ² | | GC-30060 | |
| Optional accessories | | | |
| Transport case Standard , for TORKEL(| no cables) | GD-00954 | |
| Transport case Large for TORKEL and s | GD-00955 | | |
| TXL830 Extra load | | | |
| Incl. Cable set GA-09550, 2x3 m 70 m | 2*) | BS-59093 | |
| TXL850 Extra load Incl. Cable set GA-09550, 2x3 m 70 m | BS-59095 | | |
| TXL865 Extra load Incl. Cable set GA-00550, 2x3 m 25 m | BS-59096 | | |
| TXL870 Extra load Incl. Cable set GA-00550, 2x3 m 25 m² | BS-59097 | | |
| TXL890 Extra load | | | |
| Incl. Cable set GA-00550, 2x3 m 25 m ² | BS-59099 | | |
| *) Control leads 2 x 2 m (6.5 ft),Trans | port case. | | |
| Mains cable | | | |

| ORMATION | |
|--|----------|
| Item | Cat. No. |
| Cable set | |
| 2x3m, 25mm ² , female/clamp. 110A. 3.0kg (6.6 lbs) | GA-00550 |
| Extension cable | |
| Extension for GA-00550, 2x3m, 25mm ² , male/female | GA-00552 |
| Cable set | |
| 2x3m, 50 mm ² , female/clamp 220 A. 5.0 kg (11 lbs) | GA-00545 |
| Cable set, high rating | |
| 2 x 3 m, 70 mm ² , female/fork. 270 A. 5.0 kg (11 lbs) | GA-09550 |
| Extension cable, high rating Extension for GA-09550,and GA-00545, 2x3m, | |
| $70 \mathrm{mm^2}$, male/female | GA-09552 |
| Sensing lead set | 0/(05552 |
| For measuring voltage at battery terminals. 2 x 5 m | |
| (16.4 ft) | GA-00210 |
| DC clamp-on probe, 1000 A | |
| To measure current in external circuit | XA-12991 |
| BVM | |
| Incl. Dolphin clips, Power & signal connectors, Power supplies, Connection cables and Carrying case | |
| BVM150 , System of 16 BVM units | CJ-59092 |
| BVM150, System of 31 BVM units | CJ-59092 |
| BVM600, System of 61 BVM units | CJ-59095 |
| BVM special 600 V, System of 46 BVM units ³⁾ | 0-39090 |
| Incl. Dolphin clips, Power & signal connectors, | |
| Opto couplers, Power supplies, Connection cables and | |
| Carrying case. | CJ-59198 |
| BVM, Single unit | |
| Incl. Control cable black RJ45 0.5m (1.6 ft) | CJ-59090 |
| Extension cable Extension lead for connecting BVM unit to battery, | |
| 0.5 m (1.6 ft) | 04-30050 |
| 3) The TORKEL 950 can handle a maximum of 500 V. Ba | |
| over 500 V and up to 600 V can be tested with BVM a | |
| application on a computer. | |



Postal address Megger Sweden AB Box 724 SE-182 17 Danderyd SWEDEN TORKEL900-series_DS_en_V12 ZI-CS01E • Doc. CS033664LE • 2022 Subject to change without notice Megger Sweden AB Registered to ISO 9001 and 14001 The word 'Megger' is a registered trademark



Test Equipment Depot - 800.517.8431 - TestEquipmentDepot.com