

# micro CA-25 Inspection Camera



## **⚠ WARNING!**

Read this Operator's Manual carefully before using this tool. Failure to understand and follow the contents of this manual may result in electrical shock, fire and/or serious personal injury.

**Test Equipment  
Depot**  
1-800-517-8431

99 Washington Street  
Melrose, MA 02176  
Phone 781-665-1400  
Toll Free 1-800-517-8431



Visit us at [www.TestEquipmentDepot.com](http://www.TestEquipmentDepot.com)

## Safety Symbols

In this operator's manual and on the product, safety symbols and signal words are used to communicate important safety information. This section is provided to improve understanding of these signal words and symbols.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.



**DANGER** indicates a hazardous situation which, if not avoided, will result in death or serious injury.



**WARNING** indicates a hazardous situation which, if not avoided, could result in death or serious injury.



**CAUTION** indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.



**NOTICE** indicates information that relates to the protection of property.



This symbol means read the operator's manual carefully before using the equipment. The operator's manual contains important information on the safe and proper operation of the equipment.



This symbol means always wear safety glasses with side shields or goggles when handling or using this equipment to reduce the risk of eye injury.



This symbol indicates the risk of hands, fingers or other body parts being caught or wrapped in gears or other moving parts.



This symbol indicates the risk of electrical shock.

## General Safety Information

### ⚠ WARNING

**Read all safety warnings and instructions. Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury.**

### SAVE THESE INSTRUCTIONS!

### Work Area Safety

- **Keep your work area clean and well lit.** Cluttered or dark areas invite accidents.
- **Do not operate equipment in explosive atmospheres, such as in the presence of flammable liquids, gases or dust.** Equipment can create sparks which may ignite the dust or fumes.
- **Keep children and by-standers away while operating equipment.** Distractions can cause you to lose control.

### Electrical Safety

- **Avoid body contact with earthed or grounded surfaces such as pipes, radiators, ranges and refrigerators.** There is an increased risk of electrical shock if your body is earthed or grounded.

- **Do not expose equipment to rain or wet conditions.** Water entering equipment will increase the risk of electrical shock.

### Personal Safety

- **Stay alert, watch what you are doing and use common sense when operating equipment. Do not use equipment while you are tired or under the influence of drugs, alcohol or medication.** A moment of inattention while operating equipment may result in serious personal injury.
- **Do not overreach. Keep proper footing and balance at all times.** This enables better control of the power tool in unexpected situations.
- **Use personal protective equipment.** Always wear eye protection. Protective equipment such as dust mask, non-skid safety shoes, hard hat or hearing protection used for appropriate conditions will reduce personal injuries.

### Equipment Use and Care

- **Do not force equipment. Use the correct equipment for your application.** The correct equipment will do the job better and safer at the rate for which it is designed.
- **Do not use equipment if the switch**

does not turn it ON and OFF. Any tool that cannot be controlled with the switch is dangerous and must be repaired.

- **Disconnect the batteries from the equipment before making any adjustments, changing accessories, or storing.** Such preventive safety measures reduce the risk of injury.
- **Store idle equipment out of the reach of children and do not allow persons unfamiliar with the equipment or these instructions to operate the equipment.** Equipment can be dangerous in the hands of untrained users.
- **Maintain equipment.** Check for misalignment or binding of moving parts, missing parts, breakage of parts and any other condition that may affect the equipment's operation. If damaged, have the equipment repaired before use. Many accidents are caused by poorly maintained equipment.
- **Use the equipment and accessories in accordance with these instructions, taking into account the working conditions and the work to be performed.** Use of the equipment for operations different from those intended could result in a hazardous situation.
- **Use only accessories that are recommended by the manufacturer for your equipment.** Accessories that may be suitable for one piece of equipment may become hazardous when used with other equipment.
- **Keep handles dry and clean; free from oil and grease.** Allows for better control of the equipment.

## Service

- **Have your equipment serviced by a qualified repair person using only identical replacement parts.** This will ensure that the safety of the tool is maintained.

## Specific Safety Information

### **WARNING**

**This section contains important safety information that is specific to the inspection camera.**

**Read these precautions carefully before using the micro CA-25 Inspection Cam-**

**era to reduce the risk of electrical shock or other serious injury.**

### **SAVE THESE INSTRUCTIONS!**

A manual holder is supplied in the carrying case of the micro CA-25 Inspection Camera to keep this manual with the tool for use by the operator.

## micro CA-25 Inspection Camera Safety

- **The micro CA-25 imager head and cable are waterproof to 4' (1.2 m). The handheld display unit is not.** Do not expose the display unit to water or rain. This increases the risk of electrical shock.
- **Do not place the micro CA-25 Inspection Camera anywhere that may contain a live electrical charge.** This increases the risk of electrical shock.
- **Do not place the micro CA-25 Inspection Camera anywhere that may contain moving parts.** This increases the risk of entanglement injuries.
- **Do not use this device for personal inspection or medical use in any way.** This is not a medical device. This could cause personal injury.
- **Always use appropriate personal protective equipment while handling and using the micro CA-25 Inspection Camera.** Drains and other areas may contain chemicals, bacteria and other substances that may be toxic, infectious, cause burns or other issues. **Appropriate personal protective equipment always includes safety glasses and gloves,** and may include equipment such as latex or rubber gloves, face shields, goggles, protective clothing, respirators and steel-toed footwear.
- **Practice good hygiene.** Use hot, soapy water to wash hands and other exposed body parts exposed to drain contents after handling or using the micro CA-25 Inspection Camera to inspect drains and other areas that may contain chemicals or bacteria. Do not eat or smoke while operating or handling the micro CA-25 Inspection Camera. This will help prevent contamination with toxic or infectious material.
- **Do not operate the micro CA-25 Inspection Camera if operator or device is standing in water.** Operating an electrical

device while in water increases the risk of electrical shock.

Weight.....1.35 lbs (0,6 kg)

## Description, Specifications and Standard Equipment

### Description

The micro CA-25 Inspection Camera displays live color video from an imaging sensor and light source that's connected to a 4' (1.2 m) flexible cable. It can be used to look into tight spots and beam back real-time video to a color LCD. It comes with a 11/16" (17 mm) camera head for general use.

### Specifications

Display.....	2.7" (68,6 mm) Color LCD (320 x 240 Resolution)
Lighting.....	4 Adjustable LEDs
Cable Reach.....	4' (1.2 m) Fixed Cable Waterproof to 4' (1.2 m) (IP67)
Camera Head.....	11/16" (17mm)
Video Output.....	RCA (3' (0,9 m) Cable Included)
TV-Out.....	NTSC
Operating Temp.....	32°F - 122°F (0 C ~ 50°C)
Storage Temp.....	4°F - 140°F (-20°C ~ 60°C)
Storage Humidity.....	15% ~ 85% RH
Depth of Field (DOF).....	0.04" (10mm) ~ • (infinity)
Power Source.....	4 x "AA" Alkaline or Rechargeable Batteries
Attachments.....	Hook, Magnet, Mirror

### Standard Equipment

The micro CA-25 Inspection Camera comes with the following items:

- micro CA-25 with Fixed 4' (1.2 m) 17mm Imager
- 3' (90 cm) RCA Cable
- Hook, Magnet, Mirror Attachments
- 4 x "AA" Batteries
- Carrying Case
- Operator's Manual



Figure 1 – micro CA-25

### Controls



Figure 2 – Controls

## FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment OFF and ON, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

## Electromagnetic Compatibility (EMC)

The term electromagnetic compatibility is taken to mean the capability of the product to function smoothly in an environment where electromagnetic radiation and electrostatic discharges are present and without causing electromagnetic interference to other equipment.

**NOTICE** The RIDGID micro CA-25 Inspection Camera conforms to all applicable EMC standards. However, the possibility of it causing interference in other devices cannot be precluded.

## Tool Assembly

### **⚠ WARNING**

**To reduce the risk of serious injury during use, follow these procedures for proper assembly.**

### Changing/Installing Batteries

The micro CA-25 is supplied without batteries installed. If the power status light is red, the batteries need to be replaced. Remove the

batteries prior to long term storage to avoid battery leakage.

1. Slide lock button toward middle to open battery door (See *Figure 3*) and remove battery compartment from the micro CA-25 Inspection Camera (See *Figure 4*). If needed, remove batteries.



Figure 3 – Battery Door

2. Install 4 new AA alkaline batteries (LR6), observing the correct polarity as indicated on the battery compartment. Only replace in sets to help prevent battery leakage.
3. Insert battery compartment into inspection camera terminal end first. The compartment will only go in one way. Do not force. Close the battery door, confirm securely closed.



Figure 4 – Battery Compartment

### Installing An Accessory

The three included accessories, (mirror, hook and magnet) (*Figure 1*) all attach to the imager head the same way.

To connect, hold the imager head as shown in *Figure 5*. Slip the semicircle end of the accessory over the flats of the imager head as shown in *Figure 5*. Then rotate the accessory a 1/4 turn so the long arm of the accessory is extending out as shown.



Figure 5 – Installing Accessories

## Pre-Operation Inspection

### ⚠ WARNING



**Before each use, inspect your inspection camera and correct any problems to reduce the risk of serious injury from electric shock and other causes and prevent tool damage.**

1. Make sure the unit is OFF.
2. Remove the battery holder and inspect it and batteries for signs of damage. Replace batteries if necessary. Do not use inspection camera if batteries are damaged.
3. Clean any oil, grease or dirt from the equipment. This aids inspection and helps prevent the tool from slipping from your grip.
4. Inspect micro CA-25 Inspection Camera for any broken, worn, missing, misaligned or binding parts or any condition which may prevent safe and normal operation.
5. Inspect the camera head lens for condensation. To avoid damaging the unit, do not use the camera if condensation forms inside the lens. Let the water evaporate before using.
6. Inspect the full length of the cable for cracks or damage. A damaged cable could allow water to enter the unit and increase the risk of electrical shock.
7. Check that the warning label is present, firmly attached and readable.



Figure 6 – Warning Label

8. If any issues are found during the inspection, do not use the inspection camera until it has been properly serviced.
9. With dry hands, re-install the battery holder, making sure to fully insert.
10. Press and Hold the Power Button for 1 second. Once the camera is ready an image will appear. If the unit does not operate properly, try changing the batteries.
11. Press and Hold the Power Button for 1 second to turn the unit OFF.

## Tool and Work Area Set-Up

### ⚠ WARNING



**Set up the micro CA-25 Inspection Camera and work area according to these procedures to reduce the risk of injury from electrical shock, entanglement and other causes and prevent tool and system damage.**

1. Check work area for:
  - Adequate lighting
  - Flammable liquids, vapors or dust that may ignite. If present, do not work in area until sources have been identified and corrected. The micro CA-25 Inspection Camera is not explosion proof and can cause sparks.

- Clear, level, stable, dry place for operator. Do not use the inspection camera while standing in water.
2. Examine the area or space that you will be inspecting and determine if the micro CA-25 Inspection Camera is the correct piece of equipment for the job.

- Determine the access points to the space. The minimum opening the camera head can fit through is approximately  $\frac{3}{4}$ " (19 mm) in diameter for the 17 mm camera head.
- Determine if there are any obstacles that would require very tight turns in the cable. The inspection camera cable can go down to a 2" (50 mm) radius without damage.
- Determine if there is any electrical power supplied to the area to be inspected. If so, the power to the area must be turned off to reduce the risk of electric shock. Use appropriate lock out procedures to prevent the power from being turned back on during the inspection.
- Determine if any chemicals are present, especially in the case of drains. It is important to understand the specific safety measures required to work around any chemicals present. Contact the chemical manufacturer for required information. Chemicals may damage or degrade the inspection camera.
- Determine the temperature of the area and items in the area. The working temperature of the inspection camera is between 32 and 122 degrees F (0°C - 50°C). Use in areas outside of this range or contact with hotter or colder items could cause camera damage.
- Determine if any moving parts are present in the area to be inspected. If so, these parts must be deactivated to prevent movement during inspection to reduce the risk of entanglement. Use appropriate lock out procedures to prevent the parts from moving during the inspection.

If the micro CA-25 Inspection Camera is not the correct piece of equipment for the job, other inspection equipment is available from RIDGID. For a complete listing of RIDGID products, see the RIDGID catalog.

3. Make sure the micro CA-25 Inspection Camera has been properly inspected.
4. Install the correct accessories for the application.

## Operating Instructions

### ⚠ WARNING



**Always wear eye protection to protect your eyes against dirt and other foreign objects.**

**Follow operating instructions to reduce the risk of injury from electrical shock, entanglement and other causes.**

1. Make sure that the inspection camera and work area have been properly set up and that the work area is free of bystanders and other distractions.



Figure 7 – Controls

2. **Power On:** Press and Hold the power button for 1 second.

The power status light will come ON. If the power status light is GREEN, the micro CA-25 Inspection Camera batteries are good. If the power status light is RED, the batteries need to be changed. If the LED does not turn ON, the batteries need to be changed.

3. **Pre-Form The Cable:** If needed for the area to be inspected, pre-form the cable. Do not try to form bends with a radius of less than 2" (50 mm) as this can damage the cable.

- LED Brightness Adjustment:** Turn the LEDs ON. The imager head is equipped with four white LEDs to aid inspection. Use the + and – buttons to turn ON and adjust the brightness of the LEDs.
- Inspection:** Insert the imager head and cable into the space to be inspected. Do not use the imager head or cable for anything other than an inspection device. Do not use the imager head and cable to clear a path. Do not force the imager head and cable through tight bends or spaces. These uses can damage the unit and the area to be inspected.
- Image Rotation:** If needed, the image seen on the screen can be rotated in 180 degree increments by pressing the rotate image button.
- Power Off:** When the inspection is complete, carefully withdraw the imager and cable from the inspection area. Press and Hold the power button for 1 second to turn the unit OFF. The unit will automatically turn OFF 30 minutes after the last button press or if the batteries drop too low.

## Viewing

The micro CA-25 Inspection Camera can be connected to a television or other monitor for remote viewing or recording through the included RCA cable. Open the rubber cover on the side of the screen and insert the RCA cable into the TV-OUT jack.

Insert the other end into the Video In jack on the television or monitor. The television or monitor may need to be set to the proper input to allow viewing.



Figure 8 – TV-OUT Jack

## Cleaning

### ⚠ WARNING

**Remove batteries before cleaning.**

- Always clean the imager head and cable after use with mild soap or mild detergent.
- Gently clean the LCD with a clean dry cloth. Avoid rubbing too hard on the LCD.
- Wipe the hand held display unit down with a clean, dry cloth.

## Storage

The RIDGID micro CA-25 Inspection Camera must be stored in a dry secure area between -4°F (-20°C) and 140°F (60°C).

Store the tool in a locked area out of the reach of children and people unfamiliar with the micro CA-25 Inspection Camera.

Remove the batteries before any long period of storage or shipping to avoid battery leakage.

## Service and Repair

### ⚠ WARNING

**Improper service or repair can make the RIDGID micro CA-25 Inspection Camera unsafe to operate.**

RIDGID tools are warranted to be free of defects in workmanship and material. Should this product require service.

## Disposal

Parts of the RIDGID micro CA-25 Inspection Camera contain valuable materials and can be recycled. There are companies that specialize in recycling that may be found locally. Dispose of the components in compliance with all applicable regulations. Contact your local waste management authority for more information.






**For EC Countries:** Do not dispose of electrical equipment with household waste!

According to the European Guideline 2002/96/EC for Waste Electrical and Electronic Equipment and its implementation into national legislation, electrical equipment that is no longer usable must be collected separately and disposed of in an environmentally correct manner.

## **Battery Disposal**

For EC countries: Defective or used batteries must be recycled according to the guideline 2006/66/EEC.

**Test Equipment  
Depot**



**1-800-517-8431**

99 Washington Street  
Melrose, MA 02176  
Phone 781-665-1400  
Toll Free 1-800-517-8431

 Visit us at [www.TestEquipmentDepot.com](http://www.TestEquipmentDepot.com)