TRACEABLE® CARBON-FIBER CALIPER INSTRUCTIONS

TURNING THE UNIT ON/OFF

To turn the unit on, press the ON button.

To turn the unit off, press the OFF button.



5 Commonwealth Ave Woburn, MA 01801 Phone 781-665-1400 Toll Free 1-800-517-8431

INCHES OR MILLIMETERS

Once the unit has been turned on, each press of the inch/mm button will toggle the display between inches and millimeters.

While taking a measurement, press the inch/mm button at any time to covert from one unit of measure to the other.

ZERO ADJUSTING

Clean the measuring surfaces by rubbing a clean piece of paper between the caliper surfaces several times.

Push the measuring surfaces together.

Reset the display to **0.0** by pressing the **ZERO** button.

NOTE

The graduated scale on the caliper body is for approximate reference only, the exact measurement, accurate to ã0.2mm/0.01", is shown on the LCD display.

All Operational Difficulties

If this unit does not function properly for any reason, replace the battery with a new high-quality battery (see "Battery Replacement" section). Low bat tery power can occasionally cause any number of "apparent" operational difficulties. Replacing the battery with a new fresh battery will solve most difficulties.

Battery Replacement

Erratic readings, a faint display, or no display are all indications that the battery must be replaced. Slide the battery cover off (away from the display). Remove the exhausted battery and replace with a new 1.5 volt silver-oxide battery. Equivalent battery replacements are: RAYOVAC RW42, DURAC ELL D357, GPA76, and EVEREADY 357. Make certain to insert the new battery with the positive (+) side up. Replace the battery cover.

WARRANTY, SERVICE, OR RECALIBRATION

For warranty, service, or recalibration, contact:

CONTROL COMPANY

Control Company is ISO 9001 Quality-Certified by DNV and ISO 17025 accredited as a Calibration Laboratory by A2LA.