SPECIFICATIONS		ULTRA™ THERMOMETER ACCURACY	DATA HOLD	BATTERY REPLACEMENT
Range:	−58 to 572 °F −50 to 300 °C	Ultra™ thermometers are tested at selected test points to be within tighter than normal tolerances to assist in providing improved accuracy. Other points will not necessarily fall within the same accuracy as those found at the selected test points, but will be	Slide the HOLD/TEST switch to TEST to make measurements. Slide the HOLD/TEST switch to HOLD to "freeze" the display at the current reading, "F/"C will flash on the display. Once the reading has been recorded, slide the HOLD/TEST switch to TEST to	Erratic readings, a faint display indications that the battery mu replace the battery, remove the it in the direction indicated by Remove the exhausted battery
Accuracy:	<b>Cat. No. 4050</b> ±1.5°			
	Cat. No. 4350	within an accuracy of $\pm 1.5$ °C.	"release" the display and return to the current read-	a new 1.5 volt size G-13 batter
	$\pm 0.4^{\circ}$ at tested points $\pm 1.5^{\circ}$ C otherwise	OPERATION	ing, °F/°C will no longer flash on the display.	No. 1039). Make certain that the facing you. Replace the batter
		<ol> <li>Remove the stem from the protective sheath.</li> </ol>	ALL OPERATIONAL DIFFICULTIES	
Resolution:	0.1° from –20 to 200	<ol><li>Slide the ON/OFF switch to ON.</li></ol>	If this thermometer does not function properly for any	
	(otherwise 1°)	3. Slide the °F/°C switch to °F to display the tem-	reason, please replace the battery with a new high-	
Sampling Rate:	1 second	perature in Fahrenheit or to °C to display the temperature in Celsius.	quality battery (see "Battery Replacement" section).  Low battery power can occasionally cause any num-	
Stem Length:	31/2" (8.9 cm)	4. Slide the HOLD/TEST switch to TEST and insert	ber of "apparent" operational difficulties. Replacing	
Stem Diameter:	0.15" (3.8 mm)	the stem of the thermometer into the material to be measured.	the battery with a new fresh battery will solve most difficulties. If the voltage of the battery becomes low	
Overall Length:	7" (17.8 cm)	<ol><li>Slide the ON/OFF switch to OFF.</li></ol>	°C and °F symbols will flash.	

6. Replace the protective sheath.

Battery:

Cat. No. 1039

## readings, a faint display, or no display are all tions that the battery must be replaced. To

e the battery, remove the battery cap by turning e direction indicated by the "OPEN" arrow. ve the exhausted battery and replace it with

1.5 volt size G-13 battery (Replacement Cat. 39). Make certain that the positive (+) side is you. Replace the battery cap.

TestEquipmentDepot.com

1-800-517-8431