



Data Sheet





BT-120 Breaker tracers

The Amprobe breaker finders work on energized systems and are designed to quickly and easily indentify breakers in residential and commercial environments. Automatic sensitivity adjustment removes ambiguity from the results of the tracing, and the receiver will clearly and quickly identify the breaker with sound and light.

- Used to identify circuit breakers
- Automatic sensitivity adjustment is easier to use and faster than the manual one
- Microprocessor controlled design provides extremely accurate readings (always finds the right breaker)
- Durable and dependable
- BT-120 works with standard 120V breakers
- UL Listed

No hassle warranty

No waiting.

No shipping charges.



(note: \$500 MSLP limit)





BT-120 Breaker tracers Data Sheet

Specifications

| Voltage Range | 90 to 120V |
|---------------------------------|--|
| Operating Frequency | 50 - 60 Hetz |
| Storage Temperature | 0-40 Degrees C |
| Operating Temperature | 0-40 Degrees C |
| Sensitivity Adjustment | Automatic |
| Power Supply | 9-Volt Alkaline Battery (Receiver Only) |
| Transmitter Polarity | Automatic |
| Humidity | 80% RH (non condensing) |
| Environmental Conditions | For Indoor use, For Altitudes up to 2000 m, Pollution Degree 2 |
| Installation Category II | |
| Caution | HTP-HVL cord assembly to be used with Circuit Detective Transmitter only according to instructions |

Included Accessories

Users Manual