micro CA-350 Operator's Manual

micro CA-350 Inspection Camera

RIDGID





 pment
 99 Washington Street

 Depot
 Melrose, MA 02176

 Phone 781-665-1400

 7-8431
 Toll Free 1-800-517-8431

Visit us at www.TestEquipmentDepot.com

Safety Symbols

In this operator's manual and on the product, safety symbols and signal words are used to communicate important safety information. This section is provided to improve understanding of these signal words and symbols.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

A DANGER DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.

A WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

A CAUTION

death or serious injury. CAUTION indicates a hazardous situation which, if not avoided, could result in minor

or moderate injury.

NOTICE indicates information that relates to the protection of property.

This symbol means read the operator's manual carefully before using the equipment. The operator's manual contains important information on the safe and proper operation of the equipment.

This symbol means always wear safety glasses with side shields or goggles when handling or using this equipment to reduce the risk of eye injury.

This symbol indicates the risk of hands, fingers or other body parts being caught or wrapped in gears or other moving parts.



This symbol indicates the risk of electrical shock.

General Safety Information

A WARNING

Read all safety warnings and instructions. Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury.

SAVE THESE INSTRUCTIONS!

Work Area Safety

- Keep your work area clean and well lit. Cluttered or dark areas invite accidents.
- Do not operate equipment in explosive atmospheres, such as in the presence of flammable liquids, gases or dust. Equipment can create sparks which may ignite the dust or fumes.
- Keep children and by-standers away while operating equipment. Distractions can cause you to lose control.

Electrical Safety

 Avoid body contact with earthed or grounded surfaces such as pipes, radiators, ranges and refrigerators. There is an increased risk of electrical shock if your body is earthed or grounded. Do not expose equipment to rain or wet conditions. Water entering equipment will increase the risk of electrical shock.

Personal Safety

- Stay alert, watch what you are doing and use common sense when operating equipment. Do not use equipment while you are tired or under the influence of drugs, alcohol or medication. A moment of inattention while operating equipment may result in serious personal injury.
- Do not overreach. Keep proper footing and balance at all times. This enables better control of the power tool in unexpected situations.
- Use personal protective equipment. Always wear eye protection. Protective equipment such as dust mask, non-skid safety shoes, hard hat or hearing protection used for appropriate conditions will reduce personal injuries.

Equipment Use and Care

 Do not force equipment. Use the correct equipment for your application. The correct equipment will do the job better and safer at the rate for which it is designed.

- Do not use equipment if the switch does not turn it ON and OFF. Any tool that cannot be controlled with the switch is dangerous and must be repaired.
- Disconnect the batteries from the equipment before making any adjustments, changing accessories, or storing. Such preventive safety measures reduce the risk of injury.
- Store idle equipment out of the reach of children and do not allow persons unfamiliar with the equipment or these instructions to operate the equipment. Equipment can be dangerous in the hands of untrained users.
- Maintain equipment. Check for missing parts, breakage of parts and any other condition that may affect the equipment's operation. If damaged, have the equipment repaired before use. Many accidents are caused by poorly maintained equipment.
- Use the equipment and accessories in accordance with these instructions, taking into account the working conditions and the work to be performed. Use of the equipment for operations different from those intended could result in a hazardous situation.
- Use only accessories that are recommended by the manufacturer for your equipment. Accessories that may be suitable for one piece of equipment may become hazardous when used with other equipment.
- Keep handles dry and clean; free from oil and grease. Allows for better control of the equipment.

Battery Use & Care

- Recharge only with the charger specified by the manufacturer. A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack.
- Use equipment only with specifically designated battery packs. Use of any other battery packs may create a risk of injury and fire.
- When a battery pack is not in use, keep it away from other metal objects, like paper clips, coins, keys, nails, screws or other small metal objects that can make a connection from one terminal to an-

other. Shorting the battery terminals together may cause burns or a fire.

 Under abusive conditions, liquid may be ejected from the battery; avoid contact. If contact accidentally occurs, flush with water. If liquid contacts eyes, additionally seek medical help. Liquid ejected from the battery may cause irritation or burns.

Service

 Have your equipment serviced by a qualified repair person using only identical replacement parts. This will ensure that the safety of the tool is maintained.

Specific Safety Information

A WARNING

This section contains important safety information that is specific to the inspection camera.

Read these precautions carefully before using the RIDGID[®] micro CA-350 Inspection Camera to reduce the risk of electrical shock or other serious injury.

SAVE THESE INSTRUCTIONS!

A manual holder is supplied in the carrying case of the micro CA-350 Inspection Camera to keep this manual with the tool for use by the operator.

micro CA-350 Inspection Camera Safety

- Do not expose the display unit to water or rain. This increases the risk of electrical shock. The micro CA-350 imager head and cable are waterproof to 10' (3 m). The hand-held display unit is not.
- Do not place the micro CA-350 Inspection Camera anywhere that may contain a live electrical charge. This increases the risk of electrical shock.
- Do not place the micro CA-350 Inspection Camera anywhere that may contain moving parts. This increases the risk of entanglement injuries.
- Do not use this device for personal inspection or medical use in any way. This is not a medical device. This could cause personal injury.

- Always use appropriate personal protective equipment while handling and using the micro CA-350 Inspection Camera. Drains and other areas may contain chemicals, bacteria and other substances that may be toxic, infectious, cause burns or other issues. Appropriate personal protective equipment always includes safety glasses and gloves, and may include equipment such as latex or rubber gloves, face shields, goggles, protective clothing, respirators and steel-toed footwear.
- Practice good hygiene. Use hot, soapy water to wash hands and other body parts exposed to drain contents after handling or using the micro CA-350 Inspection Camera to inspect drains and other areas that may contain chemicals or bacteria. Do not eat or smoke while operating or handling the micro CA-350 Inspection Camera. This will help prevent contamination with toxic or infectious material.
- Do not operate the micro CA-350 Inspection Camera if operator or device is standing in water. Operating an electrical device while in water increases the risk of electrical shock.
- Before operating a micro CA-350 Inspection Camera, read and understand:
 - This operator's manual,
 - The battery/charger manual,
 - The instructions for any other equipment used with this tool,

Failure to follow all instructions and warnings may result in property damage and/or serious injury.

The EC Declaration of conformity (890-011-320.10) will accompany this manual as a separate booklet when required.

Description, Specifications and Standard Equipment

Description

The RIDGID[®] micro CA-350 Inspection Camera is a powerful handheld digital recording device. It is a complete digital platform that allows you to perform inspections and record pictures and videos in hard to reach areas. Several image manipulation features such as image rotation and digital zoom are built into the system to ensure detailed and accurate visual inspections. The tool has external memory and TV-Out features. Accessories (hook, magnet and mirror) are included to attach to the imager head to provide application flexibility.

Specifications

Recommended Use	
Viewable Distance Display	. ,
Camera Head	3/4" (17mm)
Lighting	4 Adjustable LEDs
Cable Reach	3' (0,9 m), Expand- able to 30' (9 m) with Optional Extensions, Imager and Cable are Waterproof to 10' (3 m), IP67
Photo Format	JPEG
Image Resolution	640 x 480
Video Format	MP4
Video Resolution	640 x 480
Frame Rate	up to 30 FPS
TV-Out	PAL/NTSC
	User selectable
Built-In Memory	235 MB Memory
External Memory	SD™ Card 32 GB max (8 GB supplied)
Data Output	USB Data Cable and SD™ Card
Operating	
Temperature	
	(0 to 45°C)
Storage Temperature.	4°F to 140°F (-20°C to 60°C)

Power Supply......12V Li-Ion Battery AC Adapter 12V, 3 Amp

Weight.....5.5 lbs (2,5 kg)

Standard Equipment

The micro CA-350 Inspection Camera comes with the following items:

- micro CA-350 Handset
- 17 mm Imager
- 3' (90 cm) USB Cable
- 3' (90 cm) RCA Cable with Audio
- Hook, Magnet, Mirror Attachments
- 12 V Li-Ion Battery
- · Li-Ion Battery Charger with Cord
- AC Adapter
- Headset Accessory with Microphone
- 8 GB SD[™] Card
- Operator's Manual Pack



Figure 1 – micro CA-350 Inspection Camera

Controls









Figure 4 – Left Side Port Cover

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment OFF and ON, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/-TV technician for help.

Electromagnetic Compatibility (EMC)

The term electromagnetic compatibility is taken to mean the capability of the product to function smoothly in an environment where electromagnetic radiation and electrostatic discharges are present and without causing electromagnet interference to other equipment.

NOTICE The RIDGID micro CA-350 Inspection Camera conforms to all applicable EMC standards. However, the possibility of it causing interference in other devices cannot be precluded.

lcons

	Battery Life Indicator – Fully charged battery.
	Battery Life Indicator – Less than 25% of battery charge remains.
5>	SD[™] Card – Indicates an SD card has been inserted into the device.
	Still Camera – Indicates device is operat- ing in still camera mode.
	Video Camera – Indicates device is oper- ating in video camera mode.
Þ	Playback Mode – Selecting this icon al- lows you to view and delete previously saved images and video.
	Menu – Push select on this icon to be taken to the menu screen.
	Select – Pressing select from the live screen will take you to the playback screen.
٦	Return – Pressing return from the live screen will switch between camera and video. Return will also back out of menu and playback mode.
	LED Brightness – Press right & left ar- rows to change the LED brightness.
0	Zoom – Press up & down arrows to change the zoom from 1.0x to 2.0x.
	Save – Indicates image or video has been saved to memory.
	Trash – Delete confirmation icon.
	Mode – Select between image, video or playback.
R	Time Stamp – Select to display or hide date and time on live screen.
	Language – Choose between, English, French, Spanish, German, Dutch, Italian, etc.
	Time and Date – Enter this screen to set time and date.
Ĕ,	TV – Chose between NTSC and PAL to enable TV out video format.
	Update Firmware – Use to update unit with most current software.
	Speaker/Microphone – Turns speaker and microphone ON or OFF during recording and playback.
\bigcirc	Automatic Power Off – Device will auto- matically shut down after 5, 15 or 60 min- utes of inactivity.
\bigcirc	Factory Reset – Restore factory defaults.
?	About – Displays software version.

Tool Assembly

A WARNING

To reduce the risk of serious injury during use, follow these procedures for proper assembly.

Changing/Installing Batteries

The micro CA-350 is supplied without the battery installed. If the battery indicator displays \implies , the battery needs to be recharged. Remove the battery prior to storage.

1. Squeeze the battery tabs (See Figure 5) and pull to remove battery.



Figure 5 – Removing/Installing Battery

2. Insert contact end of battery into the inspection tool, as shown in *Figure 5*.

Powering with the AC Adapter

The micro CA-350 Inspection Camera can also be powered using the supplied AC Adapter.

- 1. Open the right side port cover (Figure 3).
- 2. With dry hands, plug the AC adapter into the outlet.
- Insert the AC adapter barrel plug into the port marked "DC 12V".



Figure 6 – Powering the Unit with AC Adapter

Installing the Imager Head Cable or Extension Cables

To use the micro CA-350 Inspection Camera, the imager head cable must be connected to the handheld display unit. To connect the cable to the handheld display unit, make sure the camera socket key and display unit socket slot (*Figure 7*) are properly aligned. Once they are aligned, finger tighten the knurled knob to hold the connection in place.



Figure 7 – Cable Connections

3' (90 cm) and 6' (180 cm) cable extensions are available to increase the length of your camera cable up to 30 feet (9 m). To install an extension, first remove the camera head cable from the display unit by loosening the knurled knob. Connect the extension to the handheld as described above (*Figure 7*). Connect the keyed end of the camera head cable to the slotted end of the extension and finger tighten the knurled knob to hold the connection in place.

Installing Accessories

The three included accessories, (Hook, Magnet, Mirror) all attach to the imager head the same way.




Figure 8 – Installing an Accessory

To connect, hold the imager head as shown in *Figure 8*. Slip the semicircle end of the accessory over the flats of the imager head. Then rotate the accessory a 1/4 turn to retain.

Installing SD[™] Card

Open the left side port cover (*Figure 4*) to access the SD card slot. Insert the SD card into the slot making sure the contacts are facing towards you and the angled portion of the card is facing down (*Figure 9*). SD cards can only be installed one way – do not force. When an SD card is installed, a small SD card icon will appear in the upper left hand portion of the screen, along with the number of images or length of video that can be stored on the SD card.



Figure 9 - Inserting the SD Card

Pre-Operation Inspection

A WARNING



Before each use, inspect your Inspection Camera and correct any problems to reduce the risk of serious injury from electric shock and other causes and prevent tool damage.

- 1. Make sure the unit is OFF.
- Remove the battery and inspect it for signs of damage. Replace battery if necessary. Do not use Inspection Camera if the battery is damaged.
- Clean any oil, grease or dirt from the equipment. This aids inspection and helps prevent the tool from slipping from your grip.
- Inspect micro CA-350 Inspection Camera for any broken, worn, missing or binding parts or any condition which may prevent safe and normal operation.
- Inspect the camera head lens for condensation. To avoid damaging the unit, do not use the camera if condensation forms inside the lens. Let the water evaporate before using.
- Inspect the full length of the cable for cracks or damage. A damaged cable could allow water to enter the unit and increase the risk of electrical shock.

- Check to make sure the connections between the handheld unit, extension cables and imager cable are tight. All connections must be properly assembled for the cable to be water resistant. Confirm unit is properly assembled.
- Check that the warning label is present, firmly attached and readable (*Figure 10*).



Figure 10 – Warning Label

- If any issues are found during the inspection, do not use the inspection camera until it has been properly serviced.
- 10. With dry hands, re-install the battery.
- 11. Press and hold the Power Button for one second. The imager lights should come on, then a splash screen will appear. Once the camera is ready, a live image of what the camera sees is displayed on the screen. Consult the *Troubleshooting* section of this manual if no picture appears.
- 12. Press and hold the Power Button for one second to turn camera OFF.

Tool and Work Area Set-Up



Set up the micro CA-350 Inspection Camera and work area according to these procedures to reduce the risk of injury from electrical shock, entanglement and other causes and prevent tool damage.

- 1. Check work area for:
 - Adequate lighting
 - Flammable liquids, vapors or dust that may ignite. If present, do not work in area until sources have been identified and corrected. The micro CA-350 Inspection Camera is not explosion proof and can cause sparks.
 - Clear, level, stable, dry place for operator. Do not use the inspection camera while standing in water.
- Examine the area or space that you will be inspecting and determine if the micro CA-350 Inspection Camera is the correct piece of equipment for the job.
 - Determine the access points to the space. The minimum opening the camera head can fit through is approximately ³/₄" (19 mm) in diameter for the 17 mm camera head.
 - Determine the distance to the area to be inspected. Extensions can be added to the camera to reach up to 30' (9 m).
 - Determine if there are any obstacles that would require very tight turns in the cable. The inspection camera cable can go down to a 5" (127 mm) radius without damage.
 - Determine if there is any electrical power supplied to the area to be inspected. If so, the power to the area must be turned OFF to reduce the risk of electric shock. Use appropriate lock out procedures to prevent the power from being turned back on during the inspection.
 - Determine if any liquids will be encountered during the inspection. The cable and imager head are waterproof to a depth of 10' (3 m). Greater depths may cause leakage into the cable and imager and cause electric shock or damage the equipment. The handheld display unit is water resistant (IP54) but should not be submerged in water.
 - Determine if any chemicals are present, especially in the case of drains. It is important to understand the specific safety measures required to work around any chemicals present. Contact the chemical manufacturer for required information. Chemicals may damage or degrade the inspection camera.
 - Determine the temperature of the area and items in the area. See Specifica-

tions. Use in areas outside of specification temperatures or contact with hotter or colder items could cause camera damage.

Determine if any moving parts are present in the area to be inspected. If so, these parts must be deactivated to prevent movement during inspection to reduce the risk of entanglement. Use appropriate lock out procedures to prevent the parts from moving during the inspection.

If the micro CA-350 Inspection Camera is not the correct piece of equipment for the job, other inspection equipment is available from RIDGID. For a complete listing of RIDGID products, see the RIDGID catalog.

- Make sure the micro CA-350 Inspection Camera has been properly inspected before each use.
- Install the correct accessories for the application.

Operating Instructions

🛦 WARNING



Always wear eye protection to protect your eyes against dirt and other foreign objects.

Follow operating instructions to reduce the risk of injury from electrical shock, entanglement and other causes.

- Make sure that the Inspection Camera and work area have been properly set up and that the work area is free of bystanders and other distractions.
- Press and hold the Power Button for two seconds. The imager lights should come ON, then a splash screen will appear. This screen tells you the device is booting up. Once the product is fully powered up, the screen will automatically switch to the live screen.



Figure 11 – Splash Screen (Note: Version will change with each firmware update.)

Live Screen

The live screen is where you will do most of your work. A live image of what the camera sees is displayed on the screen. You can zoom, adjust LED brightness and take images or video from this screen.

The screen has a status bar at the top showing the tool mode, zoom, SD[™] card icon if inserted, available memory and speaker/mic ON/OFF. The bottom bar shows information about date and time if time stamp is ON.




Figure 12 – Live Screen

When the Inspection Camera is turned ON, the default mode is for capturing still images. Pressing the menu button at any time will access the menu. The menu will overlay on the LIVE Screen. Use the right and left arrow > 4 buttons to switch to the MODE category. Use the up and down arrows $\land \lor$ to navigate between menu items and press select \bigcirc as desired.





- If the other inspection camera settings (Time Stamp, Language, Date/Time, TV Out, Update Firmware, Speaker/Microphone, Auto Power OFF, Factory Reset) need to be adjusted, see Menu Section.
- 4. Prepare the camera for inspection. The camera cable may need to be pre-formed or bent to properly inspect the area. Do not try to form bends less than 5" (13cm) radius. This can damage cable. If inspecting a dark space, turn the LEDs on before inserting the camera or cable.

Do not use excessive force to insert or withdraw the cable. This may result in damage to the inspection camera or inspection area. Do not use the cable or imager head to modify surroundings, clear pathways or clogged areas, or as anything other than an inspection device. This may result in damage to the Inspection camera or inspection area.

Image Adjustment

Adjust LED Brightness : Pressing the right and left arrow button > < on the button pad (In live screen) will increase or decrease the LED brightness. A brightness indicator bar will be displayed on the screen as you adjust brightness.



Figure 14 – Adjusting LED

Zoom : The micro CA-350 Inspection Camera has a 2.0x digital zoom. Simply press the up and down arrows ▲ ¥ while in the live screen to zoom in or out. A zoom indicator bar will be displayed on the screen as you adjust your zoom.



Figure 15 – Adjusting Zoom

Image Rotation : If needed, the image/video seen on the screen can be rotated in 90 degree increments counter clockwise by pressing the rotate image button (a).

Image Capture

Capturing a Still Image

While in the live screen, make sure the still camera icon **●** is present at the top left portion of the screen. Press the shutter button to capture the image. The save icon **●** will momentarily appear on the screen. This indicates the still image has been saved to the internal memory or SDTM card.

Capturing a Video

While in the live screen, make sure the video camera icon is present at the top left portion of the screen. Press the shutter button to start capturing video. When the device is recording a video, a red outline will flash around

the video mode icon and the recording duration will show at the top of the screen. Press the shutter button again to stop the video. It may take several seconds to save the video if saving to the internal memory.

The micro CA-350 features an integrated microphone and speaker for recording and playback of audio with video. A headset with integrated microphone is included and may be used instead of the integrated speaker and microphone. Plug the headset into the audio port on the right side of the camera.

When the inspection is complete, carefully withdraw the camera and cable from the inspection area.



Figure 16 – Video Recording Screen

Menu

Pressing the Menu button at any time will access the menu. The menu will overlay on the LIVE Screen. From the menu, the user will be able to change to the various modes or enter the settings menu.

There are different setting categories to choose from (*Figure 17*) while in the settings screen. Use the right and left arrow buttons > < to switch from one category to the next. Use the up and down arrows $\land \lor$ to navigate the menu items. The selected category will be highlighted with a bright red outline. Once the desired setting is reached, press select to change to the new selection. The changes are automatically saved when they are changed.

While in menu mode, you can press the Return button <u>to return</u> to the previous screen or to the live screen.



Figure 17 – Settings Screen

Playback Mode

- Pressing the Select button in the live screen will enter playback mode. Select either Image or Video to playback the desired file. The playback mode is the interface into saved files. It will default to the last file recorded.
- While reviewing the image the user will be able to cycle through all saved images, delete an image and display file information.
- While reviewing a video, a user will be able to navigate through videos, pause, restart and delete. A user will only be able to playback images and video from internal memory when SD[™] Card is not inserted.

Deleting Files

Press Menu button image or video. The delete confirmation dialog allows the user to delete unwanted files. The active icon is outlined in red. Navigation is done with the arrow buttons <>.

Time Stamp 🔞

Enable or Disable the display of the Date and Time.

Language 💽

Select the "Language" icon in the menu and press Select. Select different languages with up/down arrow buttons A v, then press Select to save the language setting.

Date/Time 🔛

Select Set Date or Set Time to set the current date or time. Select Format Date or Time to change how the date/time is displayed.

TV-Out 🔜

Select the "NTSC" or "PAL" to enable the TV-Out for the video format required. Screen will go black and image will be transmitted to external screen. To get live image on unit, hit Power button () to disable function.

Update Firmware 🖻

Select Update Firmware to install the latest version of software on the unit. Software will have to be loaded onto a SD[™] Card and in-serted in to the unit.

Speaker 🔟

Select the Speaker icon in the menu and press Select \bigodot . Select ON or OFF with up/down button \checkmark to keep the speaker ON or OFF during video playback.

Auto Power Off 💽

Select the Auto Power Off icon and press select or Select disable to turn OFF the automatic shut down function. Select the 5 Minutes, 15 Minutes or 60 Minutes to turn OFF the tool upon 5/15/60 minutes of non-operation. Automatic shut down setting will not be activated when recording or playing video.

Factory Reset 💽

Select the Reset icon and press Select Confirm the reset function by selecting Yes and press Select again. This will reset the tool to the factory set up.

About 💽

Select the About function to display the firmware revision of the micro CA-350 as well as the software copyright information.

Transferring Images to a Computer

With the unit powered ON, connect the micro CA-350 to a computer using the USB cable. The USB connected screen is displayed on the micro CA-350. The internal memory and SDTM card (if applicable) will appear as separate drives on the computer and are now accessible as a standard USB storage device. The copy and delete options are available from computer operation.

Connecting to TV

The micro CA-350 Inspection Camera can be connected to a television or other monitor for remote viewing or recording through the included RCA cable.

Open the right side port cover (Figure 3). Insert the RCA cable into the TV-Out jack. Insert the other end of the cable into the Video-In jack on the television or monitor. Check to make sure the video format (NTSC or PAL) output is set properly. The television or monitor may need to be set to the proper input to allow viewing. Select the appropriate TV-Out format using the menu.

Use with SeeSnake® Inspection Equipment

The micro CA-350 Inspection Camera can also be used with various SeeSnake Inspection Equipment and is specifically designed to be used with the microReel, microDrain[™] and the nanoReel Inspection Systems. When used with these types of equipment, it retains all of the functionality described in this manual. The micro CA-350 Inspection Camera can also be used with other SeeSnake Inspection Equipment for viewing and recording only.

For use with SeeSnake Inspection Equipment, the imager head and any cable extensions must be removed. For the microReel, microDrain[™], nanoReel and similar equipment, see the operator's manual for information on proper connection and use. For other SeeSnake Inspection Equipment (typically a reel and monitor), an adapter must be used to connect the micro CA-350 Inspection Camera to a Video-Out port on the SeeSnake Inspection Equipment. When connected in this manner, the micro CA-350 Inspection Camera will display the camera view and can be used for recording.

When connecting to SeeSnake Inspection Equipment (microReel, microDrain[™], or nano-Reel), align the interconnect module connected to your reel with the cable connector on the micro CA-350 Inspection Camera, and slide it straight in, seating it squarely. (See Figure 18)



Figure 18 – Camera Connector Plug Installed

NOTICE Do not twist the connector plug to prevent damage.

Locating the Sonde

If used with a sonde (In-Line Transmitter), the sonde can be controlled two ways. If the reel is equipped with a sonde key, that can be used to turn the sonde ON and OFF. Otherwise, the sonde is turned ON by decreasing LED brightness to zero. Once the Sonde has been located, the LEDs can be returned to their normal brightness level to continue the inspection.

A RIDGID locator such as the SR-20, SR-60, Scout[®], or NaviTrack[®] II set to 512 Hz can be used to locate features in the drain being inspected.




Figure 19 – Locating the Reel Sonde

To locate the Sonde, turn the locator ON and set it to Sonde mode. Scan in the direction of the Sonde's probable location until the locator detects the Sonde. Once you have detected the Sonde, use the locator indications to zero in on its location precisely. For detailed instructions on Sonde locating, consult the Operator's Manual for the locator model you are using.

Maintenance

A WARNING

Remove battery before cleaning.

- Always clean the imager head and cable after use with mild soap or mild detergent.
- Gently clean the display screen with a clean dry cloth. Avoid rubbing too hard.
- Use only alcohol swabs to clean the cable connections.
- Wipe the hand held display unit down with a clean, dry cloth.

Reset Function

If the unit stops functioning and does not operate, press the Reset Button (*under the left side port cover – Figure 4*). The unit may recover to normal operation when restarted.

Optional Equipment

A WARNING

To reduce the risk of serious injury, only use equipment specifically designed and recommended for use with the RIDGID micro CA-350 Inspection Camera such as those listed below. Other equipment suitable for use with other tools may be hazardous when used with the micro CA-350 Inspection Camera.

Catalog No.	Description
37108	3' (90 cm) Cable Extension
37113	6' (180 cm) Cable Extension
37103	Imager Head and Cable - 17 mm
37098	1 m length 6mm diameter imager
37093	4 m length 6mm diameter imager
37123	17 mm Accessory Pack (Hook, Magnet, Mirror)
36758	AC Adapter
40623	Headset Accessory with Microphone

RBC-121 Chargers and Cords

Catalog No.		Region	Plug Type
55193	Charger	USA, Canada and Mexico	Α
55198	Charger	Europe	С
55203	Charger	China	Α
55208	Charger	Australia & Latin America	Ι
55213	Charger	Japan	Α
55218	Charger	United Kingdom	G
44798	Charger Cord	North America	Α
44808	Charger Cord	Europe	С
44803	Charger Cord	China	Α
44813	Charger Cord	Australia & LA	Ι
44818	Charger Cord	Japan	Α
44828	Charger Cord	United Kingdom	G

Batteries

Catalog No.	Model	Capacity
55183	RB-1225	12V 2.5Ah

All listed batteries will work with any catalog number RBC-121 Battery Charger.

Storage

The RIDGID micro CA-350 Inspection Cam era must be stored in a dry secure area between $-4^{\circ}F$ (-20°C) and 140°F (60°C) and humidity between 15% and 85% RH.

Store the tool in a locked area, out of the reach of children and people unfamiliar with the micro CA-350 Inspection Camera.

Remove the battery before storage or shipping.

Service and Repair

A WARNING

Improper service or repair can make the RIDGID micro CA-350 Inspection Camera unsafe to operate.

Service and repair of the micro CA-350 Inspection Camera must be performed by a RIDGID Independent Authorized Service Center.

For information on your nearest RIDGID Independent Service Center or any service or repair questions.

micro CA-350 Inspection Camera RIDG

Disposal

Parts of the RIDGID micro CA-350 Inspection Camera contain valuable materials and can be recycled. There are companies that specialize in recycling that may be found locally. Dispose of the components in compliance with all applicable regulations. Contact your local waste management authority for more information.



For EC Countries: Do not dispose of electrical equipment with house-hold waste!

According to the European Guideline 2012/19/EU for Waste Electrical and Electronic Equipment and its

implementation into national legislation, electrical equipment that is no longer usable must be collected separately and disposed of in an environmentally correct manner.

Troubleshooting

SYMPTOM	POSSIBLE REASON	SOLUTION
Display turns ON, but does not show image.	Loose cable connections.	Check cable connections, clean if re- quired. Re-attach.
	Imager is broken.	Replace the Imager.
	Imager head covered by debris.	Visually inspect imager head to make certain it is not covered by debris.
LEDs on imager head are dim at max bright- ness, display switches between black and white, color display turns itself OFF after a brief period.	Battery low on power.	Replace battery with charged battery.
Unit will not turn ON.	Dead battery.	Replace with charged battery.
	Unit need to be reset.	Reset unit. See "Maintenance" Section.



Visit us at www.TestEquipmentDepot.com

Printed 6/18 EC42736 ©2016, 2018 RIDGID, Inc. The Emerson logo and RIDGID logo are registered trademarks of Emerson Electric Co. or RIDGID, Inc. in the U.S. and other countries. All other trademarks belong to their respective holders.





